

Configuration No.	Berrima to Cootamundra	CTM Endorsed By	Deane Thrower	Version
Weekend No.	20	Date Endorsed	09/11/2023	V1-09/11/23
TAA Number	1358-2023	CTM Coordinator	PPO	
Legend	Priority Movements	Changing Tracks	Test Train	Possession Details
Possession Limits and Power Outage Sections as per advertised is TAA				

NOTE: Competent worker/s are to be arranged for work train and track machine movements, including Propelling and Piloting of trains when entering, exiting and within the possession limits.

NOTE: No equipment or infrastructure should be booked out (IBA) or left inoperable that would interfere with the operation of the CTM without approval prior to the possession.

MOVEMENT No.	Run Number	Forms Run Number	TIMES			Work Train/Track Machine Name	Work Train/Track Machine Consist	Movement			Worksite	Instructions	Traffic Officer/Pilot (Phone Number)	FORMS MOVEMENT No.	Supervisor / ARTC Site Rep (Phone Number)
			ENTER POSSESSION BOUNDARY	EXIT POSSESSION BOUNDARY	WORKSITE TIME			From	To	Track					
Saturday															
1					0600-0645	Martinus Rail PL Pandrol Jackson Tampers	Pandrol Jackson Tamper & Ballast Regulator	Wingello	Wingello		Briefing	Resurfacing Team starts at Wingello Station-Upside at 0600 hours and complete Briefing	David Trajcevski Ph: 0410 530 775	6	Kurt Beatty Ph: 0437 844 266
2					0600-0645	Brimble Rail PL Unimat Tampers	Unimat Tamper & Ballast Regulator	Goulburn	Goulburn	Siding	Briefing	Resurfacing Team starts at Wingello Station-Upside at 0600 hours and complete Briefing	Sione Vunga Ph: 0423 330 279	3	Mark Tuxford Ph: 0476 047 157
3					0600-0645	RSA 093XD (HSP1) Tampers	09-3XD Tamper & Ballast Regulator	Yass	Yass	Siding	Briefing	Resurfacing Team starts at Yass Yard at 0600 hours and complete Briefing	Anthony Andrew Ph: 0488 416 888	4	Kale Stanton Ph: 0401 855 381
4	3M42		0615		0615-0630	Rail Train 1	Locomotive Railset Locomotive	Yass	306km	DOWN Main	Travel	Travel on DOWN Main to Worksite Train PUSH/PULL	Nick Moutos 0424 237 147	5	Adrian Unwin 0419 634 639
5		3M43			0630-1000	Rail Train 1	Locomotive Railset Locomotive	306km	310km	DOWN Main	UNLOAD	UNLOAD 33 Rails	Nick Moutos 0424 237 147	16	Adrian Unwin 0419 634 639
6					0645-0745	Martinus Rail PL Pandrol Jackson Tampers	Pandrol Jackson Tamper & Ballast Regulator	Wingello	Wingello	Siding	Briefing	Crane In Tampers onto Up Goods Siding	David Trajcevski Ph: 0410 530 775	10	Kurt Beatty Ph: 0437 844 266
7					0645-0715	Brimble Rail PL Unimat Tampers	Unimat Tamper & Ballast Regulator	Goulburn	Breadalbane	Up Main	Travel	Tampers Travel at Up Main to Resurfacing Location at 244.100km Breadalbane	Sione Vunga Ph: 0423 330 279	8	Mark Tuxford Ph: 0476 047 157
8					0715-1430	Brimble Rail PL Unimat Tampers	Unimat Tamper & Ballast Regulator	Breadalbane	Breadalbane	Up Main	Tamping	Tamp Up Main: 244.100-247.900km	Sione Vunga Ph: 0423 330 279	21	Mark Tuxford Ph: 0476 047 157
9					0730-1100	RSA 093XD (HSP1) Tampers	09-3XD Tamper & Ballast Regulator	Yass	Yass	Up Main	Tamping	Tamp Up Main: 323.000-324.300km	Anthony Andrew Ph: 0488 416 888	18	Kale Stanton Ph: 0401 855 381
10					0745-0800	Martinus Rail PL Pandrol Jackson Tampers	Pandrol Jackson Tamper & Ballast Regulator	Wingello	Bundanoon	Up Main	Travel	Tampers exit Wingello Yard at Up Main and travel to Resurfacing Location at 162.850km Up Main	David Trajcevski Ph: 0410 530 775	11	Kurt Beatty Ph: 0437 844 266
11					0800-1700	Martinus Rail PL Pandrol Jackson Tampers	Pandrol Jackson Tamper & Ballast Regulator	Bundanoon	Bundanoon	Up Main	Tamping	Tamp Up Main: 162.850-162.200km (Including Resurfacing at 2CA & 4CA Pts Turnouts) and Up Main thorough Bundanoon Platform	David Trajcevski Ph: 0410 530 775	22	Kurt Beatty Ph: 0437 844 266
12	2M44		0830		0830-0840	Ballast Train 1	Locomotive - Ballast Train - Locomotive	Marulan	Medway	DOWN Main	Travel	Depart Marulan DOWN Siding Travel on DOWN Main to Medway, Cross to UP MAIN via 51 pts Train PUSH/PULL	Pilot day shift 0600-1800 Ken Mills 0427 771 579 Pilot night shift 1800-0600 Ronnie Akbal 0474 777 182	13	Steve Twyford 0419 465 552

NOTE: Competent worker/s are to be arranged for work train and track machine movements, including Propelling and Piloting of trains when entering, exiting and within the possession limits.

NOTE: No equipment or infrastructure should be booked out (IBA) or left inoperable that would interfere with the operation of the CTM without approval prior to the possession.

MOVEMENT No.	Run Number	Forms Run Number	TIMES			Work Train/Track Machine Name	Work Train/Track Machine Consist	Movement			Worksite	Instructions	Traffic Officer/Pilot (Phone Number)	FORMS MOVEMENT No.	Supervisor / ARTC Site Rep (Phone Number)
			ENTER POSSESSION BOUNDARY	EXIT POSSESSION BOUNDARY	WORKSITE TIME			From	To	Track					
13		2M45			0840-0600 (Sun)	Ballast Train 1	Locomotive - Ballast Train - Locomotive	Medway	180km	UP Main	UNLOAD	Work CONTINUOUSLY until 0600 Sunday 12th Stable Tallong Station	Pilot day shift 0600-1800 Ken Mills 0427 771 579 Pilot night shift 1800-0600 Ronnie Akbal 0474 777 182	END	Steve Twyford 0419 465 552
14					0900-0945	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Goulburn	Goulburn	Siding	Briefing	Resurfacing Team starts at Goulburn Yard at 0900 hours and complete Briefing	Rob May Ph: 0428 641 708	15	Shane Robbins Ph: 0400 067 171
15					0945-1045	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Goulburn	Medway	Up Main	Travel	Tampers exit Goulburn Yard at Up Main and travel to 188.500km Medway Sledding Site	Rob May Ph: 0428 641 708	17	Shane Robbins Ph: 0400 067 171
16	3M43				1000-1030	Rail Train 1	Locomotive Railset Locomotive	310km	Yass	DOWN Main	Travel	Travel to Yass STABLE in Yard	Nick Moutos 0424 237 147	END	Adrian Unwin 0419 634 639
17					1045-1845	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Medway	Tallong	Up Main	Tamping	Tamp Up Main: 188.500-185.381km (Sledding Site) - Multiple Passes required	Rob May Ph: 0428 641 708	18	Shane Robbins Ph: 0400 067 171
18					1130-1300	RSA 093XD (HSP1) Tampers	09-3XD Tamper & Ballast Regulator	Bowning	Bowning	Up Main	Tamping	Tamp Up Main: 326.500-327.500km	Anthony Andrew Ph: 0488 416 888	19	Kale Stanton Ph: 0401 855 381
19					1330-1430	RSA 093XD (HSP1) Tampers	09-3XD Tamper & Ballast Regulator	Bowning	Bowning	Up Main	Tamping	Tamp Up Main: 329.000-329.500km	Anthony Andrew Ph: 0488 416 888	20	Kale Stanton Ph: 0401 855 381
20					1445-1800	RSA 093XD (HSP1) Tampers	09-3XD Tamper & Ballast Regulator	Bowning	Bowning	Up Main	Tamping	Tamp Up Main: 331.800-334.000km	Anthony Andrew Ph: 0488 416 888	25	Kale Stanton Ph: 0401 855 381
21					1445-1800	Brimble Rail PL Unimat Tampers	Unimat Tamper & Ballast Regulator	Cullerin	Cullerin	Up Main	Tamping	Tamp Up Main: 256.016-257.801km	Sione Vunga Ph: 0423 330 279	24	Mark Tuxford Ph: 0476 047 157
22					1700-1730	Martinus Rail PL Pandrol Jackson Tampers	Pandrol Jackson Tamper & Ballast Regulator	Bundanoon	Bundanoon	Up Main to Down Main	Transfer & Travel	Transfer Tampers at 162.174km-3BA Pts from Up Main to Down Main Stabel at 162.100km at Down Main	David Trajcevski Ph: 0410 530 775	35	Kurt Beatty Ph: 0437 844 266
23					1800	Martinus Rail PL Pandrol Jackson Tampers	Pandrol Jackson Tamper & Ballast Regulator	Bundanoon	Bundanoon	Down Main	Stable	Stable Tampers at 162.100km Down Main (Cityside of 3BA Pts) Bundanoon	David Trajcevski Ph: 0410 530 775	35	Kurt Beatty Ph: 0437 844 266
24					1830-2330	Brimble Rail PL Unimat Tampers	Unimat Tamper & Ballast Regulator	Oolong	Oolong	Up Main	Tamping	Tamp Up Main: 286.335-288.751km	Simon Weeks Ph: 0498 139 884	31	Jack Richards Ph: 0448 680 752
25					1845-1915	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Tallong	Medway	Up Main	Travel	Reverse Tampers at Up Main to Resurfacing Location at 189.200km	Rob May Ph: 0428 641 708	27	Shane Robbins Ph: 0400 067 171
26					1900-2200	RSA 093XD (HSP1) Tampers	09-3XD Tamper & Ballast Regulator	Bowning	Bowning	Up Main	Tamping	Tamp Up Main: 335.000-336.400km	Damian Smith Ph: 0407 874 227	30	Kyle Van Woerkom Ph: 0400 763 989
27					1915-2030	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Medway	Medway	Up Main	Tamping	Tamp Up Main: 189.200-188.500km	Rob May Ph: 0428 641 708	28	Shane Robbins Ph: 0400 067 171
28					2030-2045	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Medway	Marulan	Up Main	Travel	Reverse Tampers at Up Main to 192.870km Marulan Station Platform	Rob May Ph: 0428 641 708	29	Shane Robbins Ph: 0400 067 171
29					2100	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Marulan	Marulan	Up Main	Stable	Stable Tampers at 192.870km Up Main at Marulan Station	Rob May Ph: 0428 641 708	38	Shane Robbins Ph: 0400 067 171

NOTE: Competent worker/s are to be arranged for work train and track machine movements, including Propelling and Piloting of trains when entering, exiting and within the possession limits.

NOTE: No equipment or infrastructure should be booked out (IBA) or left inoperable that would interfere with the operation of the CTM without approval prior to the possession.

MOVEMENT No:	Run Number	Forms Run Number	TIMES			Work Train/Track Machine Name	Work Train/Track Machine Consist	Movement			Worksite	Instructions	Traffic Officer/Pilot (Phone Number)	FORMS MOVEMENT No.	Supervisor / ARTC Site Rep (Phone Number)
			ENTER POSSESSION BOUNDARY	EXIT POSSESSION BOUNDARY	WORKSITE TIME			From	To	Track					
30					2230-2330	RSA 093XD (HSP1) Tampers	09-3XD Tamper & Ballast Regulator	Binalong	Binalong	Up Main	Tamping	Tamp Up Main: 346.300-346.700km	Damian Smith Ph: 0407 874 227	32	Kyle Van Woerkom Ph: 0400 763 989
31					2340 hours on 11 Nov to 0115 hours on 12 Nov 2023	Brimble Rail PL Unimat Tampers	Unimat Tamper & Ballast Regulator	Oolong	Oolong	Up Main	Tamping	Tamp Up Main: 291.342-292.043km	Simon Weeks Ph: 0498 139 884	33	Jack Richards Ph: 0448 680 752
Sunday															
32					0030-0600	RSA 093XD (HSP1) Tampers	09-3XD Tamper & Ballast Regulator	Binalong	Binalong	Up Main	Tamping	Tamp Up Main: 349.700-351.800km	Damian Smith Ph: 0407 874 227	39	Kyle Van Woerkom Ph: 0400 763 989
33					0115-0145	Brimble Rail PL Unimat Tampers	Unimat Tamper & Ballast Regulator	Oolong	Jerrawa	Up Main to Down Main	Travel & Transfer	Transfer Tampers from Up Main to Down Main at 297.410km B Pts and travel at Down Main to Resurfacing Location at 290.800km	Simon Weeks Ph: 0498 139 884	34	Jack Richards Ph: 0448 680 752
34					0145-0600	Brimble Rail PL Unimat Tampers	Unimat Tamper & Ballast Regulator	Jerrawa	Jerrawa	Down Main	Tamping	Tamp Down Main: 290.800-292.800km	Simon Weeks Ph: 0498 139 884	35	Jack Richards Ph: 0448 680 752
35					0600-0645	Martinus Rail PL Pandrol Jackson Tampers	Pandrol Jackson Tamper & Ballast Regulator	Bundanoon	Bundanoon	Down Main	Briefing	Resurfacing Team starts at Bundanoon Station at 0600 hours and complete Briefing	David Trajcevski Ph: 0410 530 775	37	Kurt Beatty Ph: 0437 844 266
36					0630-1000	Brimble Rail PL Unimat Tampers	Unimat Tamper & Ballast Regulator	Oolong	Oolong	Down Main	Tamping	Tamp Down Main: 276.500-278.300km	Sione Vunga Ph: 0423 330 279	43	Mark Tuxford Ph: 0476 047 157
37					0645-1300	Martinus Rail PL Pandrol Jackson Tampers	Pandrol Jackson Tamper & Ballast Regulator	Bundanoon	Bundanoon	Down Main	Tamping	Tamp Down Main: 162.850-162.200km (Including Resurfacing at 2CB Pts Turnout, 2C Crossover) and Resurfacing Down Main through Bundanoon Platform	David Trajcevski Ph: 0410 530 775	48	Kurt Beatty Ph: 0437 844 266
38					0700-0745	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Marulan	Marulan	Up Main	Briefing	Resurfacing Team starts at Marulan Station at 0700 hours and complete Briefing	Rob May Ph: 0428 641 708	40	Shane Robbins Ph: 0400 067 171
39					0700-0900	RSA 093XD (HSP1) Tampers	09-3XD Tamper & Ballast Regulator	Galong	Galong	Up Main	Tamping	Tamp Up Main: 354.200-355.500km	Anthony Andrew Ph: 0488 416 888	42	Kale Stanton Ph: 0401 855 381
40					0745-0800	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Marulan	Medway	Up Main	Travel	Tampers travel at Up Main to Sledding Site at 188.500km	Rob May Ph: 0428 641 708	41	Shane Robbins Ph: 0400 067 171
41					0800-1200	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Medway	Tallong	Up Main	Tamping	Tamp Up Main: 188.500-185.500km (Sledding Site Follow Up Tamping)	Rob May Ph: 0428 641 708	45	Shane Robbins Ph: 0400 067 171
42					0930-1030	RSA 093XD (HSP1) Tampers	09-3XD Tamper & Ballast Regulator	Galong	Galong	Up Main	Tamping	Tamp Up Main: 367.000-367.800km	Anthony Andrew Ph: 0488 416 888	44	Kale Stanton Ph: 0401 855 381
43					1015-1145	Brimble Rail PL Unimat Tampers	Unimat Tamper & Ballast Regulator	Fish River	Fish River	Down Main	Tamping	Tamp Down Main: 272.740-273.124km (Excessive Superelevation Correction Required)	Sione Vunga Ph: 0423 330 279	46	Mark Tuxford Ph: 0476 047 157
44					1100-1330	RSA 093XD (HSP1) Tampers	09-3XD Tamper & Ballast Regulator	Cunningar	Cunningar	Up Main	Tamping	Tamp Up Main: 372.300-373.900km	Anthony Andrew Ph: 0488 416 888	49	Kale Stanton Ph: 0401 855 381
45					1200-1230	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Tallong	Wingello	Up Main to Down Main	Travel & Transfer	Reverse Tampers at Up Main to 189.730km-51A Pts, Transfer from Up Main to Down Main and travel at Down Main to Resurfacing Location at 178.907km	Rob May Ph: 0428 641 708	47	Shane Robbins Ph: 0400 067 171
46					1200-1500	Brimble Rail PL Unimat Tampers	Unimat Tamper & Ballast Regulator	Cullerin	Cullerin	Down Main	Tamping	Tamp Down Main starting at 267.400km and progress towards 269.450km - Resurface & Regulate till 1500 hours. Resurfacing & Regulating must stop at 1500 hours and Tampers start travelling at 1500 hours towards Goulburn Yard.	Sione Vunga Ph: 0423 330 279	56	Mark Tuxford Ph: 0476 047 157

NOTE: Competent worker/s are to be arranged for work train and track machine movements, including Propelling and Piloting of trains when entering, exiting and within the possession limits.

NOTE: No equipment or infrastructure should be booked out (IBA) or left inoperable that would interfere with the operation of the CTM without approval prior to the possession.

MOVEMENT No.	Run Number	Forms Run Number	TIMES			Work Train/Track Machine Name	Work Train/Track Machine Consist	Movement			Worksite	Instructions	Traffic Officer/Pilot (Phone Number)	FORMS MOVEMENT No.	Supervisor / ARTC Site Rep (Phone Number)
			ENTER POSSESSION BOUNDARY	EXIT POSSESSION BOUNDARY	WORKSITE TIME			From	To	Track					
47					1230-1500	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Wingello	Wingello	Down Main	Tamping	Tamp Down Main: 178.907-177.060km	Rob May Ph: 0428 641 708	55	Shane Robbins Ph: 0400 067 171
48					1330-1500	Martinus Rail PL Pandrol Jackson Tampers	Pandrol Jackson Tamper & Ballast Regulator	Exeter	Exeter	Down Main	Tamping	Down Main: 153.900-153.400km	David Trajcevski Ph: 0410 530 775	57	Kurt Beatty Ph: 0437 844 266
49					1330-1430	RSA 093XD (HSP1) Tampers	09-3XD Tamper & Ballast Regulator	Cunningar	Cunningar	Up Main	Tamping	Resurface as per ARTC Site Representative Instructions	Anthony Andrew Ph: 0488 416 888	51	Kale Stanton Ph: 0401 855 381
50	2M45				1400-1425	Ballast Train 1	Locomotive - Ballast Train - Locomotive	180km	Medway	UP Main	Travel	Depart Tallong on UP Main travel to Medway Medway, Cross to DOWN MAIN via 51 pts Train PUSH/PULL	Pilot day shift 0600-1800 Ken Mills 0427 771 579	52	Steve Twyford 0419 465 552
51					1430-1600	RSA 093XD (HSP1) Tampers	09-3XD Tamper & Ballast Regulator	Cunningar	Yass	Up Main	Travel	Travel Tampers at Up Main to Yass Yard to Stable	Anthony Andrew Ph: 0488 416 888	59	Kale Stanton Ph: 0401 855 381
52					1425-1445	Ballast Train 1	Locomotive - Ballast Train - Locomotive	Medway	Lynwood	DOWN Main	Travel		Pilot day shift 0600-1800 Ken Mills 0427 771 579	53	Steve Twyford 0419 465 552
53					1445-1500	Ballast Train 1	Locomotive - Ballast Train - Locomotive	Marulan	Towrang	DOWN Main	Travel		Pilot day shift 0600-1800 Ken Mills 0427 771 579	54	Steve Twyford 0419 465 552
54					1500-1530	Ballast Train 1	Locomotive - Ballast Train - Locomotive	Medway	Goulburn	DOWN Main	Travel	Enter Goulburn SOUTH Yard via 133pts and STABLE	Pilot day shift 0600-1800 Ken Mills 0427 771 579	END	Steve Twyford 0419 465 552
55					1500-1530	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Wingello	Tallong	Down Main to Up Main	Travel & Transfer	Transfer Tampers from Down Main to Up Main at 177.030km-2C Pts and Travel at Up Main to Resurfacing Location at 183.870km	Rob May Ph: 0428 641 708	58	Shane Robbins Ph: 0400 067 171
56					1500-1600	Brimble Rail PL Unimat Tampers	Unimat Tamper & Ballast Regulator	Cullerin	Goulburn	Down Main	Travel	Tampers Travel to Goulburn Yard to Stable	Sione Vunga Ph: 0423 330 279	62	Mark Tuxford Ph: 0476 047 157
57					1500-1600	Martinus Rail PL Pandrol Jackson Tampers	Pandrol Jackson Tamper & Ballast Regulator	Exeter	Wingello	Down Main to Up Main	Travel & Transfer	Tampers Travel at Down Main to 176.853km-4D Pts, Transfer from Down Main to Up Main and Stable at Wingello Yard-Up Goods Siding	David Trajcevski Ph: 0410 530 775	61	Kurt Beatty Ph: 0437 844 266
58					1530-1630	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Tallong	Tallong	Up Main	Tamping	Tamp Up Main: 183.870-183.079km	Rob May Ph: 0428 641 708	63	Shane Robbins Ph: 0400 067 171
59					1600	RSA 093XD (HSP1) Tampers	09-3XD Tamper & Ballast Regulator	Yass	Yass	Siding	Stable	Stable Tampers at Yass Yard by 1600 hours	Anthony Andrew Ph: 0488 416 888	END	Kale Stanton Ph: 0401 855 381
60	D240	D241	1615		1615-1655	AMPR Test Train 1	Light Locomotive	Yass	Jerrawa	UP Main	Travel	Carryout Track Circuit Testing 309-307.	Nick Moutos 0424 237 147	64	Adrian Unwin 0419 634 639
61					1615	Martinus Rail PL Pandrol Jackson Tampers	Pandrol Jackson Tamper & Ballast Regulator	Wingello	Wingello	Siding	Stable	Stable Tampers at Wingello Yard-Up Goods Siding	David Trajcevski Ph: 0410 530 775	END	Kurt Beatty Ph: 0437 844 266
62					1615	Brimble Rail PL Unimat Tampers	Unimat Tamper & Ballast Regulator	Goulburn	Goulburn	Siding	Stable	Tampers stable at Goulburn Yard by 1615 hours	Sione Vunga Ph: 0423 330 279	END	Mark Tuxford Ph: 0476 047 157
63					1630-1645	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Tallong	Marulan	Up Main	Travel & Stable	Travel Tampers at Up Main to Marulan to stable at Marulan Yard-Down Goods Siding	Rob May Ph: 0428 641 708	65	Shane Robbins Ph: 0400 067 171

NOTE: Competent worker/s are to be arranged for work train and track machine movements, including Propelling and Piloting of trains when entering, exiting and within the possession limits.

NOTE: No equipment or infrastructure should be booked out (IBA) or left inoperable that would interfere with the operation of the CTM without approval prior to the possession.

MOVEMENT No:	Run Number	Forms Run Number	TIMES			Work Train/Track Machine Name	Work Train/Track Machine Consist	Movement			Worksite	Instructions	Traffic Officer/Pilot (Phone Number)	FORMS MOVEMENT No.	Supervisor / ARTC Site Rep (Phone Number)
			ENTER POSSESSION BOUNDARY	EXIT POSSESSION BOUNDARY	WORKSITE TIME			From	To	Track					
64	D241			1655	1655-1725	AMPR Test Train 1	Light Locomotive	Jerrawa	Yass	UP Main	Travel	Travel to Yass STABLE in Yard	Nick Moutos 0424 237 147	END	Adrian Unwin 0419 634 639
65					1700	ARTC 09-3XD Tampers	09-3XD Tamper & Ballast Regulator	Marulan	Marulan	Siding	Stable	Stable Tampers at Marulan Yard-Down Goods Siding by 1700 hours	Rob May Ph: 0428 641 708	END	Shane Robbins Ph: 0400 067 171