



**Manual**

# **Train Operating Conditions (TOC) Manual – Division Pages**

Version 21.0

Issue date: 11 May 2021

## Important message

This document is one of a set of standards developed solely and specifically for use on Transport Assets (as defined in the Asset Standards Authority Charter). It is not suitable for any other purpose.

The copyright and any other intellectual property in this document will at all times remain the property of the State of New South Wales (Transport for NSW).

You must not use or adapt this document or rely upon it in any way unless you are providing products or services to a NSW Government agency and that agency has expressly authorised you in writing to do so. If this document forms part of a contract with, or is a condition of approval by a NSW Government agency, use of the document is subject to the terms of the contract or approval. To be clear, the content of this document is not licensed under any Creative Commons Licence.

This document may contain third party material. The inclusion of third party material is for illustrative purposes only and does not represent an endorsement by NSW Government of any third party product or service.

If you use this document or rely upon it without authorisation under these terms, the State of New South Wales (including Transport for NSW) and its personnel does not accept any liability to you or any other person for any loss, damage, costs and expenses that you or anyone else may suffer or incur from your use and reliance on the content contained in this document. Users should exercise their own skill and care in the use of the document.

This document may not be current and is uncontrolled when printed or downloaded. Standards may be accessed from the Transport for NSW website at [www.transport.nsw.gov.au](http://www.transport.nsw.gov.au)

For queries regarding this document, please email the ASA at [standards@transport.nsw.gov.au](mailto:standards@transport.nsw.gov.au) or visit [www.transport.nsw.gov.au](http://www.transport.nsw.gov.au)

## Standard governance

**Owner:** Director Fleet Engineering, Asset Management Branch  
**Authoriser:** Director Engineering, Asset Management Branch  
**Approver:** Executive Director, Asset Management Branch on behalf of the AMB Configuration Control Board

## Document history

Version	Summary of changes
1.0	First issue (December 2013)
2.0	Second issue (December 2014)
3.0	Third issue (April 2015)
4.0	Fourth issue (August 2015)
5.0	Fifth issue (December 2015)
6.0	Sixth issue (April 2016)
7.0	Seventh issue (August 2016)
8.0	Eighth issue (December 2016)
9.0	Ninth issue (April 2017)
10.0	Tenth issue (August 2017)
11.0	Eleventh issue (December 2017)
12.0	Twelfth issue (April 2018)
13.0	Thirteenth issue (August 2018)
14.0	Fourteenth issue (December 2018)
15.0	Fifteenth issue (April 2019)
16.0	Sixteenth issue (August 2019)
17.0	Seventeenth issue (December 2019)
18.0	Eighteenth issue (April 2020)
19.0	Nineteenth issue (August 2020)
20.0	Twentieth issue (December 2020)
21.0	Current issue (April 2021)

## Preface

The Asset Management Branch (AMB), formerly known as Asset Standards Authority (ASA) is a key strategic branch of Transport for NSW (TfNSW). As the network design and standards authority for NSW Transport Assets, as specified in the *ASA Charter*, the ASA identifies, selects, develops, publishes, maintains and controls a suite of requirements documents on behalf of TfNSW, the asset owner.

The ASA deploys TfNSW requirements for asset and safety assurance by creating and managing TfNSW's governance models, documents and processes. To achieve this, the ASA focuses on four primary tasks:

- publishing and managing TfNSW's process and requirements documents including TfNSW plans, standards, manuals and guides
- deploying TfNSW's Authorised Engineering Organisation (AEO) framework
- continuously improving TfNSW's Asset Management Framework
- collaborating with the Transport cluster and industry through open engagement

The AEO framework authorises engineering organisations to supply and provide asset related products and services to TfNSW. It works to assure the safety, quality and fitness for purpose of those products and services over the asset's whole-of-life. AEOs are expected to demonstrate how they have applied the requirements of ASA documents, including TfNSW plans, standards and guides, when delivering assets and related services for TfNSW.

Compliance with ASA requirements by itself is not sufficient to ensure satisfactory outcomes for NSW Transport Assets. The ASA expects that professional judgement be used by competent personnel when using ASA requirements to produce those outcomes.

## About this document

This Train Operating Conditions (TOC) Manual is published by the ASA to provide an update from the December 2020 issue of the TOC Manual.

This TOC Manual aims to provide a single reference and technical guidance for train operations on the TfNSW Metropolitan Heavy Rail network.

The content, information, and data within this TOC Manual are derived from updates since the last edition of 23 December 2020. The information is compiled from a number of sources. The ASA performs limited validation of this information as it is deemed to be sourced from competent organisations.

This April 2021 issue of the TOC Manual comprises three parts as follows:

- TS TOC.1: 2021 issue 1
- TS TOC.2: 2021 issue 1; this document

- TS TOC.3: 2021 issue 1

As the ASA continues to evolve, future iterations of the TOC Manual and the information contained within it may be made available in different formats and delivery mechanisms to facilitate ease of access and usability.

## Table of contents

<b>Introduction .....</b>	<b>9</b>
<b>Purpose.....</b>	<b>9</b>
Scope.....	9
Application .....	10
<b>Reference documents .....</b>	<b>10</b>
<b>Terms and definitions .....</b>	<b>10</b>
<b>Summary of changes .....</b>	<b>10</b>
<b>Page layout.....</b>	<b>12</b>
<b>13. Northern Division pages .....</b>	<b>20</b>
Maximum speed of locomotives and rolling stock .....	20
General - Sectional running times and full sectional loads.....	21
DOWN loads.....	22
DOWN – sectional running times and full sectional loads.....	24
UP loads .....	25
UP – sectional running times and full sectional loads .....	26
Location of speed signs .....	27
Station data.....	30
Advisory speed signs.....	31
Tonnage signals .....	31
Transfer of Heavy Coal locomotives Woodville Junction – Enfield/Chullora and return for wheel lathe attention or maintenance .....	32
Conditions for the operation of self-propelled diesel trains .....	33
<b>14. Western Division pages .....</b>	<b>36</b>
Maximum speed of locomotives and rolling stock .....	36
General - Sectional running times and full sectional loads.....	37
DOWN loads.....	38
DOWN – sectional running times and full sectional loads.....	39
UP loads .....	40
UP – sectional running times and full sectional loads .....	41
Location of speed signs .....	42
Station data.....	44
Tonnage signals .....	44
Freight train braking requirements.....	45
Conditions for the operation of self-propelled diesel trains .....	46
<b>15. Illawarra Division pages.....</b>	<b>48</b>
Maximum speed of locomotives and rolling stock .....	49
General - Sectional running times and full sectional loads.....	50
DOWN loads.....	51
DOWN – sectional running times and full sectional loads.....	52
UP loads .....	53
UP – sectional running times and full sectional loads .....	54

Wollongong local area – loads .....	55
Location of speed signs .....	56
Station data .....	60
Emergency working or diversion of container trains Tempe – Unanderra (en route to and from Moss Vale) .....	61
Loads and conditions between Unanderra and 91.080 km (Unanderra – Moss Vale line) .....	61
DOWN loads .....	61
DOWN - sectional running times and full sectional loads .....	62
UP loads .....	62
UP - sectional running times and full sectional loads .....	62
UP – 91.080 km to Unanderra – Explanatory notes .....	63
Conditions of operation of freight trains - Unanderra and 91.080 km (en route to and from Moss Vale) .....	64
Operation of single pipe trains in excess of 2400 tonnes and up to 1500 metres long from Summit Tank to Unanderra .....	64
Conditions for the operation of self-propelled diesel trains - Unanderra and 91.080 km (en route to and from Moss Vale) .....	66
<b>16. Sydney Metropolitan Area pages .....</b>	<b>68</b>
Maximum speed of locomotives and rolling stock - Sydney Metropolitan Area .....	68
Sydney Metropolitan Area - sectional freight loads .....	71
Sydney Metropolitan Area - freight and locomotive running times .....	72
Hours of signal boxes .....	73
Dangerous goods in the Sydney Underground .....	73
Tonnage signals .....	74
Bondi Junction – trains / vehicles less than 4 cars using diamond crossover .....	74
East Hills Line – operation of freight vehicles with axle loads greater than 18 tonnes .....	74
Cronulla Line – operation of 81, 82, BL, C, G, GL, RL, and VL locomotives .....	76
General - Sectional running times and full sectional loads .....	77
Main South – DOWN loads .....	78
Main South – DOWN sectional running times and full sectional loads .....	79
Main South – UP loads .....	80
Main South – UP sectional running times and full sectional loads .....	81
Location of speed signs .....	82
Sydney Metropolitan Area – Division page references .....	83
<b>17. Passenger train operating conditions .....</b>	<b>95</b>
Introduction .....	95
Sydney Trains and NSW TrainLink .....	95
Sydney Metropolitan area - operation of wide gauge rolling stock .....	100
Specific localities .....	100
1 - City Circle .....	100
7 - Strathfield to Newcastle Interchange .....	100
10 - Erskineville to Bondi Junction .....	101
12 - Central to Wollie Creek (Airport Line) .....	102
14 - Metropolitan freight lines .....	102
Passenger train loads and running times .....	102
Western locomotive hauled loads – Up and Down Loads .....	103

Western locomotive hauled running times.....	103
<b>18. Coal train working .....</b>	<b>105</b>
General - Sectional running times and full sectional loads.....	105
North coal train loads and running times .....	105
Western coal train loads and running times .....	109
Illawarra coal train loads and running times .....	110

## Introduction

This document contains the Division pages of the Train Operating Conditions (TOC) Manual, which shall be read in conjunction with the relevant standard working timetables for the purpose of safe train operations and is applicable to all freight, passenger, and infrastructure maintenance operations on the TfNSW Metropolitan Heavy Rail network.

The April 2021 issue of the TOC Manual comprises three parts:

- TS TOC.1: 2021 issue 1 *Train Operating Conditions (TOC) Manual – General Instructions*
- TS TOC.2: 2021 issue 1 *Train Operating Conditions (TOC) Manual – Division Pages*; this document
- TS TOC.3: 2021 issue 1 *Train Operating Conditions (TOC) Manual – Track Diagrams*

This document, TS TOC.2: 2021 issue 1, *Train Operating Conditions (TOC) Manual – Division Pages*, contains the following:

- Northern Division Pages
- Western Division Pages
- Illawarra Division Pages
- Sydney Metropolitan Area Division Pages
- Passenger Train Operating Condition Pages
- Coal Working Pages

TS TOC.1: 2021 issue 1, *Train Operating Conditions (TOC) Manual – General Instructions*, contains the following:

- General Instruction Pages

TS TOC.3: 2021 issue 1, *Train Operating Conditions (TOC) Manual – Track Diagrams* contains the following:

- Track Diagrams

## Purpose

The TOC Manual specifies conditions for the operation of trains and rolling stock on the TfNSW Metropolitan Heavy Rail network.

## Scope

The TOC Manual describes the network, defines operating conditions for trains and rolling stock, and lists all rolling stock authorised to operate on the TfNSW Metropolitan Heavy Rail network.

The TfNSW Metropolitan Heavy Rail network is bounded by Newcastle Interchange (165.746km), Woodville Junction (163.981 km and 164.045 km), Bomaderry (153.630 km), Unanderra (91.080 km), Macarthur (57.965 km), and Bowenfels (158.800 km) but does not include the South Sydney Freight Line and Metropolitan Freight Network (bound by Marrickville 6.370 km, Flemington South Junction 18.909 km, and Sefton Park East Junction 21.285 km).

In addition Light Rail Networks and Metro Networks are not included in the TfNSW Metropolitan Heavy Rail network.

## Application

The TOC Manual is to be used by train planners, train timetablers, train control personnel, and train crews, and shall be read in conjunction with the relevant Safeworking rules and procedures.

## Reference documents

### Transport Standards

*Available from the Asset Standards Authority web site; [www.transport.nsw.gov.au](http://www.transport.nsw.gov.au).*

- TS TOC.1: 2021 issue 1 *Train Operating Conditions (TOC) Manual – General Instructions*
- TS TOC.3: 2021 issue 1 *Train Operating Conditions (TOC) Manual – Track Diagrams*

See TS TOC.1: 2021 issue 1 for further reference documents.

## Terms and definitions

See TS TOC.1: 2021 issue 1 *Train Operating Conditions (TOC) Manual – General Instructions*.

## Summary of changes

Table 1 provides a summary of changes to the content of this section of the manual since its previous publication. Changes to front matter, formatting, branding, and governance are not included.

**Table 1 - Summary of changes from December 2020 ASA reprint**

Area of manual	Page	Section	Change
13. Northern Division pages	22	DOWN loads	Amended loads per TW 204-471
13. Northern Division pages	24	DOWN – sectional running times and full sectional loads	Updated section running times based on Rail Geography 5.14
13. Northern Division pages	26	UP – sectional running times and full sectional loads	Updated section running times based on Rail Geography 5.14

<b>Area of manual</b>	<b>Page</b>	<b>Section</b>	<b>Change</b>
14. Western Division pages	36	Maximum speed of locomotives and rolling stock	Amended Safeworking to include Axle Counters at Mt Victoria
14. Western Division pages	39	DOWN – sectional running times and full sectional loads	Updated section running times based on Rail Geography 5.14
14. Western Division pages	41	UP – sectional running times and full sectional loads	Updated section running times based on Rail Geography 5.14
15. Illawarra Division pages	49	Maximum speed of locomotives and rolling stock	Amended Safeworking to include Axle Counters at Bomaderry to Berry.
15. Illawarra Division pages	52	DOWN – sectional running times and full sectional loads	Updated section running times based on Rail Geography 5.14
15. Illawarra Division pages	54	UP – sectional running times and full sectional loads	Updated section running times based on Rail Geography 5.14
16. Sydney Metropolitan Area pages	82	Location of speed signs	2e per WN4-21 and WN10/11-21, 6a per WN1/2-21, 8c per WN13-21
16. Sydney Metropolitan Area pages	79	Main South – DOWN sectional running times and full sectional loads	Updated section running times based on Rail Geography 5.14
16. Sydney Metropolitan Area pages	81	Main South – UP sectional running times and full sectional loads	Updated section running times based on Rail Geography 5.14
17. Passenger train operating conditions	97	Maximum speed of Sydney Trains and NSW TrainLink rolling stock	Updated as per TW 203-1025
17. Passenger train operating conditions	103	Western locomotive hauled running times	Updated section running times based on Rail Geography 5.14
18. Coal train working	105	North coal train loads and running times	Updated section running times based on Rail Geography 5.14
18. Coal train working	109	Western coal train loads and running times	Updated section running times based on Rail Geography 5.14
18. Coal train working	110	Illawarra coal train loads and running times	Updated section running times based on Rail Geography 5.14

## Page layout

### Format of division pages

Version December 2016

## FORMAT OF DIVISION PAGES

### MAXIMUM SPEED OF LOCOMOTIVE AND ROLLING STOCK

**ITEM 1** → 14. Western Division pages

Version December 2014

#### Maximum speed of locomotives and rolling stock

**ITEM 2**  
Classification of tracks

**ITEM 3**  
Maximum speed of locomotives

**ITEM 4**  
Multiple locomotive working

**ITEM 5**  
Classification of freight vehicles


**ITEM 6**  
Classification of passenger vehicles

**ITEM 7**  
Safeworking systems

Class of Line	Pennith – Lithgow	Lithgow – Valley Heights	Valley Heights – Pennith
Line Map Reference	DOWN MAIN	UP MAIN	UP MAIN
Class A	1	1	1
Line Map Reference	A	B	C

#### LOCOMOTIVES

Class	Max Speed km/h		
90, T1	N/A	N/A	N/A
31, L, LQ, LZ	100	100	100
32, 93, 8000, 8020, ACC, C, CEY, CF, GWA, GWU, LDP10, RL, SCT, TT100, WH, XRN	115	115	115
32, CLP, GL NR	115	115	115
14, 31, ALF, AN, BL, CLF, G, VL	115	115	115
42, 80, 80a, B, DL	115	115	115
18	90	90	90
442, 442a, 700, GM(12), S, X	115	115	115
22, 421, 422, 44, 45, 45a, 600, DC, EL, FL, GM(1), HL	115	115	115
43, 44b, 930	115	115	115
423	80	80	80
D, K, T	100	100	100
47, 48, 48200, 48b, 49, 830, 900, GPU, MM, PL	100	100	100
73 (e)	70	70	70
48, 88 Electric	100(b)	100(b)	100(b)
Multiple Locomotive working	4	5	4
<b>FREIGHT</b>			
Class A	115	115	115
Class B	100	100	100
Class C	80	80	80
Class D	65	65	65
Class E	80	80	80
Class F	65	65	65
Class G	N/A	N/A	N/A
<b>PASSENGER</b>			
XPT	160	160	160
XPLOREK	145	145	145
DIESEL RAILCARS	115	115	115
LOCO HAULED	115	115	115
	(a)		
<b>NOTES</b>			
(a)	See instructions contained in General Instructions for operation of trains and light locomotives over the section Katoomba to Valley Heights.		
(b)	Applies to SINGLE and distributed locomotives (separated by at least 70 metres of train). No OHW restrictions apply. Both pantographs may be raised.		
(c)	Only locomotives fitted with vigilance control system are approved to operate outside shunting yards.		
<b>SAFECWORKING SYSTEMS</b>			
Pennith – Edgecombe	# Rail Vehicle Detection		
Edgecombe – Zig Zag	Rail Vehicle Detection (Bi-directional)		
Zig Zag – Lithgow Coal Stage Signal Box	Rail Vehicle Detection		
Lithgow Coal Stage Signal Box – Lithgow Yard	Rail Vehicle Detection		
Signal Box	# Valley Heights to Springwood – Two way running Down Main		



**ITEM 8**  
LINE MAP

— Double track  
— Single track

Subsection break

Signal Box/  
Control centre

Crossing loop length

**ITEM 9**  
Private siding

## Format of division pages – explanation

April 2015

Table 2 explains the format of the division pages.


**Table 2 - Format of division pages – explanation**

Item	Label	Description
Item 1	Divisions	The Train Operating Conditional Manual comprises the Western, Northern, Illawarra, and Metropolitan Divisions. Each division provides the condition for operation of locomotives and rolling stock.
Item 2	Classification of track	The class of track will affect the speed and types of locomotives and rolling stock authorised to run over the various sections.
Item 3	Maximum speed of locomotives	Identifies locomotives and maximum speeds approved for that section of track. The letters N/A indicate these locomotives are not approved to run over this section of track.
Item 3	Operation of unlisted locomotives	Refer to the Asset Standards Authority for authorisation.
Item 4	Multiple locomotive working	The columns associated with locomotives headed “MULTIPLE LOCOS” shows the maximum number of locomotives powering that may run coupled together in a locomotive group on each relevant section of track. Up to a maximum of 5 locomotives total can be marshalled together in any locomotive group attached to a train. However, the number of locomotives that can be powering within each locomotive group at any given time is indicated in the multiple working section on the respective MAXIMUM SPEED OF LOCOMOTIVES AND ROLLING STOCK page.
Item 5	Classification of freight vehicles	Identifies freight vehicle class and maximum speeds approved for that section of track. The letters N/A indicate these vehicles are not approved to run over this section of track.
Item 5	Operation of unlisted freight vehicles	Refer to the Asset Standards Authority for authorisation.
Item 6	Classification of passenger vehicles	Identifies passenger vehicles and maximum speeds approved for that section of track. The letters N/A indicate these vehicles are not approved to run over this section of track.
Item 6	Classification of passenger vehicles	The grouping Diesel Railcars includes #self propelled diesel trains and Rail Motors. #Refer to Sydney Trains & NSW TrainLink pages for Endeavour/Hunter railcar approval.
Item 6	Operation of unlisted passenger rolling stock	Refer to the Asset Standards Authority for authorisation.
Item 7	Safeworking	This section indicates the safeworking system and the area controlled by that system. When words ‘Yard Working’ appear, the nominated section of track will be worked in accordance with the instructions contained in Sydney Trains Network Rule <i>NTR 418 Yard limits</i> .

Item	Label	Description
Item 8	Line map	See list page 12 for details.
Item 9	Private line/siding	<p>A Private (Non TfNSW owned) Line/Siding represented in the Division Pages (Line Map) by "P" is one that is not owned by TfNSW and therefore will not necessarily have operating conditions published in this Manual.</p> <p>Where this Manual contains information relating to the operating conditions for a private Line/siding, that information is published with the agreement or at the request of the owner/operator of that line/siding.</p> <p>For the purpose of train control, to and from a private Line/siding, the operator in securing a train path on the TfNSW Metropolitan Heavy Rail network has certified that there is an interface understanding/agreement between the operator and the owner/operator of the private Line/siding, which authorises the train/vehicles to operate within the confines of the private Line/siding.</p> <p>In providing an agreed train path in accordance with the operations protocol, Sydney Trains has certified that the operator's train will be accepted from or delivered to the boundary of the private Line/siding nominated in the operator's train path application.</p>

## Where can locomotives run?

April 2016



## Draw capacity tonnage and maximum length of trains / brake type

April 2015

### HOW TO DETERMINE DRAW CAPACITY TONNAGE

1. Check vehicle draw capacity in LOCOMOTIVE AND ROLLING STOCK DATA table.

Table 107—Manildra·Flour—Freight·rolling·stock

Code	Description	Class	Max·Gross Mass-(t)	Tare-(t)	Length (m)	Draw Capacity (MN)	Brake Type	Notes
MBAX	Covered wagon (Ex WBAX)	C	76 80	25	18.0	1.30	B3	R1
MHGX	Grain-hopper (Ex AHGX)	C	76	21	14.6	1.30	B2	
MQRF	Container flat (Ex AQRF)	C	76	21	14.9	1.30	B1	
MGFH	Grain-hopper	C	100	26.5	17.6	1.80	B4	1,2,3

### UP—sectional·running·times·and·full·sectional·loads

Version April 2015

#SECTIONAL-RUNNING-TIMES	FULL SECTIONAL LOADS														GRADE						
	%A1	C1	C2	C4	C5	Loco	AC6	2	3	4	5	6	7	8	9	10	11	12	13	14	
BOMADERRY																					
BERRY	12	13				11a	2766	2227	2104	1976	1743	1699	1650	1422	1372	1259	1175	820		1:80	
GERRINGONG	..	..				10	2623	2111	1995	1872	1651	1610	1563	1346	1299	191	1112	776		1:76	
KIAMA	21	23				9a	2477	1992	1882	1766	1557	1519	1473	1268	1224						1:70

DRAW-CAPACITY	GRADES 1::X																					
	MN	30	32	35	40	45	48	50	55	60	66	70	72	75	77	80	85	90	95	100	110	120
H 1.80	304	320	324	340	356	372	388	404	420	436	452	468	484	490	506	522	538	554	570	586	602	618
1.85	3489	3809	4019	4239	4459	4679	4899	5119	5339	5559	5779	5999	6219	6439	6659	6879	7099	7319	7539	7759	7979	8199
1.90	3583	3912	4128	4348	4568	4788	4998	5218	5438	5658	5878	6098	6318	6538	6758	6978	7198	7418	7638	7858	8078	8298

3. Find 1.80 in Trailing Tonnage table.

4. This figure 7196 tonnes indicates trailing tonnage permitted behind a MGFH over the section.

2. Cross reference Grade column with draw capacity column.

### MAXIMUM LENGTH OF TRAINS / BRAKE TYPE

1. The length of a train is the overall length of a train including all locomotives whether powering, off line, dead attached or banking.  
The train must also be covered by an access agreement between Sydney Trains and the Operator, which indicates the trains **maximum length, motive power and maximum speed**. The maximum length of trains also depends upon **draw capacity** (see HOW TO DETERMINE DRAW CAPACITY TONNAGE table) and the **brake equipment type** (see Step 2) that is fitted to the vehicles.

2. Reference must be made to the LOCOMOTIVE AND ROLLING STOCK DATA pages to determine the brake type (i.e. B1, B2, B3 or B4). If no brake type is listed then assume B1 type. When a train is being marshalled at its point of origin, remarshalled or has vehicles attached en route the brake type list must be checked to ensure limits are not exceeded.

Table 107—Manildra·Flour—Freight·rolling·stock

Code	Description	Class	Max·Gross Mass-(t)	Tare-(t)	Length (m)	Draw Capacity (MN)	Brake Type	Notes
MBAX	Covered wagon (Ex WBAX)	C	76 80	25	18.0	1.30	B3	R1
MHGX	Grain-hopper (Ex AHGX)	C	76	21	14.6	1.30	B2	
MQRF	Container flat (Ex AQRF)	C	76	21	14.9	1.30	B1	
MGFH	Grain-hopper	C	100	26.5	17.6	1.80	B4	1,2,3

3. Check this table to determine the allowable position of the vehicles in a train

Brake-type	Allowable vehicle position in train
B1	Any position in the first 900 metres of train
B2 & B3	Any position in the first 1500 metres of train
B4	Any position in train
E1	Any position in train (all locomotives and wagons ECP braked)

## Format of speed sign table

December 2018

FORMAT OF LOCATION OF SPEED SIGN TABLE														
														
<b>Section 11</b> Sydenham – Regents Park				<b>Section 12</b> Central – Wollie Creek (Airport Line)										
														
KILO-METRAGE	DOWN	UP	Nor-mal	XPT	Nor-mal	XPT								
5 170	738 Points	X25	..	..	..	..								
5 308	Sydenham	..	..	..	..	..								
5 411	..	15	..	..	..	..								
5 510	Up sign on Down Bankstown	..	..	..	..	..								
6 040	40	..	..	..	..	..								
6 575	Marrickville	..	40	..	..	..								
7 540	..	..	70	..	..	..								
7 750	60	..	..	..	..	..								
7 872	Dulwich Hill	..	..	..	..	..								
8 797	Hurlstone Park	..	..	..	..	..								
														
Kilometrage from Sydney		Station, siding or location		'Normal' speed signs apply to all trains except for XPT, Xplorer, Endeavour, Hunter, and OSC.										
<p>Speed signs indicate the maximum speed between signs.          'X' speeds (e.g. X40) indicate the maximum speed throughout turnouts. The maximum speed throughout the sharp curves of junctions, crossovers and turnouts is <b>25 kilometres per hour</b>, unless otherwise shown.</p>														
<p>XPT, Xplorer, Endeavour and Hunter trains run to XPT speed signs to the maximum speed specified under the listing of <b>MAXIMUM SPEED OF LOCOMOTIVES AND ROLLING STOCK</b>.          XPT, Xplorer, Endeavour, Hunter, and OSC trains run to 'Normal' speed signs where XPT signs are not provided.</p>														
<p>A white background speed sign with the letters MU alongside the numerals applies only to XPT, Xplorer, Endeavour trains, Hunter and Multiple unit trains (NSG604).</p>														
<p>'Wrong Road' speed signs shown in italics.</p>														
														
<b>Location of speed signs</b>														
Hornsby -- Hawkesbury River														
KILOMETRAGE	DOWN	UP	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH						
33.864	HORNSBY	..	..	..	..	..	..	..						
33.950	80	80	80	80	..	..	..	..						
33.950	X60	..	..	X65	..	..	..	..						
34.100	535 Pts	Down Sign on Up Sidings	..	..	520 Points	..	..	..						
														
Kilometrage from Sydney		Station, siding or location		'Wrong Road' speed signs shown in italics.			'General' speed signs apply to locomotive hauled passenger and freight trains, track maintenance vehicles, Rail Motors and 620 class diesel trains.							
<p>Speed signs indicate the maximum speed between signs.          'X' speeds (e.g. X40) indicate the maximum speed throughout turnouts. The maximum speed throughout the sharp curves of junctions, crossovers and turnouts is <b>25 kilometres per hour</b>, unless otherwise shown.</p>							'High' speed signs apply to XPT, Xplorer, Endeavour, Hunter, and OSC trains.							
<p>'Medium' speed signs apply to Sydney Trains electric multiple unit trains.</p>														
<p>December 2018</p>														

## Format of station data table and rolling stock data pages

August 2016

### FORMAT OF STATION DATA TABLE

#### Station-data

Version 10.0-December 2012

Station	Kilo-metres	Signal-Box-Status	Hours-of-Signal-Box	Facilities
Penrith	55.086	A	Always	P, WC
Emu-Plains	57.439		Controlled from Penrith	P
Lapstone	63.617			P

Station,  
siding or  
location

Kilometre  
from Sydney

Hours of signal boxes.  
controlled location  
information,siding  
information.

L = Location only  
LP = Local panel  
P = Platform  
PS = Private siding  
TT = Turntable  
WC = Water column

A = Always attended  
C = Controlled from (location)  
P = Partially attended signal box  
U = Unattended

### FORMAT OF ROLLING STOCK DATA PAGES

#### Pacific-National--Freight-rolling-stock--grain-hoppers

Table 124--Pacific-National--Freight-rolling-stock--grain-hoppers

Code	Description	Class	Max-Gross Mass-(t)	Tare-(t)	Length (m)	Draw Capacity (MN)	Brake-Type	Notes
NGDX	Grain	C	73	18.5	14.3	0.90	•□B3	
NGFF	Grain	C	76		14.6	0.75	B2	
NGGF	Grain	A	78		14.3	1.80	B3	
	When loaded from 78 up to a maximum of 81-tonnes gross mass Class E speeds will apply.		81					
NGHF	Grain	C	76	17.8	14.4	1.80	••B4	

Vehicle  
code

When the description  
indicates 'permanently  
coupled' or 'articulated  
units' the tonnage shown  
in the MAXIMUM GROSS  
MASS TONNES column  
will be the combined  
tonnage for all wagons.

Speed  
classification

Maximum vehicle or multi-  
vehicle gross mass  
permitted on Class 1 track  
for speed classification.  
When 'Empty' is shown in the 'MAX GROSS MASS  
TONNES' column the  
vehicles will operate to  
the maximum speed  
shown for the nominated  
classification i.e. NPHH  
operate to Class B  
speeds when empty.

Vehicle or multi-vehicle  
length over coupling  
faces.

Maximum draw/buff  
capacity of the vehicle  
in Meganewtons

• symbol indicates  
vehicle is fitted with two  
pipe brake system.  
All other vehicles are  
single pipe brake system.  
•□ symbol indicates  
vehicle is fitted with a  
main reservoir pipe but it  
does not feed the brake  
system.  
This vehicle type can be  
marshalled anywhere in a  
conventional two pipe  
train but it does not  
necessarily meet the  
same brake performance.

Superseded by TS TOC 2 v22.0, 24/09/2021

**Section 13**  
**Northern Division pages**

## 13. Northern Division pages

Version December 2020

### Maximum speed of locomotives and rolling stock

	Hornsby – Vales Point	Vales Pt – Woodville Junction	Woodville Junction – Newcastle Interchange	
Class of Line	1	1	1	
Line Map Reference	A	B	C	
<b>LOCOMOTIVES</b>				
Class		Max Speed Km/h		
90, TT(139t), TT100(139t), C44aci(139t)(g)	(a)	60(a,f)	20(c)	
31, L, LQ, LZ	100	100	20(c)	
1100, 92, 93, 6000, 6020, ACC, C, CEY, CF, CM, CSR, FIE, GWA, GWU, LDP, LDP10, MRL, PHC, QBX, RL, SCT, SSR, TT(134t) TT100 (134t), WH, XRN	115	115	20(c)	
82, CLP, GL, NR	115(b)	115	20(c)	
14, 81, ALF, AN, BL, CLF, G, VL	115	115	50	
42, 80, 80s, B, DL	115	115	50	
18	90	90	50	
442, 442s, 700, GM(12), S, X	115	115	50	
32	100	100	50	
1200, 22, 421, 422, 44, 45, 45s, 600, DC, EL, FL, GM(1), HL	115	115	50	
43, 44s, 930	115	115	50	
423	80	80	50	
D, K, T	100	100	50	
47, 48, 48200, 48s, 49, 830, 900, GPU, MM, PL	100	100	50	
73 (e)	70	70	50	
46, 86 Electric	100(d)	100(d)	50(d)	
59, 32(P) Steam	80	80	50	
Multiple locomotive working (powering locomotives horsepower limit per locomotive group)	5 (16000)	U (16000)	U (16000)	
<b>FREIGHT</b>				
Class A	115	115	50	
Class B	100	100	50	
Class C	80	80	50	
Class D	65	65	50	
Class E	80	80	50	
Class F	65	65	50	
Class G	N/A	60(f)	N/A	
<b>PASSENGER</b>				
XPT	160	160	80	
XPLOREER	145	145	80	
DIESEL RAILCARS	115	115	80	
LOCO HAULED	115	115	50	
<b>NOTES</b>				
U = Unlimited number of locomotives (subject to horsepower limit per locomotive group).				
(a) When operating light 90 class locomotives between Woodville Junction and Enfield/Chullora, see Special conditions Page 32 of this section.				
(b) NR locomotive maximum speed of 40 km/h through Boronia Tunnel No 3 (Down and Up) 54.300km to 54.500km.				
(c) Woodville Junction to Hamilton Junction <b>ONLY</b> .				
(d) Applies to SINGLE and distributed locomotives (separated by at least 70 metres of train). No OHW restrictions apply. Both pantographs may be raised.				
(e) Only locomotives fitted with vigilance control system are approved to operate outside shunting yards.				
(f) Maximum speed of 50 km/h (Down and Up) when traversing Dora Ck bridge at 127.025km .				
(g) C44aci(139t) locomotives provisioned between 134t and 139t include 92, 93, 6000, 6020, ACC, CEY, CF, FIE, GWU, MRL, XRN, PHC.				
<b>SAFeworking SYSTEMS</b>				
Hornsby – Cowan		Rail Vehicle Detection		
Cowan – Boronia		Rail Vehicle Detection (Bi-directional)		
Boronia – Hawkesbury River		Rail Vehicle Detection (Bi-directional)		
Hawkesbury River – Hamilton		Rail Vehicle Detection		

## General - Sectional running times and full sectional loads

Version April 2020

The locomotive-load-run times configurations (DOWN loads and UP loads) published in this section are for existing approved paths in the Standard Working Timetable (SWTT). For configurations that are not listed, the train shall run at the discretion of the train controller, based on the following:

- The trailing load does not exceed the sum of individual locomotive full sectional loads, accounting for load reductions specified in (TS TOC.1 Section 2.11 and 2.12)
- There is capacity on the network (based on the live status and the SWTT/DWTT) for the train controller to allocate additional times for the train if longer journey or sectional running times, or both are foreseen.
- The operator operates to the assigned schedule or under the direction of the train controller to ensure the train's arrival at critical junctions or destinations does not cause train control conflicts to the network.

The sectional running times published are based on RailNet Running Time Profiles (simulations). Train consists (locomotive and trailing loads) used in the simulations are based on the length limits in the train operating length diagram in TS TOC 1 (Section 1.11) with no speed restrictions applied.

Any planned and timetabled sectional running times used in ad hoc paths, Daily Working Timetable, and Standard Working Timetable have additional time added to the published running times (for example recovery time), which should be accounted for by the train controller / planner / programmer as appropriate.

## DOWN loads

Version April 2021

SECTIONS	LOCOMOTIVE CLASS = L	LOAD - TONNES				TRAIN DATA		
		SINGLE	DOUBLE	TRIPLE	QUAD	VEHICLE CLASS	SECT RUN TIMES	NOTES
1 SYDNEY METROP. – BROADMEADOW	L2	1000	2000	3000	4000	A	A1	
2 SYDNEY METROP. – BROADMEADOW	L7	735	1470	2205	2940	A	A1	
3 SYDNEY METROP. – BROADMEADOW	AC6	1000	2000	3000	--	A	A1	
4 SYDNEY METROP. – BROADMEADOW	AC6 + L2	--	2750	--	--	AB	B1	# C44ACi or GT46C ACe and NR
5 SYDNEY METROP. – BROADMEADOW	AC6 + L2	--	2410	--	--	AB	B1	# C44ACi or GT46C ACe and AN
6 SYDNEY METROP. – BROADMEADOW	AC6 + 2 x L2	--	--	4050	--	AB	B1	# C44ACi or GT46C ACe and NR
7 SYDNEY METROP. – BROADMEADOW	AC6 + 2 x L2	--	--	3530	--	AB	B1	# C44ACi or GT46C ACe and AN
8 SYDNEY METROP. – BROADMEADOW	2 x AC6 + L2	--	--	4200	--	AB	B1	# C44ACi or GT46C ACe and NR
9 SYDNEY METROP. – BROADMEADOW	2 x AC6 + L2	--	--	3700	--	AB	B1	# C44ACi or GT46C ACe and AN
10 SYDNEY METROP. – BROADMEADOW	L2	1300	2600	3900	5200	AB	B1	
11 SYDNEY METROP. – BROADMEADOW	L4	970	1940	2910	3880	AB	B1	
12 SYDNEY METROP. – BROADMEADOW	L7	909	1818	2727	3636	AB	B1	
13 SYDNEY METROP. – BROADMEADOW	AC6	1500	3000	4600*	--	AB	B1	*
14 SYDNEY METROP. – BROADMEADOW	L8+L8+L13	--	--	600	--	ABC	C	
15 SYDNEY METROP. – BROADMEADOW	L2	1300	2600	3900	5200	ABCE	C1	
16 SYDNEY METROP. – BROADMEADOW	L4	970	1940	2910	3880	ABCE	C1	
17 SYDNEY METROP. – BROADMEADOW	L7	909	1818	2727	3636	ABCE	C1	
18 SYDNEY METROP. – BROADMEADOW	L9	590	1180	1770	2360	ABCE	C1	
19 SYDNEY METROP. – BROADMEADOW	AC6	1500	3000	4600*	--	ABCE	C1	*
20 SYDNEY METROP. – BROADMEADOW	AC6 + L2	--	2750	--	--	ABCE	C1	# C44ACi or GT46C ACe and NR
21 SYDNEY METROP. – BROADMEADOW	AC6 + L2	--	2410	--	--	ABCE	C1	# C44ACi or GT46C ACe and AN
22 SYDNEY METROP. – BROADMEADOW	AC6 + 2 x L2	--	--	4050	--	ABCE	C1	# C44ACi or GT46C ACe and NR
23 SYDNEY METROP. – BROADMEADOW	AC6 + 2 x L2	--	--	3530	--	ABCE	C1	# C44ACi or GT46C ACe and AN
24 SYDNEY METROP. – BROADMEADOW	2 x AC6 + L2	--	--	4200	--	ABCE	C1	# C44ACi or GT46C ACe and NR
25 SYDNEY METROP. – BROADMEADOW	2 x AC6 + L2	--	--	3700	--	ABCE	C1	# C44ACi or GT46C ACe and AN
26 SYDNEY METROP. – BROADMEADOW	L3	1200	2400	3600	4800	ABCE	C2	
27 SYDNEY METROP. – BROADMEADOW	L4	1131	2262	3393	4524	ABCE	C2	
28 SYDNEY METROP. – BROADMEADOW	L5	1056	2112	3168	4224	ABCE	C2	
29 SYDNEY METROP. – BROADMEADOW	L6	926	1852	2778	3704	ABCE	C2	
30 SYDNEY METROP. – BROADMEADOW	L7	909	1818	2727	3636	ABCE	C2	
31 SYDNEY METROP. – BROADMEADOW	L8	875	1750	2625	3500	ABCE	C2	
32 SYDNEY METROP. – BROADMEADOW	L9	750	1500	2250	3000	ABCE	C2	
33 SYDNEY METROP. – BROADMEADOW	L10	725	1450	2175	2900	ABCE	C2	
34 SYDNEY METROP. – BROADMEADOW	L11	660	1320	1980	2640	ABCE	C2	
35 SYDNEY METROP. – BROADMEADOW	L12	615	1230	1845	2460	ABCE	C2	
36 SYDNEY METROP. – BROADMEADOW	L13	310	615	925	1230	ABCE	C2	
37 SYDNEY METROP. – BROADMEADOW	L4	1131	2262	3393	4524	ABCDE	D1	
38 SYDNEY METROP. – BROADMEADOW	L10	725	1450	2175	2900	ABCDE	D1	
39 SYDNEY METROP. – BROADMEADOW	L13	410	820	1230	1640	ABCDE	D1	
40 SYDNEY METROP. – BROADMEADOW	L3	1200	--	--	--	ABCDE	D1	

- # A full list of approved AC6 locomotives (United Group Ltd – C44ACi, Downer EDI Rail – GT46C-ACe, and CRRC Ziyang – SDA1) is summarised under Table 8 Approved locomotives grouped into load categories – locomotive type AC in TS TOC 1.
- \* Total trialling load limited to 4500t only if consist contains any SDA1 type AC locomotives.

## DOWN – sectional running times and full sectional loads

Version April 2021 (5.14)

#SECTIONAL RUNNING TIMES (INDICATIVE)	FULL SECTIONAL LOADS													GRADE						
	LOCOMOTIVE CATEGORIES = L																			
	A1	B1	C	C1	C2	%D1	Loco	AC6	2	3	4	5	6	7	8	9	10	11	12	13
MFN FLEMINGTON to:																				
FLEM GDS SOUTH JCT	01:06	01:06	01:06	01:06	01:06	8	01:24	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984
FLEM GDS MID JCT	01:36	01:36	01:36	01:36	01:36	1	01:18	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984
FLEM MKTS 625 PTS	01:24	01:24	01:24	01:24	01:24	5	01:12	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984
NTH STRATHFIELD JCT	04:06	04:06	04:06	04:06	04:06	5	03:54	2904	2536	2339	2211	2077	1833	1786	1736	1495	1442	1324	1236	862
CONCORD WEST	02:36	02:36	02:06	02:36	02:36	3	01:54	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600
RHODES	01:36	01:48	01:36	01:48	01:48	2	01:36	4102	3587	3314	3134	2949	2607	2535	2472	2133	2055	1892	1766	1232
WEST RYDE	02:18	02:18	02:18	02:18	02:24	2	02:12	2171	1892	1743	1646	1543	1359	1328	1285	1105	1068	977	912	636
EASTWOOD	02:48	03:30	02:18	03:24	04:00	--	02:18	1500	1300	1200	1131	1056	926	909	875	750	725	660	615	410
EPPING	02:54	03:36	02:06	03:30	04:12	11	02:12	1676	1458	1341	1265	1183	1040	1018	980	842	815	743	693	483
THORNLEIGH	08:24	10:06	05:54	10:12	11:54	16	05:42	1500	1300	1200	1131	1056	926	909	875	750	725	660	615	410
HORNSBY	04:12	04:36	03:36	04:30	04:48	6	04:18	1500	1300	1200	1131	1056	926	909	875	750	725	660	615	410
BEROWRA	10:06	11:00	09:18	11:00	11:12	16	08:12	1500	1300	1200	1131	1056	926	909	875	750	725	660	615	410
COWAN	04:12	04:18	04:18	04:18	04:12	4	04:30	2985	2607	2405	2274	2136	1885	1837	1785	1539	1484	1363	1272	887
BORONIA X/OVER	03:54	03:54	03:54	03:54	03:48	3	05:36	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600
HAWKESBURY RIVER	05:54	05:54	05:42	05:54	05:54	6	07:54	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600
WOY WOY	14:18	15:00	13:24	15:00	15:30	18	13:54	1500	1300	1200	1131	1056	926	909	875	750	725	660	615	410
GOSFORD	07:06	07:12	07:00	07:18	07:12	9	06:54	2326	2028	1869	1766	1656	1459	1425	1380	1188	1147	1051	980	684
WYONG	14:48	15:48	16:18	17:06	17:06	20	13:36	2477	2161	1992	1882	1766	1557	1519	1473	1268	1224	1122	1047	731
WYEE	08:54	10:06	10:30	11:12	11:06	15	08:18	2171	1892	1743	1646	1543	1359	1328	1285	1105	1068	977	912	636
VALES PT JCT	02:48	03:18	03:30	03:54	04:00	--	02:36	1846	1607	1479	1396	1307	1149	1125	1085	933	902	823	768	536
MORISSET	03:00	03:06	03:12	03:24	03:24	10	03:18	1846	1607	1479	1396	1307	1149	1125	1085	933	902	823	768	536
ERARING COLL JCT	08:30	09:18	08:00	09:54	10:36	--	07:00	1676	1458	1341	1265	1183	1040	1018	980	842	815	743	693	483
AWABA	04:30	04:48	03:54	04:48	05:06	20	04:48	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600
FASSIFERN	04:06	04:12	04:06	04:18	04:18	5	04:36	2171	1892	1743	1646	1543	1359	1328	1285	1105	1068	977	912	636
NEWSTAN COLL JCT	00:18	00:18	00:18	00:18	00:18	--	00:36	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600
TERALBA COLL JCT	06:42	06:48	06:30	06:54	06:54	--	07:24	1500	1300	1200	1131	1056	926	909	875	750	725	660	615	410
SULPHIDE JCT	02:42	02:48	02:36	02:48	02:36	14	02:36	2623	2289	2111	1995	1872	1651	1610	1563	1346	1299	1191	1112	776
ADAMSTOWN	08:00	08:42	07:18	08:48	09:12	13	08:18	2766	2414	2227	2104	1976	1743	1699	1650	1422	1372	1259	1175	820
BROADMEADOW YD	01:18	01:18	01:18	01:18	01:18	--	01:30	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600
BROADMEADOW	00:36	00:36	00:42	00:42	00:36	3	00:42	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600
WOODVILLE JCT	00:42	00:42	00:36	00:36	00:36	4	00:36	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600
ISLINGTON JCT	01:18	01:18	01:18	01:18	01:12	2	01:06	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600

# For other Sydney Metropolitan area running times, refer to diagram in the 'Sydney Metropolitan Division Pages' Sydney Metropolitan Area – freight and locomotive running times (page 72).

% D schedules do not form part of the Standard Working Timetable. It is used for special train path planning

## UP loads

Version December 2020

SECTIONS	LOCOMOTIVE CLASS = L	LOAD - TONNES				TRAIN DATA		
		SINGLE	DOUBLE	TRIPLE	QUAD	VEHICLE CLASS	SECT RUN TIMES	NOTES
1 BROADMEADOW – SYDNEY METROP.	L2	1000	2000	3000	4000	A	A1	
2 BROADMEADOW – SYDNEY METROP.	L7	735	1470	2205	2940	A	A1	
3 BROADMEADOW – SYDNEY METROP.	AC6	1000	2000	3000	--	A	A1	
4 BROADMEADOW – SYDNEY METROP.	L2	1230	2460	3690	4920	AB	B1	
5 BROADMEADOW – SYDNEY METROP.	L4	970	1940	2910	3880	AB	B1	
6 BROADMEADOW – SYDNEY METROP.	L7	909	1818	2727	3636	AB	B1	
7 BROADMEADOW – SYDNEY METROP.	AC6	1500	3000	4600*	--	AB	B1	*
8 BROADMEADOW – SYDNEY METROP.	AC6 + L2	--	2500	--	--	AB	B1	# C44ACi and NR only
9 BROADMEADOW – SYDNEY METROP.	AC6 + L2	--	2350	--	--	AB	B1	b
10 BROADMEADOW – SYDNEY METROP.	AC6 + 2 x L2	--	--	3650	--	AB	B1	# C44ACi and NR only
11 BROADMEADOW – SYDNEY METROP.	AC6 + 2 x L2	--	--	3408	--	AB	B1	b
12 BROADMEADOW – SYDNEY METROP.	2 x AC6 + L2	--	--	3850	--	AB	B1	# C44ACi and NR only
13 BROADMEADOW – SYDNEY METROP.	2 x AC6 + L2	--	--	3641	--	AB	B1	b
14 BROADMEADOW – SYDNEY METROP.	L2	1230	2460	3690	4920	ABCE	C1	
15 BROADMEADOW – SYDNEY METROP.	L4	970	1940	2910	3880	ABCE	C1	
16 BROADMEADOW – SYDNEY METROP.	L7	909	1818	2727	3636	ABCE	C1	
17 BROADMEADOW – SYDNEY METROP.	L9	590	1180	1770	2360	ABCE	C1	
18 BROADMEADOW – SYDNEY METROP.	AC6	1500	3000	4600*	--	ABCE	C1	*
19 BROADMEADOW – SYDNEY METROP.	AC6 + L2	--	2500	--	--	ABCE	C1	#C44ACi and NR only
20 BROADMEADOW – SYDNEY METROP.	AC6 + L2	--	2350	--	--	ABCE	C1	b
21 BROADMEADOW – SYDNEY METROP.	AC6 + 2 x L2	--	--	3650	--	ABCE	C1	#C44ACi and NR only
22 BROADMEADOW – SYDNEY METROP.	AC6 + 2 x L2	--	--	3408	--	ABCE	C1	b
23 BROADMEADOW – SYDNEY METROP.	2 x AC6 + L2	--	--	3850	--	ABCE	C1	#C44ACi and NR only
24 BROADMEADOW – SYDNEY METROP.	2 x AC6 + L2	--	--	3641	--	ABCE	C1	b
25 BROADMEADOW – SYDNEY METROP.	L3	1200	2400	3600	4800	ABCE	C2	
26 BROADMEADOW – SYDNEY METROP.	L4	1131	2262	3393	4524	ABCE	C2	
27 BROADMEADOW – SYDNEY METROP.	L5	1056	2112	3168	4224	ABCE	C2	
28 BROADMEADOW – SYDNEY METROP.	L6	926	1852	2778	3704	ABCE	C2	
29 BROADMEADOW – SYDNEY METROP.	L7	909	1818	2727	3636	ABCE	C2	
30 BROADMEADOW – SYDNEY METROP.	L8	875	1750	2625	3500	ABCE	C2	
31 BROADMEADOW – SYDNEY METROP.	L9	750	1500	2250	3000	ABCE	C2	
32 BROADMEADOW – SYDNEY METROP.	L10	725	1450	2175	2900	ABCE	C2	
33 BROADMEADOW – SYDNEY METROP.	L11	660	1320	1980	2640	ABCE	C2	
34 BROADMEADOW – SYDNEY METROP.	L12	615	1230	1845	2460	ABCE	C2	
35 BROADMEADOW – SYDNEY METROP.	L13	310	615	925	1230	ABCE	C2	
36 BROADMEADOW – SYDNEY METROP.	L4	1131	2262	3393	4524	ABCDE	D1	
37 BROADMEADOW – SYDNEY METROP.	L10	725	1450	2175	2900	ABCDE	D1	
38 BROADMEADOW – SYDNEY METROP.	L13	410	820	1230	1640	ABCDE	D1	

# A full list of approved AC6 locomotives (United Group Ltd – C44ACi, Downer EDI Rail – GT46C-ACe, and CRRC Ziyang – SDA1) is summarised under Table 8 Approved locomotives grouped into load categories – locomotive type AC in TS TOC 1.

\* Total trailing load limited to 4500t only if consist contains SDA1 type AC locomotives.

b The AC6 locomotive shall be a C44ACi or GT46C-ACe locomotive and the L2 locomotive can be NR or AN class.

## UP – sectional running times and full sectional loads

Version April 2021 (5.14)

#SECTIONAL RUNNING TIMES (INDICATIVE)	FULL SECTIONAL LOADS															GRADE				
	LOCOMOTIVE CATEGORIES = L																			
	A1	B1	C1	C2	*D1	Loco	AC6	2	3	4	5	6	7	8	9	10	11	12	13	
ISLINGTON JCT to:	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
WOODVILLE JCT	02:06	02:00	02:00	02:06	3	01:18	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	Level
BROADMEADOW	01:18	01:18	01:18	01:18	4	00:30	5057	4426	4090	3869	3645	3223	3132	3060	2641	2542	2344	2188	1527	1:185
BROADMEADOW YD	01:48	01:54	01:54	02:00	--	01:00	5057	4426	4090	3869	3645	3223	3132	3060	2641	2542	2344	2188	1527	1:185
ADAMSTOWN	00:30	00:36	00:36	00:36	3	00:24	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	Level
SULPHIDE JCT	07:06	07:48	07:48	08:24	11	07:06	2477	2161	1992	1882	1766	1557	1519	1473	1268	1224	1122	1047	731	1:70
TERALBA COLL JCT	02:24	02:24	02:24	02:30	--	02:54	4407	3855	3562	3369	3171	2803	2726	2660	2295	2210	2036	1900	1326	1:150
NEWSTAN COLL JCT	06:36	06:54	06:54	07:00	--	07:00	2477	2161	1992	1882	1766	1557	1519	1473	1268	1224	1122	1047	731	1:69
FASSIFERN	00:30	00:30	00:30	00:30	13	00:30	2357	2080	1894	1789	1678	1479	1444	1399	1204	1163	1065	994	693	1:66
AWABA	04:06	04:12	04:24	04:18	6	03:48	2357	2080	1894	1789	1678	1479	1444	1399	1204	1163	1065	994	693	1:66
ERARING COLL JCT	04:30	05:00	05:00	05:24	--	03:54	2477	2161	1992	1882	1766	1557	1519	1473	1268	1224	1122	1047	731	1:72
MORISSET	07:54	08:18	08:36	08:54	20	07:48	2477	2161	1992	1882	1766	1557	1519	1473	1268	1224	1122	1047	731	1:71
VALES PT JCT	03:06	03:12	03:24	03:30	--	02:30	2623	2289	2111	1995	1872	1651	1610	1563	1346	1299	1191	1112	776	1:74
WYEE	03:18	03:30	03:54	03:54	10	03:06	2623	2289	2111	1995	1872	1650	1610	1563	1345	1300	1191	1110	775	1:73
WYONG	08:42	09:30	11:36	11:30	16	09:18	2477	2161	1992	1882	1766	1557	1519	1473	1268	1224	1122	1047	731	1:72
GOSFORD	14:42	15:30	16:18	16:12	20	13:18	2623	2289	2111	1995	1872	1651	1610	1563	1346	1299	1191	1112	776	1:75
WOY WOY	07:24	07:36	07:42	07:42	9	07:06	3039	2654	2449	2315	2175	1920	1870	1818	1567	1511	1388	1295	904	1:90
HAWKESBURY RIVER	13:54	14:24	14:12	14:18	18	13:30	2171	1892	1743	1646	1543	1359	1328	1285	1105	1068	977	912	636	1:60
BORONIA X/OVER	08:48	10:30	10:30	13:18	21	05:18	1500	1230	1200	1131	1056	926	909	875	750	725	660	615	410	1:40
COWAN	07:00	08:24	08:24	11:06	9	03:54	1676	1458	1341	1265	1183	1040	1018	980	842	815	743	693	483	1:45
BEROWRA	05:00	05:48	05:48	07:00	9	03:54	2477	2161	1992	1882	1766	1557	1519	1473	1268	1224	1122	1047	731	1:72
HORNSBY	10:06	10:18	10:18	10:12	11	10:24	2477	2161	1992	1882	1766	1557	1519	1473	1268	1224	1122	1047	731	1:68
THORNLEIGH	04:06	04:12	04:12	04:06	5	04:00	2477	2161	1992	1882	1766	1557	1519	1473	1268	1224	1122	1047	731	1:72
EPPING	06:36	06:36	06:36	06:42	6	08:24	2477	2161	1992	1882	1766	1557	1519	1473	1268	1224	1122	1047	731	1:72
EASTWOOD	02:00	02:06	02:06	02:12	--	02:42	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	Level
WEST RYDE	02:12	02:12	02:12	02:12	5	03:06	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
RHODES	02:42	02:42	02:42	02:42	3	03:06	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
CONCORD WEST	01:54	02:00	02:00	02:00	3	01:48	4102	3587	3314	3134	2949	2607	2535	2472	2133	2055	1892	1766	1232	1:132
NTH STRATHFIELD JCT	02:00	02:00	02:00	02:00	3	02:12	4102	3587	3314	3134	2949	2607	2535	2472	2133	2055	1892	1766	1232	1:132
FLEM MKTS 625 Pts	03:18	03:18	03:18	03:18	5	03:24	2766	2414	2227	2104	1976	1743	1699	1650	1422	1372	1259	1175	820	1:80
FLEM GDS MID JCT	01:12	01:12	01:12	01:12	5	01:06	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984	1:100
FLEM GDS SOUTH JCT	01:24	01:24	01:24	01:24	1	01:24	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984	1:100
MFN FLEMINGTON	01:30	01:30	01:30	01:30	8	01:06	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984	1:100

# For other Sydney Metropolitan area running times, refer to diagram in the 'Sydney Metropolitan Division Pages' Sydney Metropolitan Area – freight and locomotive running times (page 72).

% D schedules do not form part of the Standard Working Timetable. It is used for special train path planning.



## Gosford – Newcastle Interchange

KILOM-ETRAGE	DOWN SIGNS ON UP MAIN			UP SIGNS ON DOWN MAIN		
51.230	X50	..	X50	..	..	..
51.409	BORONIA					
51.510	..	..	..	X50	..	X50
51.751	..	..		60	60	60
52.513	55	70	75	..	..	..
53.250	50	60	60	..	..	..
53.742	..	..	..	60	65	65
53.745	50	55	55	..	..	..
54.859	55	55	60	..	..	..
56.499	..	..	..	55	55	55
56.700	X50		X50	..	..	..
57.397	HAWKESBURY RIVER					

## Hawkesbury River – Gosford

KILOM-ETRAGE	DOWN			UP		
	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH
57.555	80	80	85	..	..	..
58.127	80	100	100	..	..	..
58.130	..	..	..	75	75	85
60.897	80	95	100	..	..	..
60.927	..	..	..	80	100	100
61.625	70	70	75	80	95	100
62.321	65	65	70	..	..	..
63.358	..	..	..	70	70	70
65.146	WONDABYNE					
65.290	60	60	65	..	..	..
65.611	60	75	80	..	..	..
65.615	..	..	..	65	65	70
66.586	..	..	..	65	75	80
66.658	60	60	65	..	..	..
66.894	80	115	115	..	..	..
66.995	..	..	..	60	60	65
69.239	80	105	110	80	115	115
69.488	80	115	125	..	..	..
69.489	..	..	..	80	105	110
72.253	..	..	..	80	115	125
72.378	75	75	85	..	..	..
72.617	WOY WOY					
72.949	..	..	..	70	80	90
73.193	85	85	85	..	..	..
74.650	..	..	..	80	90	100
74.713	90	90	100	..	..	..
74.819	KOOLEWONG					
75.359	70	70	75	..	..	..
75.905	..	..	..	70	70	75
75.907	85	85	95	..	..	..
76.906	TASCOTT					
77.230	85	90	95	85	85	90
78.050	POINT CLARE					
78.207	85	115	120	85	90	95
80.077	..	..	..	85	115	120
80.078	60	60	60	..	..	..
80.485	..	..	..	85	90	95
80.515	60	40	40	..	..	..
80.791	..	..	..	60	40	40
80.908	GOSFORD					

KILOM-ETRAGE	DOWN			UP		
	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH
80.908	GOSFORD					
81.017	..	..	..	50	40	40
81.040	25	25	25	Down Refuge		
81.045	50	40	40	..	..	..
81.465	85B Pts Up Refuge			X50	..	..
81.640	..	..	..	50	40	40
81.800	80	85	90	..	..	..
81.825	75	75	75	Down Refuge		
82.000	Up Refuge			60	60	60
83.407	X75	..	..	201A Pts Down Refuge		
83.440	Up Refuge			75	75	75
83.620	202B Pts			X75	..	..
83.974	75	75	80	80	85	90
84.597	NARARA					
84.754	..	..	..	75	75	80
84.820	75	90	100	..	..	..
85.845	..	..	..	75	90	100
86.111	75	75	80	..	..	..
86.193	NIAGARA PARK					
86.800	100	100	105	..	..	..
86.802	..	..	..	75	75	80
87.729	LISAROW					
87.983	110	115	125	100	100	105
90.004	..	..	..	110	115	125
90.031	110	110	120	..	..	..
90.607	OURIMBAH					
92.231	..	..	..	110	110	120
92.231	115	115	145	..	..	..
93.329	X70	110A Pts			..	..
93.360	..	..	..	115	115	145
93.525	X75	111B Pts			Up Sign on Down Main	
95.334	115	115	135	115	115	145
97.104	110	110	115	..	..	..
97.143	..	..	..	115	115	135
97.676	..	..	..	110	110	115
98.540	TUGGERAH					
99.088	90	90	100	..	..	..
99.400	100	100	105	..	..	..
100.089	..	..	..	115	115	150
100.641	..	..	..	115	115	135
101.082	WYONG					
101.291	60	60	60	Down Sign on Up Main		
101.291	115	115	115	90	90	95
101.419	Up Sign on Down Main			45	60	60
102.491	X60	107 Points			Down Sign on Up Main	
102.558	Up Sign on Down Main			60	60	60
102.760	108 Points			X60	..	..
103.084	..	..	..	95	95	105
103.687	115	115	160	..	..	..
105.896	WARNERVALE					
106.488	110	110	115	..	..	..
111.803	..	..	..	110	115	115
113.009	105	105	115	110	115	135
114.532	115	115	140	..	..	..
114.534	..	..	..	105	105	115
114.864	WYEE					
115.115	..	..	..	115	115	130
116.801	115	115	130	115	115	140
117.436	110	110	120	115	115	130
118.106	105	105	115	110	110	120
119.545	85	85	90	105	105	115
120.265	..	..	..	80	80	85
120.502	115	115	120	..	..	..
123.146	110	110	120	..	..	..
123.189	..	..	..	115	115	125

KIOM-ETRAGE	DOWN			UP			KIOM-ETRAGE	DOWN			UP		
123.334	MORISSET						160.536	..	..	..	90	100	110
124.478	70	70	75	..	..	..	161.120	ADAMSTOWN					
124.480	..	..	..	110	110	115	162.033	..	..	..	90	90	100
125.255	80	80	85	..	..	..	162.804	60	60	60	..	..	..
125.303	..	..	..	75	75	80	162.935	BROADMEADOW					
125.680	..	..	..	80	80	85	163.670	X30	..	X30	..	..	..
125.680	95	95	105	..	..	..	163.685	WOODVILLE JUNCTION					
126.137	110	115	120	..	..	..	163.690	WOODVILLE JUNCTION SIGNAL BOX					
126.139	..	..	..	95	95	105	163.910	40	..	45	<i>On Down Islington Loop</i>		
127.232	DORA CREEK						163.910	<i>On Up Islington Loop</i>			X30	..	X30
127.931	110	110	115	..	..	..	163.913	..	..	..	80	80	80
127.998	..	..	..	105	115	115	Note: General only speed signs through to Newcastle Interchange						
128.364	..	..	..	105	110	115	163.938	40	..	..	..	..	..
129.519	85	85	95	..	..	..	164.310	X25	..	..	<i>475 Points</i>		
129.521	..	..	..	105	105	115	164.330	..	..	..	40	..	..
130.447	85	85	90	..	..	..	164.395	25	..	..	..	..	..
131.217	70	70	75	..	..	..	164.410	<i>476 Points</i>			X25	..	..
131.219	..	..	..	85	90	95	164.488	60	..	..	..	..	..
131.638	70	75	80	..	..	..	164.555	..	..	..	75	..	..
133.039	70	70	75	70	75	80	164.633	HAMILTON					
134.080	..	..	..	70	70	75	165.125	..	..	..	60	..	..
134.838	75	75	80	..	..	..	165.222	40 / X30	..	..	<i>Transit Road / 485A Pls</i>		
134.840	..	..	..	65	65	70	165.251	<i>Up Sign on Down Branch</i>			X60	<i>484B Pls</i>	
136.195	..	..	..	70	70	75	165.296	<i>Up Sign on Down Branch</i>			X30	<i>485B Pls</i>	
137.231	70	70	80	..	..	..	165.303	X40	..	..	<i>486A Pls</i>		
137.305	AWABA						165.386	<i>Up Sign on Transit Road</i>			X40	<i>486B Pls</i>	
137.778	100	115	130	70	70	80	165.395	<i>Up Sign on Down Branch</i>			X60	<i>487B Pls</i>	
140.162	..	..	..	115	115	130	165.395	25	..	..	<i>Transit Road</i>		
140.165	95	95	105	..	..	..	165.395	25	..	..	..	..	..
141.102	75	75	80	95	95	100	165.395	25	..	..	<i>Down Sign on Up Branch</i>		
142.313	FASSIFERN						165.465	<i>488B Pls</i>			X40	..	..
142.388	..	..	..	75	75	80	165.745	<i>Platform 3 Road</i>			40	..	..
142.498	75	100	105	..	..	..	165.746	<i>Platform 1 and 2 Road</i>			60	..	..
142.510	X25	..	..	<i>51 Points</i>			165.643	NEWCASTLE INTERCHANGE					
142.710	10	..	..	<i>On South Fork</i>									
142.710	<i>On South Fork</i>			25	..	..							
143.496	..	..	..	75	100	105							
143.496	70	70	75	..	..	..							
143.913	70	70	80	..	..	..							
144.302	..	..	..	65	75	80							
144.819	..	..	..	70	70	75							
144.874	75	80	85	..	..	..							
146.194	..	..	..	75	80	85							
146.392	BOORAGUL												
146.869	75	75	80	..	..	..							
147.540	..	..	..	75	75	80							
147.565	TERALBA												
147.770	75	115	130	..	..	..							
149.544	..	..	..	75	115	130							
149.544	75	100	105	..	..	..							
150.361	75	110	115	..	..	..							
150.364	..	..	..	75	95	105							
150.626	COCKLE CREEK												
152.264	65	110	115	..	..	..							
153.451	SULPHIDE JUNCTION												
153.546	75	75	85	75	110	115							
153.908	..	..	..	75	80	85							
154.845	65	65	70	..	..	..							
154.897	..	..	..	75	75	80							
155.083	CARDIFF												
155.512	70	70	75	..	..	..							
156.399	85	85	95	..	..	..							
156.400	..	..	..	70	70	75							
158.339	..	..	..	85	85	90							
158.498	60	85	90	..	..	..							
158.922	KOTARA												
159.045	60	90	90	..	..	..							
160.144	60	90	90	..	..	..							

## Station data

Version April 2019

Station	Kilo – metrage	Signal Box Status	Hours of Signal Box	Facilities
Hornsby	33.864	A	Controlled from Homebush	P
Asquith	35.694			P
Mt Colah	37.675			P
Mt Kuring-gai	40.667			P
Berowra	44.661	C	Controlled from Homebush	P
Cowan	48.814	C	Controlled from Homebush	P
Boronia	51.409	C	Controlled from Homebush	L
Hawkesbury River	57.397	C	Controlled from Homebush	P
Wondabyne	65.146			P
Woy Woy	72.617			P
Koolewong	74.819			P
Tascott	76.906			P
Point Clare	78.050			P
Gosford	80.908	A	Always	P, TT, WC
Narara	84.597			P
Niagara Park	86.193			P
Lisarow	87.729			P
Ourimbah	90.607			P
Tuggerah	98.540			P
Wyong	101.082	A	Always	P
Warnervale	105.896			P
Wyee	114.864			P
Vales Point Coal	119.230	C	Controlled from Morisset	L
Morisset	123.334	A	Always	P
Eraring Coal	132.590	C	Controlled from Broadmeadow Signal Control Centre	L
Dora Creek	127.232			P
Awaba	137.305	C	Controlled from Broadmeadow Signal Control Centre	LP, P
Fassifern	142.313		Attended as required for Newstan Colliery	P
Booragul	146.392			P
Teralba	147.565			P
Teralba Colliery				L
Cockle Creek	150.626			P
Sulphide Junction	153.451	C	Controlled from Broadmeadow Signal Control Centre	
Cardiff	155.083			P
Kotara	158.922			P
Adamstown	161.120	C	Controlled from Broadmeadow Signal Control Centre	P
Broadmeadow	162.935	C	Controlled from Broadmeadow Signal Control Centre	P
Woodville Junction	163.690	A	Always	
Hamilton	164.633	A	Always	P
Newcastle Interchange	165.643	A	Always	P

## Advisory speed signs

Special advisory speed signs have been positioned approaching signals at the locations shown below. Drivers of trains (except XPT's / Xplorer, Endeavour, Hunter trains and EMU's) are required to regulate the speed of their train at such locations to ensure that before reaching the signal indicated the speed is not in excess of that figure shown on the special advisory sign. If at any point approaching the signal it is seen to be exhibiting a full clear indication, normal track speed for the train concerned may be resumed.

Location	Signal number	Speed shown on sign
141.540 km	Fassifern No 48 Down Home, Main (88.1)	60
142.145 km	Fassifern Down Second Home, Main (88.5)	60


## Tonnage signals

Certain signals listed herein are treated as **Tonnage Signals**, that is to say, in order to avoid the risk of trains over a certain tonnage being brought to a stand at signals where it would be difficult for them to restart, these tonnage signals shall not be passed by trains conveying loads in excess of 75% of the prescribed load (i.e. 75% of Full Sectional Load) unless the Tonnage signal is in the clear position (or by telephone instructions in the case of failure).

The following signals are to be treated as a Tonnage signal, in accordance with Sydney Trains Network Rule NSG 608 *Passing signal at STOP*.

Kilometrage	Signal number	Section located
Refer to Sydney Metropolitan Section		
<b>Tonnage signals</b> <i>Tonnage signals</i> (page 74) for Tonnage Signals between Sydney and Hornsby		
57.290	# 146	Hawkesbury River
57.295	# 148	Hawkesbury River
57.300	# 150	Hawkesbury River
57.420	# 148 Repeater	Hawkesbury River
65.804	40.9	Wondabyne – Woy Woy
126.900	78.8	Dora Creek – Morisset
128.420	79.9	Dora Creek – Awaba

# The signals at Hawkesbury River are fitted with a notice plate that reads as follows:



## Transfer of Heavy Coal locomotives Woodville Junction – Enfield/Chullora and return for wheel lathe attention or maintenance

*Version April 2019*

Heavy Coal locomotives include the following locomotives:

- 90 Class
- TT and TT100 Class (at up to 139t)
- C44aci (92, 93, 6000, 6020, ACC, CEY, CF, FIE, GWU, MRL, XRN, and PHC at up to 139t)
- 5000 and 5020 Class

These Heavy Coal locomotives may be transferred from Woodville Junction to Flemington South Junction (for Enfield or Chullora) and return for wheel lathe attention or maintenance as a light locomotive movement in each direction subject to the following conditions:

1. Single or multiple 90 class locomotives are permitted, or a 90 class locomotive can be transferred in multiple with any other Pacific National locomotive.
2. Single or multiple 5000/5020 class locomotives shall be hauled dead attached by 423 and/or 6000 class locomotives. The mass of the 5000/5020 class locomotives shall not exceed 167 tonnes.
3. Single or multiple TT, TT100, or C44aci locomotives are permitted, and shall be reduced to 134 tonnes or less when traversing between Vales Point and Flemington South Junction.
4. The axle loads are to be decreased by ensuring the locomotives have a reduced fuel load (do not fill fuel tank prior to transfer).
5. The 90/5000/5020 class locomotives shall reduce its speed to 20 km/h when traversing the following bridges:
  - Main North: 12.628 km (Parramatta Rd)
  - Bankstown Line: 19.202 km (Marion St)
 In addition, the speed of 90/5000/5020 class locomotives shall be reduced to 50 km/h when traversing the following bridge:
  - Main North: 160.300 km (Kotara – Northcott Drive)
  - Main North: 127.025 km (Dora Creek – Dora Ck)
6. The maximum track speed shall be as detailed in the table below:

<b>Maximum track speeds</b>		
<b>Location</b>	<b>90 Class</b>	<b>5000 and 5020 Class</b>
Between Woodville Junction – Vales Point Junction	60 km/h	50 km/h
Between Flemington South Junction – Vales Point Junction	50 km/h	45 km/h

*Note – TT, TT100, and C44aci locomotives do not require additional speed restrictions as they are reduced to 134 tonnes or less and can operate at normal track speeds.*

7. Sector Civil Engineers to be advised at least 48 hours in advance.
8. Transfer of these locomotives from Woodville Junction to Flemington South Junction (for Enfield/Chullora) is to be done under block working conditions as per *NSY 512 Manual block working*.

Transfer of these locomotives from Flemington South Junction (from Enfield/Chullora) to Woodville Junction shall be blocked worked where specified in the *General Instruction Pages of the Train Operating Conditions Manual, Locomotive Operations*.

## Conditions for the operation of self-propelled diesel trains

Version December 2018

The following operating conditions are for diesel self-propelled trains (XPT) between Hornsby and Woodville Junction / Newcastle Interchange.

XPT	Conditions of Operation – Down Direction
√	All power cars operating
--	All engines operating
√	Maximum 7 trailer cars with 2 power cars or maximum 4 trailer cars with 1 power car powering and 1 power car disabled
√	All compressors operating
√	Emergency coupler available
√	No brake cut outs permitted
√	Electro-pneumatic (EP) brake, automatic brake, hand and all spring parking brakes fully operational

XPT	Conditions of Operation – UP Direction
√	All power cars operating
--	All engines operating
√	Maximum 7 trailer cars with 2 power cars or maximum 4 trailer cars with 1 power car powering and 1 power car disabled
√	All compressors operating
√	Emergency coupler available
√	No brake cut outs permitted
√	Electro-pneumatic (EP) brake, automatic brake, hand and all spring parking brakes fully operational

Superseded by TS TOC 2 v22.0, 24/09/2021

Superseded by TS TOC 2 v22.0, 24/09/2021


**Section 14**  
**Western Division pages**

## 14. Western Division pages

Version April 2021

### Maximum speed of locomotives and rolling stock

	Penrith – Lithgow DOWN MAIN	Lithgow – Valley Heights UP MAIN	Valley Heights – Penrith UP MAIN			
Class of Line	1	1	1			
Line Map Reference	A	B	C			
<b>LOCOMOTIVES</b>						
Class	Max Speed km/h					
90, TT(139t), TT100 (139t), C44aci(139t)(d)	N/A	N/A	N/A			
31, L, LO, LZ	100	100	100			
1100, 92, 93, 6000, 6020, ACC, C, CEY, CF, CM, CSR, FIE, GWA, GWU, LDP10, MRL, PHC, QBX, RL, SCT, SSR, TT(134t), TT100 (134t), WH, XRN	115	115	115			
82, CLP, GL NR	115	115	115			
14, 81, ALF, AN, BL, CLF, G, VL	115	115	115			
42, 80, 80s, B, DL	115	115	115			
18	90	90	90			
442, 442s, 700, GM(12), S, X	115	115	115			
32	100	100	100			
1200, 22, 421, 422, 44, 45, 45s, 600, DC, EL, FL, GM(1), HL	115	115	115			
43, 44s, 930	115	115	115			
423	80	80	80			
D, K, T	100	100	100			
47, 48, 48200, 48s, 49, 830, 900, GPU, MM, PL	100	100	100			
73 (c)	70	70	70			
46, 86 Electric	100(b)	100(b)	100(b)			
32(P), 59 Steam	80	80	80			
Multiple locomotive working (powering locomotives horsepower limit per locomotive group)	U (16000)	U (16000)	U (16000)			
<b>FREIGHT</b>						
Class A	115	115	115			
Class B	100	100	100			
Class C	80	80	80			
Class D	65	65	65			
Class E	80	80	80			
Class F	65	65	65			
Class G	N/A	N/A	N/A			
<b>PASSENGER</b>						
XPT	160	160	160			
XPLOREER	145	145	145			
DIESEL RAILCARS	115	115	115			
LOCO HAULED	115	115	115			
	(a)					
<b>NOTES</b>						
U = Unlimited number of locomotives (subject to horsepower limit per locomotive group).						
(a)	See instructions contained in <i>General Instructions</i> for operation of trains and light locomotives over the section Katoomba to Valley Heights.					
(b)	Applies to SINGLE and distributed locomotives (separated by at least 70 metres of train). No OHW restrictions apply. Both pantographs may be raised.					
(c)	Only locomotives fitted with vigilance control system are approved to operate outside shunting yards.					
(d)	C44aci(139t) locomotives provisioned between 134t and 139t include 92, 93, 6000, 6020, ACC, CEY, CF, FIE, GWU, MRL, XRN, PHC.					
<b>SAFeworking SYSTEMS</b>						
Penrith – Edgecombe	#Rail Vehicle Detection (Axe Counters at Mt Victoria)					
Edgecombe – Zig Zag	Rail Vehicle Detection (Bi-directional)					
Zig Zag – Lithgow Coal Stage Signal Box	Rail Vehicle Detection					
Lithgow Coal Stage Signal Box – Lithgow Yard	Rail Vehicle Detection					
Signal Box						
#Valley Heights to Springwood – Two way running Down Main						



## General - Sectional running times and full sectional loads

Version April 2020

The locomotive-load-run times configurations (DOWN loads and UP loads) published in this section are for existing approved paths in the Standard Working Timetable (SWTT). For configurations that are not listed, the train shall run at the discretion of the train controller, based on the following:

- The trailing load does not exceed the sum of individual locomotive full sectional loads, accounting for load reductions specified in (TS TOC.1 Section 2.11 and 2.12)
- There is capacity on the network (based on the live status and the SWTT/DWTT) for the train controller to allocate additional times for the train if longer journey or sectional running times, or both are foreseen.
- The operator operates to the assigned schedule or under the direction of the train controller to ensure the train's arrival at critical junctions or destinations does not cause train control conflicts to the network.

The sectional running times published are based on RailNet Running Time Profiles (simulations). Train consists (locomotive and trailing loads) used in the simulations are based on the length limits in the train operating length diagram in TS TOC 1 (Section 1.11) with no speed restrictions applied.

Any planned and timetabled sectional running times used in ad hoc paths, Daily Working Timetable, and Standard Working Timetable have additional time added to the published running times (for example recovery time), which should be accounted for by the train controller / planner / programmer as appropriate.

## DOWN loads

Version December 2020

SECTIONS	LOCOMOTIVE CLASS = L	LOAD – TONNES				TRAIN DATA		
		SINGLE	DOUBLE	TRIPLE	QUAD	VEHICLE CLASS	SECT RUN TIMES	NOTES
1 SYDNEY METROP – LITHGOW	L2	900	1800	2700	3600	ABC	L01	\$
2 SYDNEY METROP – LITHGOW	L2	900	1800	2700	3600	A	A1	
3 SYDNEY METROP – LITHGOW	L3/L4	550	1100	1650	2200	A	A1	
4 SYDNEY METROP – LITHGOW	AC6	900	1800	2700	--	A	A1	
5 SYDNEY METROP – LITHGOW	AC6 + L2	--	1950	--	--	A	A1	# C44ACi and NR Only
6 SYDNEY METROP – LITHGOW	AC6 + L2	--	1850	--	--	A	A1	b
7 SYDNEY METROP – LITHGOW	AC6 + 2 x L2	--	--	2850	--	A	A1	# C44ACi and NR Only
8 SYDNEY METROP – LITHGOW	AC6 + 2 x L2	--	--	2610	--	A	A1	b
9 SYDNEY METROP – LITHGOW	2 x AC6 + L2	--	--	3000	--	A	A1	# C44ACi and NR Only
10 SYDNEY METROP – LITHGOW	2 x AC6 + L2	--	--	2890	--	A	A1	b
11 SYDNEY METROP – LITHGOW	AC6	--	1130	--	--	ABC	C1	
12 SYDNEY METROP – LITHGOW	L3/L4	450	900	1350	1800	ABCE	C1	
13 SYDNEY METROP – LITHGOW	L4 + L11	--	691	--	--	ABCE	C1	G + 442 Only
14 SYDNEY METROP – LITHGOW	L4 + 2 x L11	--	--	932	--	ABCE	C1	G + 442 Only
15 SYDNEY METROP – LITHGOW	3 x L11	--	--	723	--	ABCE	C1	G + 442 Only
16 SYDNEY METROP – LITHGOW	2 x L11 + L12	--	--	723	--	ABCE	C1	G + 442 Only
17 SYDNEY METROP – LITHGOW	4 X L11	--	--	--	964	ABCE	C1	G + 442 only
18 SYDNEY METROP – LITHGOW	3 x L11 + L12	--	--	--	964	ABCE	C1	G + 442 only
19 SYDNEY METROP – LITHGOW	L2	900	1800	2700	3600	ABCDE	C2	
20 SYDNEY METROP – LITHGOW	L3/L4	550	1100	1650	2200	ABCE	C2	
21 SYDNEY METROP – LITHGOW	AC6	900	1800	2700	--	ABCDE	C2	
22 SYDNEY METROP – LITHGOW	AC6 + L2	--	1950	--	--	ABCDE	C2	# C44ACi & NR Only
23 SYDNEY METROP – LITHGOW	AC6 + L2	--	1850	--	--	ABCDE	C2	b
24 SYDNEY METROP – LITHGOW	AC6 + 2 x L2	--	--	2850	--	ABCDE	C2	# C44ACi & NR Only
25 SYDNEY METROP – LITHGOW	AC6 + 2 x L2	--	--	2610	--	ABCDE	C2	b
26 SYDNEY METROP – LITHGOW	2 x AC6 + L2	--	--	3000	--	ABCDE	C2	# C44ACi & NR Only
27 SYDNEY METROP – LITHGOW	2 x AC6 + L2	--	--	2890	--	ABCDE	C2	b
28 SYDNEY METROP – LITHGOW	L13	281	562	843	1124	ABCDE	C4	
29 SYDNEY METROP – LITHGOW	L3/L4	750	1500	2250	3000	ABCDE	D1	
30 SYDNEY METROP – LITHGOW	L5	700	1400	2100	2800	ABCDE	D1	
31 SYDNEY METROP – LITHGOW	L6/L7	599	1198	1497	2396	ABCDE	D1	
32 SYDNEY METROP – LITHGOW	L8	573	1146	1719	2292	ABCDE	D1	
33 SYDNEY METROP – LITHGOW	L9/L10	450	900	1350	1800	ABCDE	D1	
34 SYDNEY METROP – LITHGOW	L11/L12	402	804	1206	1608	ABCDE	D1	
35 SYDNEY METROP – LITHGOW	AC6	1246	2492	3738	--	ABCDE	D1	

\$ This schedule is for trains longer than 1280m and up to 1500m, with speed restrictions applied as per TS TOC 1, Section 1.11.

# A full listing of approved AC6 locomotives (United Group Ltd – C44ACi, Downer EDI Rail – GT46C-ACe, and CRRC Ziyang – SDA1) is summarised under Table 8 Approved locomotives grouped into load categories – locomotive type AC in TS TOC 1.

b The AC6 locomotive shall be a C44ACi or GT46CACe type AC locomotive and the L2 locomotive shall be NR or AN class.

## DOWN – sectional running times and full sectional loads

Version April 2021 (5.14)

Lo1\$	A1	C1	C2	C4	%D1	Loco	AC6	FULL SECTIONAL LOADS													GRADE
								SECTIONAL RUNNING TIMES (INDICATIVE)						LOCOMOTIVE CATEGORIES = L							
								2	3	4	5	6	7	8	9	10	11	12	13		
MFN FLEMINGTON to:	8	8	8	8	8	8	8														
FLEM GDS STH JCT	01:00	01:06	01:06	01:06	01:06	8	01:24	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984	1:100
LIDCOMBE	03:12	03:06	03:06	03:06	03:06	3	02:00	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984	1:100
AUBURN	02:06	02:06	02:06	02:06	02:06	3	02:30	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
CLYDE	02:18	02:12	02:12	02:12	02:12	3	03:00	3542	3096	2858	2702	2541	2245	2185	2128	1835	1768	1627	1518	1059	1:110
GRANVILLE	00:36	00:42	00:42	00:42	00:42	2	00:42	3775	3300	3047	2882	2711	2395	2330	2271	1959	1887	1737	1621	1131	1:120
PARRAMATTA	02:30	02:06	02:06	02:06	02:06	2	01:48	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	Level
WESTMEAD	02:00	01:54	01:42	01:48	02:12	2	01:36	2766	2414	2227	2104	1976	1743	1699	1650	1422	1372	1259	1175	820	1:80
SEVEN HILLS	06:24	05:48	05:36	05:42	06:36	7	06:24	2477	2161	1992	1882	1766	1557	1519	1473	1268	1224	1122	1047	731	1:70
BLACKTOWN	02:42	02:24	02:18	02:18	02:42	3	02:18	2904	2536	2339	2211	2077	1833	1786	1736	1495	1442	1324	1236	862	1:85
ST MARYS	11:24	10:06	09:54	10:00	11:18	12	11:48	2766	2414	2227	2104	1976	1743	1699	1650	1422	1372	1259	1175	820	1:80
PENRITH	08:06	07:06	07:00	06:54	07:30	8	07:42	2623	2289	2111	1995	1872	1651	1610	1563	1346	1299	1191	1112	776	1:75
EMU PLAINS	02:36	02:12	02:06	02:12	02:12	2	02:00	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	Level
GLENBROOK	12:12	11:42	09:54	11:06	17:24	14	08:12	2171	1892	1743	1646	1543	1359	1328	1285	1105	1068	977	912	636	1:60
VALLEY HEIGHTS	14:00	13:54	11:12	13:06	21:48	16	09:18	2171	1892	1743	1646	1543	1359	1328	1285	1105	1068	977	912	636	1:60
SPRINGWOOD	03:54	04:06	03:12	03:42	06:36	5	02:30	1246	900	750	750	700	610	599	573	490	476	431	402	281	1:33
LAWSON	29:12	29:06	23:42	27:54	45:48	36	16:54	1246	900	750	750	700	610	599	573	490	476	431	402	281	1:33
WENTWORTH FLS	11:54	11:48	09:24	11:12	17:42	14	06:24	1246	900	750	750	700	610	599	573	490	476	431	402	281	1:33
KATOOMBA	12:06	12:06	10:12	11:36	18:54	15	07:54	1246	900	750	750	700	610	599	573	490	476	431	402	281	1:33
MT VICTORIA	20:42	18:48	17:54	18:42	19:30	19	18:12	2357	2055	1894	1789	1678	1479	1444	1399	1204	1163	1065	994	693	1:66
NEWNES JCT	16:06	14:48	13:30	14:24	18:06	17	14:12	2623	2289	2111	1995	1872	1651	1610	1563	1346	1299	1191	1112	776	1:75
EDGEcombe	03:42	03:06	03:00	03:00	03:12	4	03:24	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
ZIG ZAG	06:36	05:36	05:42	05:42	06:00	6	08:06	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
LITHGOW CS BOX	04:18	04:12	03:54	04:12	03:54	5	05:06	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
LITHGOW	02:06	01:48	01:42	01:48	01:48	2	01:36	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
CRN WEST BDRY	00:36	00:30	00:30	00:30	00:36	1	00:24	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG

# For other Sydney Metropolitan area running times, refer to diagram in the 'Sydney Metropolitan Division Pages' Sydney Metropolitan Area – freight and locomotive running times (page 72).

\$ This schedule is for trains longer than 1280m and up to 1500m, with the speed restrictions applied as per TS TOC 1, Section 1.11.

% D schedules do not form part of the Standard Working Timetable. It is used for special train path planning

## UP loads

Version December 2020

SECTIONS	LOCOMOTIVE CLASS = L	LOAD – TONNES				TRAIN DATA		
		SINGLE	DOUBLE	TRIPLE	QUAD	VEHICLE CLASS	SECT RUN TIMES	NOTES
1	LITHGOW – SYDNEY METROP	L2	850	1700	2550	3400	A	A1
2	LITHGOW – SYDNEY METROP	L3/L4	550	1100	1650	2200	A	A1
3	LITHGOW – SYDNEY METROP	AC6	850	1700	2550	--	A	A1
4	LITHGOW – SYDNEY METROP	L2	1300	2600	3900	5200	A	A2
5	LITHGOW – SYDNEY METROP	L3/L4	1000	2000	3000	4000	A	A2
6	LITHGOW – SYDNEY METROP	AC6	1500	3000	4600*	--	A	A2 *
7	LITHGOW – SYDNEY METROP	AC6 + L2	--	2750	--	--	A	A2 # NR Only
7a	LITHGOW – SYDNEY METROP	AC6 + L2	--	2410	--	--	A	A2 b
8	LITHGOW – SYDNEY METROP	AC6 + 2 x L2	--	--	4050	--	A	A2 # NR Only
8a	LITHGOW – SYDNEY METROP	AC6 + 2 x L2	--	--	3530	--	A	A2 b
9	LITHGOW – SYDNEY METROP	2 x AC6 + L2	--	--	4200	--	A	A2 # NR Only
9a	LITHGOW – SYDNEY METROP	2 x AC6 + L2	--	--	3700	--	A	A2 b
10	LITHGOW – SYDNEY METROP	AC6^	--	3200	5000	^	ABCE	Lo2 ^
11	LITHGOW – SYDNEY METROP	L2	1300	2600	3900	5200	ABCE	C1
12	LITHGOW – SYDNEY METROP	L3/L4	1000	2000	3000	4000	ABCE	C1
13	LITHGOW – SYDNEY METROP	AC6	1500	3000	4600*	--	ABCE	C1 *
14	LITHGOW – SYDNEY METROP	AC6 + L2	--	2750	--	--	ABCE	C2 # C44ACi & NR Only
15	LITHGOW – SYDNEY METROP	AC6 + L2	--	2410	--	--	ABCE	C2 b
16	LITHGOW – SYDNEY METROP	AC6 + 2 x L2	--	--	4050	--	ABCE	C2 # C44ACi & NR Only
17	LITHGOW – SYDNEY METROP	AC6 + 2 x L2	--	--	3530	--	ABCE	C2 b
18	LITHGOW – SYDNEY METROP	2 x AC6 + L2	--	--	4200	--	ABCE	C2 # C44ACi & NR Only
19	LITHGOW – SYDNEY METROP	2 x AC6 + L2	--	--	3700	--	ABCE	C2 b
20	LITHGOW – SYDNEY METROP	L3/L4	1400	2800	--	--	ABCE	C2 ~
21	LITHGOW – SYDNEY METROP	L4 + L13	--	1800	--	--	ABCE	C2 ~
22	LITHGOW – SYDNEY METROP	L3/L4	1131	2262	3393	4524	ABCE	C2
23	LITHGOW – SYDNEY METROP	L5	1056	2112	3168	4224	ABCE	C2
24	LITHGOW – SYDNEY METROP	L6	926	1852	2778	3704	ABCE	C2
25	LITHGOW – SYDNEY METROP	L7	909	1818	2727	3636	ABCE	C2
26	LITHGOW – SYDNEY METROP	L8	875	1750	2625	3500	ABCE	C2
27	LITHGOW – SYDNEY METROP	L9	750	1500	2250	3000	ABCE	C2
28	LITHGOW – SYDNEY METROP	L10	725	1450	2175	2900	ABCE	C2
29	LITHGOW – SYDNEY METROP	L11	640	1280	1920	2560	ABCE	C2
30	LITHGOW – SYDNEY METROP	L12	615	1230	1845	2460	ABCE	C2
31	LITHGOW – SYDNEY METROP	L13	410	820	1230	1640	ABCE	C3
32	LITHGOW – SYDNEY METROP	L3/L4	1131	2262	3393	4524	ABCDE	D1

~ This train shall be given a clear run from Bowenfels to Zig Zag. The train shall not stop at Lithgow.

b The AC6 locomotive shall be a C44ACi or GT46C-ACe type AC locomotive and the L2 locomotive can be NR or AN class.

\*

# Total trailing load limited to 4500t only if any consist contains any SDA1 type AC locomotives.

A full listing of approved AC6 locomotives (United Group Ltd – C44ACi, Downer EDI Rail – GT46C-ACe, and CRRC Ziyang – SDA1) is summarised under Table 8 Approved locomotives grouped into load categories – locomotive type AC in TS TOC 1.

^ Operation of the Lo2 schedule is only applicable for FIE locomotives hauling FRAY wagons. The following additional conditions apply:

1. One CEY locomotive may be used to replace any of the FIE locomotives in the train consist. The CEY / FIE locomotives can be marshalled in any combination.
2. All hauling locomotives shall be fitted with an operative dynamic brake.
3. The MR and BP shall be continuous throughout the train.
4. The train length is permitted to exceed 1100 m, up to a maximum of 1280 m between Katoomba and Valley Heights.
5. A quad trailing load of 6131 tonnes is permitted to operate between Bowenfels and Katoomba with a train consist of 3 x FIE class locomotives, hauling FRAY wagons, assisted in the rear by a G class locomotive.
  - a. The train shall operate at 10km/h below the speed signs down to 50 km/h, then observe the general speed signs.
  - b. The rear assisting locomotive shall provide assistance to at least the 144 km mark and shall be detached from the consist at a location prior to Katoomba (109.9 km).
6. A quad trailing load of 6131 tonnes is permitted to operate under the Lo2 schedule between Katoomba and Sydney Metrop with a train consist of 3 x FIE class locomotives hauling FRAY wagons.

## UP – sectional running times and full sectional loads

*Version April 2021 (5.14)*

	FULL SECTIONAL LOADS															GRADE						
	*SECTIONAL RUNNING TIMES (INDICATIVE)										LOCOMOTIVE CATEGORIES = L											
	A1	A2	Lo2	C1	C2	C3	%D1	Loco	AC6	2	3	4	5	6	7	8	9	10	11	12	13	GRADE
CRN WEST BDRY to:	8	8	8	8	8	8	8	8	8	8	8	8	8	8	8	8	8	8	8	8	8	
LITHGOW	00:36	00:42	00:48	00:42	00:42	00:48	1	00:36	4407	3855	3562	3369	3171	2803	2726	2660	2295	2210	2036	1900	1326	1:150
LITHGOW CS BOX	02:00	02:06	02:00	02:00	02:00	02:00	2	01:54	4407	3855	3562	3369	3171	2803	2726	2660	2295	2210	2036	1900	1326	1:150
ZIG ZAG	04:36	06:18	06:48	06:00	09:18	09:12	7	04:12	1500	1300	1200	1131	1056	926	909	875	750	725	660	615	410	1:40
EDGEcombe	07:18	10:06	12:24	09:36	13:00	13:30	12	05:42	3039	2654	2449	2315	2175	1920	1870	1818	1567	1511	1388	1295	904	1:90
NEWNES JCT	03:06	03:42	04:06	03:36	04:18	04:30	5	03:06	3039	2654	2449	2315	2175	1920	1870	1818	1567	1511	1388	1295	904	1:90
MT VICTORIA	16:00	17:48	20:06*	17:24	19:48	20:48	17	15:48	3039	2654	2449	2315	2175	1920	1870	1818	1567	1511	1388	1295	904	1:90
KATOOMBA	17:54	19:42	22:06*	19:24	20:36	21:48	20	18:06	2766	2414	2227	2104	1976	1743	1699	1650	1422	1372	1259	1175	820	1:80
WENTWORTH FALLS	11:18	10:36	11:54	11:18	11:18	11:30	16	13:18	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
LAWSON	10:24	10:24	11:06	10:24	10:18	10:48	14	13:36	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
SPRINGWOOD	25:06	25:06	25:42	25:06	25:06	25:42	27	33:36	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
VALLEY HEIGHTS	03:42	03:42	03:48	03:42	03:42	03:54	4	03:06	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
GLENBROOK	10:54	11:00	11:36	11:00	10:48	11:00	15	14:06	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
EMU PLAINS	11:24	11:24	12:18	11:24	11:24	11:30	10	13:24	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	Level
PENRITH	02:30	02:36	02:36	02:30	02:30	02:48	4	02:18	5057	4426	4090	3869	3645	3223	3132	3060	2641	2542	2344	2188	1527	1:186
ST MARYS	06:54	07:30	07:42	07:24	08:06	09:12	8	07:12	2357	2055	1894	1789	1678	1479	1444	1399	1204	1163	1065	994	693	1:66
BLACKTOWN	10:12	10:54	11:06	10:54	11:24	12:36	13	11:18	2766	2414	2227	2104	1976	1743	1699	1650	1422	1372	1259	1175	820	1:80
SEVEN HILLS	02:24	02:24	02:30	02:24	02:24	02:30	2	03:00	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
WESTMEAD	06:06	06:18	06:30	06:12	06:24	06:42	7	06:36	3195	2791	2576	2435	2289	2021	1968	1915	1650	1591	1462	1365	952	1:95
PARRAMATTA	02:36	02:36	02:48	02:36	02:36	03:00	3	02:36	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
GRANVILLE	02:30	02:30	02:36	02:30	02:30	02:30	2	01:54	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
CLYDE	00:30	00:30	00:30	00:30	00:30	00:30	2	00:36	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG
AUBURN	02:24	02:24	02:36	02:24	02:24	02:24	3	02:12	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984	1:100
LIDCOMBE	02:06	02:06	02:12	02:06	02:06	02:06	3	02:24	3775	3300	3047	2882	2711	2395	2330	2271	1959	1887	1737	1621	1131	1:120
FLEM GDS STH JCT	01:48	01:48	02:00	01:48	01:48	01:48	3	02:06	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984	1:100
MFN FLEMINGTON	01:30	01:30	01:30	01:30	01:30	01:30	8	01:06	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984	1:100

- # For other Sydney Metropolitan area running times, refer to diagram in the 'Sydney Metropolitan Division Pages' Sydney Metropolitan Area – freight and locomotive running times (page 72).
- % D schedules do not form part of the Standard Working Timetable. It is used for special train path planning
- \* The published time does not include the shunt times and detachment of the rear assisting G class locomotive in the train consist at Mount Victoria

### Assisting Lithgow to Zig Zag

*December 2013*

The assist locomotive can be marshalled either on the front or on the rear of the train depending upon operational requirements and vehicle gross masses in the trailing 1/3 of the train mass as outlined in General Instruction Pages, Section 2 Locomotive Operations, Assisting (banking) locomotives.

When trains are **assisted in the lead** from Lithgow, the assist locomotives are to remain on the train until it arrives at Mt. Victoria. This is to avoid the situation of removing the assist locomotives from the train at Zig Zag whilst a portion of the train is still on the rising 1 in 40 grade.

When trains are **assisted in the rear** from Lithgow, bank locomotive traction motor currents shall not exceed 250 amps on diesel locomotives, until all the bank locomotives are on the Main line and completely clear of the crossovers in Lithgow yard.

Bank Locomotive working between Lithgow Coal Stage and Zig Zag is to be carried out as outlined in Sydney Trains Network Local Appendices *NLA 218 Lithgow*.



KILOM- ETRAGE	DOWN		UP	
155.986	..	..	#60	%70
156.016	#70	%80	..	..
158.753	#80	%90	#70	%85

# Down/Up Normal Signs

% Down/Up XPT signs

## Station data

Version August 2017

Station	Kilo – metrage	Signal Box Status	Hours of Signal Box	Facilities
Penrith	55.086	A	Always	P, WC
Emu Plains	57.439	C	Controlled from Penrith	P
Lapstone	63.617			P
Glenbrook	67.080			P
Blaxland	71.484			P
Warrimoo	74.296			P
Valley Heights	77.410	C	Controlled from Blacktown	P
Springwood	79.669	C	Controlled from Blacktown	P
Faulconbridge	82.962			P
Linden	86.805			P
Woodford	90.366			P
Hazelbrook	93.473			P
Lawson	96.033	C	Controlled from Blacktown	P
Bullaburra	97.685			P
Wentworth Falls	102.614			P
Leura	107.592			P
Katoomba	109.943	C	Controlled from Blacktown	P
Medlow Bath	115.803			P
Blackheath	120.724			P
Mt. Victoria	126.720	A	Always	P
Bell	137.126			P
Newnes Junction	141.763	C	Controlled from Blacktown as required for Clarence Colliery	P, S
Edgecombe	145.200	C	Controlled from Lithgow Coal Stage Signal Box	
Zig Zag	150.937	C	Controlled from Lithgow Coal Stage Signal Box	P, LP
Lithgow Coal Stage Signal Box	154.175	A	Always	
Lithgow Yard Signal Box	155.224	A	Always	
Lithgow	155.781			P, TT

## Tonnage signals

Version 10.0 December 2012

Certain signals listed herein are treated as **Tonnage Signals**, that is to say, in order to avoid the risk of trains over a certain tonnage being brought to a stand at signals where it would be difficult for them to restart, these tonnage signals shall not be passed by trains conveying loads in excess of 75% of the prescribed load unless the Tonnage signal is in the clear position (or by telephone instructions in the case of failure).

The following signals are to be treated as a Tonnage signal, in accordance with Sydney Trains Network Rule NSG 608 *Passing signal at STOP.*

Kilometrage	Signal Number	Section located
77.500	SD 21 Valley Heights	Valley Heights – Springwood
77.574	SD 23 Valley Heights	Valley Heights – Springwood
93.331	58.1	Springwood – Lawson

# Freight train braking requirements

Version 10.0 December 2012

## Conditions for freight trains – Down direction

- (a) Ballast and work trains, with less than 80% of vehicles fitted with fixed exhaust chokes, operating from the Metropolitan area beyond Valley Heights and terminating before Lithgow then returning **LOADED** to the Metropolitan area are required to have a HP grade inspection carried out on the train.

## Conditions for freight trains – Up direction

The following conditions apply to loaded freight trains operating between Katoomba and Valley Heights:

- (a) Braking requirements

- (1) Unless at least 80% of the train mass is fitted with approved fixed exhaust chokes, freight trains are required to have a HP grade inspection.
- (2) Grade control valves (where fitted) are to be set in the IP position at the inspection location or other approved location.
- (3) Dynamic / Regenerative brake shall be used if available.
- (4) Maximum length of train with single piped vehicles is **1100 metres**.
- (5) A HP grade inspection does not apply to ECP braked trains.

Refer also to TS TOC.1 General Instruction Pages – Section 3 Train Operations.

## Conditions for the operation of self-propelled diesel trains

Version December 2018

The following operating conditions are for diesel self-propelled trains (XPT) between Penrith and Bowenfels.

<b>XPT</b>	<b>Conditions of Operation – Down Direction</b>
√	All power cars operating
--	All engines operating
√	Maximum 7 trailer cars with 2 power cars or maximum 3 trailer cars with 1 power car powering and 1 power car disabled (see note below)
√	All compressors operating
√	Emergency coupler available
√	No brake cut outs permitted
√	Electro-pneumatic (EP) brake, automatic brake, hand and all spring parking brakes fully operational

<b>XPT</b>	<b>Conditions of Operation – UP Direction</b>
√	All power cars operating
--	All engines operating
√	Maximum 7 trailer cars with 2 power cars or maximum 4 trailer cars with 1 power car powering and 1 power car disabled (see note below)
√	All compressors operating (compressor on any dead power car to be switched to hotel supply)
√	Emergency coupler available
√	No brake cut outs permitted
√	Electro-pneumatic (EP) brake, automatic brake, hand and all spring parking brakes fully operational


*Note: As a limit for normal service operation, a maximum of 7 trailer cars with 2 power cars or 4 trailer cars with 1 power car powering and 1 power car disabled is permitted. For special event services (such as annual Parkes Elvis Festival) a maximum of 8 trailers with 2 power cars is permitted, all other operating conditions apply as detailed above.*

Superseded by TS TOC 2 v22.0, 24/09/2021

**Section 15**  
**Illawarra Division pages**

## 15. Illawarra Division pages

Version August 2020



July 2020

UNCONTROLLED WHEN PRINTED

# Maximum speed of locomotives and rolling stock

Version April 2021

	Waterfall - Port Kembla	Coniston- Unanderra	Berry – Boma derry (i)	Coniston – Inner Harbour	South Frk North Junction	Allans Creek – North Jct	Port Kembla Balloon Loop	Quarry Siding Bombo 2 (i)	Unanderra – 91.080km Moss Vale line
Class of Line	1	1	1(f)	1	1	1	1	2	1
Line Map Reference	A	B	C	D	E	F	G	H	J
<b>LOCOMOTIVES</b>									
Class									Maximum Speed km/h
90, TT(139t), TT100 (139t), C44aci(139)(g)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
31, L, LO, LZ	100	100	100(h)	100(e)	25	35	60	25	15
Refer to note (j) for locomotives	115	100	80	80(e)	25	35	60	25	15
CSR, QBX	115	100	80	80(e)	25	35	N/A	25	N/A
CLP, GL, NR	115	100	80(a)	80(a)	25	35	60	25	15
14, 81, 82, ALF, AN, BL, CLF, G, VL	115	100	80	80	25	35	60	25	15
42, 80, 80s, B, DL	115	100	80	80	25	35	60	25	15
18	90	90	80	80	25	35	60	25	15
442, 442s, 700, GM(12), S, X	115	100	80	80	25	35	60	25	15
32	100	100	80	80	25	35	60	25	15
1200, 22, 421, 422, 44, 45, 45s, 600, DC, EL, FL, GM(1), HL	115	100	100	100	25	35	60	25	15
43, 44s, 930	115	100	100	100	25	35	60	25	15
423	80	80	80	80	25	35	60	25	15
D, K, T	100	100	100	100	25	35	60	25	15
47, 48, 48200, 48s, 49, 830, 900, GPU, MM, PL	100	100	100	100	25	35	60	25	15
73 (d)	70	70	70	70	25	35	60	25	15
46, 86 Electric	100(b)	100(b)	100(b,c)	N/A	N/A	N/A	N/A	N/A	N/A
59, 32(P) Steam	80	80	80	80	N/A	35	N/A	N/A	50
Multiple locomotive working (powering locomotives horsepower limit per locomotive group)	U (16000)	U (16000)	U (16000)	U (16000)	U (16000)	U (16000)	U (16000)	U (16000)	U (16000)
<b>FREIGHT</b>									
Class A	115	115	100	100	25	35	60	25	15
Class B	100	100	80	80(e)	25	35	60	25	15
Class C	80	80	80	80	25	35	60	25	15
Class D	65	65	60	60	25	35	60	25	15
Class E	80	80	70	70	25	35	60	25	15
Class F	65	65	65	65	25	35	60	25	15
Class G	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
<b>PASSENGER</b>									
XPT	160	160	140	140	25	35	60	25	15
XPLOREER	145	145	140	140	25	35	60	25	15
DIESEL RAILCARS	115	115	100	100	25	35	60	25	15
LOCO HAULED	115	115	100	100	25	35	60	25	15
<b>NOTES</b>									
U = Unlimited number of locomotives (subject to horsepower limit per locomotive group).									
(a) NR locomotives restricted to operate between Unanderra and Dunmore.									
(b) Applies to SINGLE and distributed locomotive (separated by at least 70 metres of train). No OHW restrictions apply. Both pantographs may be raised.									
(c) Unanderra to Kiama only.									
(d) Only locomotives fitted with vigilance control system are approved to operate outside shunting yards.									
(e) These locomotives and freight vehicles when loaded to axle loads greater than 22 tonnes are NOT permitted to use Berry Down Siding.									
(f) Omega Tunnels 121.000km - 125.000km have track restrictions, refer to specific notes in this table and notes under individual vehicles in TS TOC 1 Section 10 and 11.									
(g) C44aci(139t) locomotives provisioned between 134t and 139t include 92, 93, 6000, 6020, ACC, CEY, CF, FIE, GWU, MRL, XRN, PHC									
(h) 31, L, LO, LZ locomotives are limited to a maximum speed of 70 km/h through the Omega Tunnels, 121.000km to 125.000km.									
(i) Rolling stock classified with R9 notes not permitted between Dunmore (Shellharbour Junction) and Bomaderry.									
(j) 1100, 92, 93, 6000, 6020, ACC, C, CEY, CF, CM, FIE, GWA, GWU, LDP, RL, LDP10, MRL, PHC, SCT, SSR, TT(134t), TT100 (134t), WH, XRN									
<b>SAFeworking SYSTEMS</b>									
<b>WATERFALL TO BOMADERRY</b>									
Waterfall to Coal Cliff		Rail Vehicle Detection (Bi directional)		Dapto to Albion Park		Rail Vehicle Detection			
Coal Cliff to Scarborough		Rail Vehicle Detection		Albion Park to Dunmore		Rail Vehicle Detection			
Scarborough to Wollongong – WG466D, WG468U		Rail Vehicle Detection (Bi directional)		Dunmore to Bombo		Rail Vehicle Detection			
Austinmer to Bulli		Thirroul Yard area		Bombo to Kiama		Rail Vehicle Detection			
Wollongong (Unanderra North – WG1001, WG1003, WG1005, WG1007) to Unanderra		Rail Vehicle Detection (Bi directional)		Kiama to Berry		Rail Vehicle Detection			
Unanderra to Dapto		Rail Vehicle Detection		Berry to Bomaderry		Rail Vehicle Detection with Axle Counters			
<b>INNER HARBOUR</b>									
Wollongong (WG121D) to Inner Harbour Balloon Loop		Wollongong Yard Area		Unanderra North (WG1003, WG1005) to Inner Harbour Balloon Loop		Wollongong Yard Area			
<b>PORT KEMBLA BRANCH – Wollongong to Port Kembla</b>									
		Rail Vehicle Detection							

## General - Sectional running times and full sectional loads

Version April 2020

The locomotive-load-run times configurations (DOWN loads and UP loads) published in this section are for existing approved paths in the Standard Working Timetable (SWTT). For configurations that are not listed, the train shall run at the discretion of the train controller, based on the following:

- The trailing load does not exceed the sum of individual locomotive full sectional loads, accounting for load reductions specified in (TS TOC.1 Section 2.11 and 2.12)
- There is capacity on the network (based on the live status and the SWTT/DWTT) for the train controller to allocate additional times for the train if longer journey or sectional running times, or both are foreseen.
- The operator operates to the assigned schedule or under the direction of the train controller to ensure the train's arrival at critical junctions or destinations does not cause train control conflicts to the network.

The sectional running times published are based on RailNet Running Time Profiles (simulations). Train consists (locomotive and trailing loads) used in the simulations are based on the length limits in the train operating length diagram in TS TOC 1 (Section 1.11) with no speed restrictions applied.

Any planned and timetabled sectional running times used in ad hoc paths, Daily Working Timetable, and Standard Working Timetable have additional time added to the published running times (for example recovery time), which should be accounted for by the train controller / planner / programmer as appropriate.

## DOWN loads

Version December 2020

SECTIONS	LOCOMOTIVE CLASS = L	LOAD – TONNES				TRAIN DATA		
		SINGLE	DOUBLE	TRIPLE	QUAD	VEHICLE CLASS	SECT RUN TIMES	NOTES
1 SYDNEY METROP – UNANDERRA	L2	--	--	2700	--	ABC	A1	%
2 SYDNEY METROP – UNANDERRA	AC6	--	--	2700	--	ABC	A1	%
3 SYDNEY METROP – BOMADERRY	L2/L3/L4	--	606	--	--	ABC	C1	
4 SYDNEY METROP – BOMADERRY	L4/L5 + L2	--	606	--	--	ABC	C1	
5 SYDNEY METROP – BOMBO	L13	--	--	500	--	ABC	C1	1
6 SYDNEY METROP – PT KEMBLA (3)	L3/L4	--	606	--	--	ABC	C1	
7 SYDNEY METROP – PT KEMBLA (3)	#AC6 + #L2	--	2750	--	--	ABC	C2	#C44ACi & NR only
8 SYDNEY METROP – PT KEMBLA (3)	AC6 + L2	--	2410	--	--	ABC	C2	b
9 SYDNEY METROP – PT KEMBLA (3)	#AC6 + 2 X #L2	--	--	4050	--	ABC	C2	#C44ACi & NR only
10 SYDNEY METROP – PT KEMBLA (3)	AC6 + 2 X L2	--	--	3530	--	ABC	C2	b
11 SYDNEY METROP – PT KEMBLA (3)	2 X #AC6 + #L2	--	--	4200	--	ABC	C2	#C44ACi & NR only
12 SYDNEY METROP – PT KEMBLA (3)	2 X AC6 + L2	--	--	3700	--	ABC	C2	b
13 SYDNEY METROP – PT KEMBLA (3)	L2	1300	2600	--	--	ABCE	C2	2
14 SYDNEY METROP – PT KEMBLA (3)	L3/L4	1131	2262	3393	4524	ABC	C2	2
15 SYDNEY METROP – BOMADERRY	AC6	1500	3000	4600*	--	ABC	C2	*
16 SYDNEY METROP – BOMADERRY	L3/L4	1131	2262	3393	4524	ABCE	C2/C3	4
17 SYDNEY METROP – BOMADERRY	L5	1056	2112	3168	4224	ABCE	C2/C3	4
18 SYDNEY METROP – BOMADERRY	L6	926	1852	2778	3704	ABCE	C2/C3	4
19 SYDNEY METROP – BOMADERRY	L7	909	1818	2727	3636	ABCE	C2	
20 SYDNEY METROP – BOMADERRY	L8	875	1750	2625	3500	ABCE	C2	
21 SYDNEY METROP – BOMADERRY	L9	750	1500	2250	3000	ABCE	C2	
22 SYDNEY METROP – BOMADERRY	L10	805	1610	--	--	ABCE	C2	
23 SYDNEY METROP – BOMADERRY	L11	660	1320	1980	2640	ABCE	C2	
24 SYDNEY METROP – BOMADERRY	L12	615	1230	--	--	ABCE	C2	
25 PT KEMBLA – BOMADERRY	L3/L4	1200	2400	3600	--	ABC	C4	2
26 UNANDERRA – BOMADERRY	L3/L4	1131	2262	3393	4254	ABC	C2	

Notes:

1. Empty ballast train.
  2. Includes Inner Harbour.
  3. Includes Unanderra.
  4. C3 schedules are only for the conveying of wagons with speed restrictions applied between 121.000 km and 125.000 km (Omega Tunnels) due to track restrictions.
- % Trains conveying D classification vehicles to run to C Schedule without loss of time.  
 b The Ac6 locomotive shall be a C44ACi or GT46C-ACe type AC locomotive and the L2 locomotive can be NR or AN class.  
 \* Total trailing load limited to 4500t only if consist contains any SDA1 type AC locomotives.  
 # A full listing of approved AC6 locomotives (United Group Ltd – C44ACi, Downer EDI Rail – GT46C-ACe, and CRRC Ziyang – SDA1) is summarised under Table 8 Approved locomotives grouped into load categories – locomotive type AC in TS TOC 1.



## UP loads

Version December 2020

SECTIONS	LOCOMOTIVE CLASS = L	LOAD – TONNES				TRAIN DATA		
		SINGLE	DOUBLE	TRIPLE	QUAD	% VEHICLE CLASS	SECT RUN TIMES	NOTES
1 UNANDERRA – SYDNEY METROP	L2	--	--	2700	--	ABC	A1	%
2 UNANDERRA – SYDNEY METROP	AC6	--	--	2700	--	ABC	A1	%
3 BOMADERRY- SYDNEY METROP	L3/L4	750	1500	2250	--	ABC	C1	
4 BOMADERRY- SYDNEY METROP	L3/L4	1140	2280	3420	4560	ABCE	C2	
5 BOMADERRY- SYDNEY METROP	L6	1062	2124	3186	4248	ABCE	C3	
6 BOMADERRY- SYDNEY METROP	L7	1040	2080	3120	4160	ABCE	C3	
7 BOMADERRY- SYDNEY METROP	L8	1002	2004	3006	4008	ABCE	C3	
8 BOMADERRY- SYDNEY METROP	L9	860	1720	2580	3440	ABCE	C3	
9 BOMADERRY- SYDNEY METROP	L11	759	1518	2277	3036	ABCE	C3	
10 BOMADERRY- SYDNEY METROP	L12	708	1416	2124	2832	ABCE	C3	
11 DUNMORE – SYDNEY METROP	L2	--	3000	--	--	ABCEF	C3	
12 DUNMORE – SYDNEY METROP	L2/L3/L4	1400	2800	--	--	ABCE	C3	
13 DUNMORE – SYDNEY METROP	L4/L5 + L2	--	2760	--	--	ABCE	C3	
14 DUNMORE – SYDNEY METROP	L5	--	2780	--	--	ABCE	C3	2
15 PT KEMBLA –SYDNEY METROP	3 X L2 + AC6	--	--	5300	ABC	C3	b	
16 PT KEMBLA –SYDNEY METROP	L2 + L3/L4	--	2800	--	--	ABC	C3	
17 PT KEMBLA –SYDNEY METROP (3)	L10	805	1610	--	--	ABCE	C3	1
18 PT KEMBLA –SYDNEY METROP (3)	L2	2230	4460	6690	--	ABC	C4	1
19 PT KEMBLA –SYDNEY METROP (3)	AC6	2623	5246	7869	--	ABC	C4	1
20 PT KEMBLA –SYDNEY METROP (3)	AC6 + L2	--	4200	--	--	ABC	C4	b
21 PT KEMBLA –SYDNEY METROP (3)	AC6 + 2 X L2	--	--	6150	--	ABC	C4	b
22 PT KEMBLA –SYDNEY METROP (3)	2 X AC6 + L2	--	--	6450	--	ABC	C4	b
23 PT KEMBLA –SYDNEY METROP	L3/L4	2000	4000	6000	--	ABC	C5	1
24 PT KEMBLA –SYDNEY METROP	L5	1850	3700	5550	--	ABC	C5	1

Notes:

- 1 Includes Inner Harbour.
- 2 Tested and approved double unit load.
- 3 Includes Unanderra.
- % Trains conveying D classification vehicles to run to C Schedule without loss of time.
- b The AC6 locomotive shall be a C44ACi or GT46C-ACe type AC locomotive and the L2 locomotive can be NR or AN class. A full listing of approved AC6 locomotives (United Group Ltd – C44ACi, Downer EDI Rail – GT46C-ACe and CRRC Ziyang – SDA1) is summarised under Table 8 Approved locomotives grouped into load categories – locomotive type AC in TS TOC 1.

# UP – sectional running times and full sectional loads

Version April 2021 (5.14)

Superseded by TS TOC 2 v22.0, 24/09/2021

STATION	FULL SECTIONAL LOADS																		GRADE			
	#SECTIONAL RUNNING TIMES (INDICATIVE)											LOCOMOTIVE CATEGORIES = L										
	%A1	C1	C2	C3	C4	C5	Loco	AC6	2	3	4	5	6	7	8	9	10	11	12	13		
BOMADERRY	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88		
BERRY	--	11:54	13:06	12:24	--	--	10:00	2766	--	2227	2104	1976	1743	1699	1650	1422	1372	1259	1175	820	1:80	
GERRINGONG	--	--	--	--	--	--	--	2623	--	2111	1995	1872	1651	1610	1563	1346	1299	1191	1112	776	1:76	
KIAMA	--	20:54	21:24	21:54	--	--	17:36	2477	--	1992	1882	1766	1557	1519	1473	1268	1224	1122	1047	731	1:70	
BOMBO	--	03:42	03:42	03:42	--	--	02:06	5283	--	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG	
DUNMORE	--	07:24	07:48	08:12	--	--	06:36	1846	1607	1479	1396	1307	1149	1125	1085	933	902	823	768	536	1:50	
SHELLHARBOUR JCT	--	01:18	01:18	01:24	--	--	01:06	1710	1488	1400	1400	1208	1062	1040	1002	860	833	759	708	494	1:46	
ALBION PARK	--	06:00	06:18	06:48	--	--	05:00	1710	1488	1400	1400	1208	1062	1040	1002	860	833	759	708	494	1:46	
DAPTO	--	08:18	08:36	09:00	--	--	06:00	1846	1607	1479	1400	1307	1149	1125	1085	933	902	823	768	536	1:50	
WONGAWILLI JCT	--	--	--	--	--	--	--	1846	1607	1479	1400	1307	1149	1125	1085	933	902	823	768	536	1:50	
UNANDERRA	--	05:24	05:30	05:30	--	--	04:30	1846	1607	1479	1400	1307	1149	1125	1085	933	902	823	768	536	1:50	
UNANDERRA NTH	*02:48	02:54	02:54	03:00	--	--	01:48	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	Level	
CONISTON	02:24	02:06	02:12	02:18	--	--	02:00	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	Level	
WOLLONGONG	01:36	01:36	01:36	01:36	01:36	01:54	01:12	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	Level	
CORRIMAL	04:42	04:54	05:00	05:06	05:06	05:18	04:30	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984	1:100	
THIRROUL	05:48	05:54	05:54	06:00	06:18	06:30	05:18	2623	2289	2111	1995	1872	1651	1610	1563	1346	1299	1191	1112	776	1:75	
SCARBOROUGH	07:54	08:24	10:06	11:48	12:42	16:00	06:36	2623	2289	2111	1995	1872	1651	1610	1563	1346	1299	1191	1112	776	1:75	
COALCLIFF	10:18	04:00	04:18	04:36	04:48	05:24	04:48	3775	3300	3047	2882	2711	2395	2330	2271	1959	1887	1737	1621	1131	1:120	
OTFORD	21:18	08:42	10:12	11:24	12:00	14:54	07:36	2623	2289	2111	1995	1872	1651	1610	1563	1346	1299	1191	1112	776	1:75	
METROP. COLL JCT	11:12	05:30	05:54	06:24	06:36	07:36	05:06	2623	2289	2111	1995	1872	1651	1610	1563	1346	1299	1191	1112	776	1:75	
HELENSBURGH	07:00	02:12	03:00	03:48	04:06	05:42	01:48	2623	2289	2111	1995	1872	1651	1610	1563	1346	1299	1191	1112	776	1:75	
WATERFALL	09:24	10:24	14:00	17:06	18:36	24:54	08:06	2766	2414	2227	2104	1976	1743	1699	1650	1422	1372	1259	1175	820	1:80	
SUTHERLAND	12:48	13:00	13:06	13:42	13:54	14:36	15:00	3775	3300	3047	2882	2711	2395	2330	2271	1959	1887	1737	1621	1131	1:120	
MORTDALE	07:24	07:30	07:48	08:12	08:18	09:00	08:24	2766	2414	2227	2104	1976	1743	1699	1650	1422	1372	1259	1175	820	1:80	
HURSTVILLE	02:18	02:42	03:18	03:48	04:12	05:24	02:00	2623	2289	2111	1995	1872	1651	1610	1563	1346	1299	1191	1112	776	1:75	
WOLLI CREEK JCT	07:36	07:36	07:54	08:00	08:12	08:30	09:36	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984	1:100	
MEEKS RD JCT	02:12	02:00	02:12	02:00	02:12	02:12	01:54	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984	1:100	
MARRICKVILLE JCT	03:48	03:54	03:48	03:54	03:48	03:48	02:24	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984	1:100	
Port Kembla – Coniston																						
PT KEMBLA YARD	--	--	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88			
PT KEMBLA NTH	--	--	00:48	00:48	00:48	00:48	00:30	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984	1:100	
CRINGILA	--	--	02:24	02:24	02:24	02:24	02:00	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	DG	
LYSAGHTS	--	--	02:12	02:18	02:12	02:18	01:42	5283	4624	4274	4044	3809	3369	3274	3199	2761	2658	2452	2288	1600	Level	
CONISTON	--	--	02:30	02:30	02:36	02:48	02:36	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984	1:100	
Inner Harbour – Coniston																						
INNER HARBOUR	--	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88			
CONISTON	--	03:18	--	03:00	03:18	03:30	03:24	3039	2654	2449	2315	2175	1920	1870	1818	1567	1511	1388	1295	904	1:90	

Illawarra Division pages

© State of NSW through Transport for NSW 2021

# Wollongong local area – loads

<b>WOLLONGONG - PORT KEMBLA - INNER HARBOUR - UNANDERRA -</b>														
<b>Local area Full sectional Loads</b>														
<b>LOCOMOTIVE CATEGORY</b>														
<b>FULL LOAD TABLE</b>	1	AC6	L2	L3	L4	L5	L6	L7	L8	L9	L10	L11	L12	L13
1	3775	3300	3047	2882	2711	2395	2330	2271	1959	1887	1737	1621	1131	
2	3542	3096	2858	2702	2541	2245	2185	2128	1835	1768	1627	1518	1059	
3	3297	2881	2659	2514	2363	2086	2032	1975	1704	1643	1511	1410	984	
4	3039	2654	2449	2315	2175	1920	1870	1818	1567	1511	1388	1295	904	
5	2011	1752	1613	1523	1427	1256	1228	1186	1020	986	901	841	587	
6	1846	1607	1479	1396	1307	1149	1125	1085	933	902	823	768	536	

Refer to table for loads. Where only one figure is shown e.g. 1 this represents the Down and Up load. Where two figures are shown the first figure represents the Down load and the second figure represents the Up load e.g. 3/5. This table does not give the authority for all classes of locomotives to run on all sections of line. Refer to MAXIMUM SPEED OF LOCOMOTIVES AND ROLLING STOCK table for authority to run on each section

# Unanderra to Inner Hbr  
\* Inner Hbr to Unanderra

To Sydney  
Wollongong

To Moss Vale  
To Bomaderry

Coniston  
Unanderra  
Lysagths  
Pt Kembla North  
Pt Kembla

Inner Harbour

KEY:

- Down full sectional load running times
- Up full sectional load running times
- Loco running times
- Arrow indicates Down direction (for this map only)
- Running times indicated between dots
- Passing times. (Square box)
- Add one minute to next section when starting, and an additional minute into terminating stations running time.
- Arrival/departure times. (Rounded box)
- Starting and terminating running time included, i.e. additional time for starting and terminating included. Black dot indicates location.
- Non electrified lines

To Sydney  
Wollongong

2/2/2

Coniston  
5/7/5  
3/3/2  
3/2/2  
5/5/4  
4/3/3  
Unanderra Nth Jun  
Unanderra

Inner Harbour  
11/8/5  
7" empty trains  
Lysagths  
Cringila  
3/3/2  
Pt Kembla Nth  
4/4/3  
Pt Kembla Yard  
3/3/3  
Pt Kembla

To Moss Vale  
To Bomaderry

KEY:

- Down full sectional load running times
- Up full sectional load running times
- Loco running times
- Arrow indicates Down direction (for this map only)
- Running times indicated between dots
- Passing times. (Square box)
- Add one minute to next section when starting, and an additional minute into terminating stations running time.
- Arrival/departure times. (Rounded box)
- Starting and terminating running time included, i.e. additional time for starting and terminating included. Black dot indicates location.
- Non electrified lines

August 2012

## Location of speed signs

Version April 2021

### Waterfall to Thirroul

LOCATION	KILO-METRE	DOWN MAIN						UP MAIN					
		▼ DOWN SIGNS ▼			▲ UP SIGNS ▲			▲ UP SIGNS ▲			▼ DOWN SIGNS ▼		
		GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH
WATERFALL	38.741												
	38.783	..	..	..	..	..	..	45	45	45			Up Refuge
	38.835	..	..	..	..	..	..	57B Points Up Refuge		X50	..	..	
	38.910	..	..	..	..	..	..	X50		57B points Up Refuge			
	39.174	..	..	..	..	..	..	50	55	60	60	75	80
	39.234	60	75	80	55	55	60	..	..	..	..	..	
	40.605	60	60	65	60	75	80	60	75	80	60	60	65
	40.930	55	55	55	60	60	65	..	..	..	55	55	55
	40.980	..	..	..	..	..	..	60	60	65	..	..	
	41.602	..	..	..	..	..	..	55	55	55	..	..	
	41.656	60	60	65	55	55	55	..	..	..	60	60	65
	45.718	50	50	55	60	60	65	60	60	65	50	50	55
HELENSBURGH	46.384												
	46.549	..	..	..	..	..	..	50	50	55	60	60	60
	46.571	60	60	60	50	50	55	..	..	..	..	..	
Metropolitan Coll. Jct	48.947												
	49.977	55	55	60	60	60	60	60	60	60	55	55	60
	50.578	60	80	85	55	55	60	55	55	60	60	80	85
	51.832	..	..	..	60	80	85	60	80	85	50	50	55
	51.886	50	50	55	..	..	..	..	..	..	..	..	
	52.520	..	..	..	50	50	55	..	..	..	..	..	
OTFORD	52.639												
	52.932	60	60	65	55	55	55	..	..	..	..	..	
	52.967	..	..	..	..	..	..	50	50	55	60	60	65
	54.197	60	70	70	..	..	..	..	..	..	60	70	70
	54.199	..	..	..	60	60	65	60	60	65	..	..	
	55.426	60	60	60	60	70	70	60	70	70	60	60	60
STANWELL PARK	55.950												
Stanwell Park Viaduct	56.725	40	60	60	60	60	60	60	60	60	40	60	60
Stanwell Park Viaduct	56.877	60	60	60	40	60	60	40	60	60	60	60	60
	58.508	60	70	75	60	60	60	60	60	60	60	75	80
	58.870	50	70	75	..	..	..	..	..	..	50	75	80
COALCLIFF	59.273												
	59.829	X40	358 Points			..	..	..	..	..	..	..	
	59.870	..	..	..	60	70	75	..	..	..	..	..	
	59.919	..	..	..	..	..	..	60	75	80	..	..	
	59.948	^50	^50	^50	^Single line section common board	^50	^50	^50	^50	^50	^50	^50	^50
	60.310	^Single line section common board	^50	^50	^50	^50	^50	^50	^50	^50	..	..	
	60.338	^50	^70	^70	..	..	..	^Single line section common board	^50	^70	^70	^70	
	61.337	^Single line section common board	^50	^80	^80	^50	^80	^80	^80	^80	..	..	
	61.360	^50	^50	^50	..	..	..	^Single line section common board	^50	^50	^50	^50	
	61.797	X50	351 Points			..	..	..	..	..	..	..	
	61.868	..	..	..	50	50	50	..	..	..	..	..	
	61.898	75	75	80	..	..	..	..	..	..	..	..	
	61.898	..	..	..	X50	351 Points			..	..	..	..	
	61.916	..	..	..	..	..	..	50	50	50	75	75	80
SCARBOROUGH	62.529												
	62.690	..	..	..	50	70	70	65	70	70	..	..	
	63.805	65	65	70	..	..	..	..	..	..	65	65	70
	63.806	..	..	..	65	75	80	65	75	80	..	..	
WOMBARRA	64.335												
	65.735	70	80	85	65	65	70	65	65	70	70	95	100
COLEDALE	66.233												
	67.109	70	70	75	..	..	..	..	..	..	70	70	75
	67.176	..	..	..	70	80	85	70	95	100	..	..	

	DOWN MAIN							UP MAIN					
	67.496	100	115	115	70	70	75	70	70	75	100	115	115
AUSTINMER	68.366	60	85	85	..	..	..	..	..	..	..	..	..
	68.585												
THIRROUL	68.706	100	115	115	..	..	..	..	..	..	..	..	..
	68.985	..	..	..	100	115	115	..	..	..	..	..	..
	69.283	..	..	..	50	90	100	..	..	..	..	..	..
	70.237												

## Thirroul to TfNSW Boundary (Unanderra – Moss Vale Line)

	DOWN MAIN							UP MAIN					
KILO-LOCATION	▼ DOWN SIGNS ▼			▲ UP SIGNS ▲			▲ UP SIGNS ▲			▼ DOWN SIGNS ▼			
METRAGE	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH	
70.359	70	70	75	..	..	..	..	..	..	70	70	75	
70.625	..	..	..	100	115	115	100	100	100	..	..	..	
70.982	80	80	80	70	70	75	60	70	75	80	80	80	
71.630	..	..	..	80	80	90	80	80	90	..	..	..	
BULLI	72.151												
	72.421	80	80	80	80	80	80	80	80	80	80	80	80
	73.076	75	75	85	60	85	90	60	85	85	75	75	85
	73.610	85	100	100	75	75	85	75	75	85	95	100	100
	73.899	..	..	..	..	..	..	90	90	90	..	..	..
WOONONA	73.993												
	75.472	85	90	95	85	100	100	..	..	..	..	..	..
BELLAMBI	75.547												
	75.630	90	95	95	85	90	95	..	..	..	..	..	..
	76.859	..	..	..	..	..	..	..	..	..	90	100	100
CORRIMAL	76.989												
	77.378	..	..	..	90	100	100	95	100	100	..	..	..
TOWRADGI	78.021												
	78.184	90	90	90	..	..	..	..	..	..	90	90	90
	78.452	..	..	..	90	95	95	95	95	95	..	..	..
	78.720	..	..	..	80	95	95	80	95	95	..	..	..
FAIRYMEADOW	79.358												
NORTH	81.320												
WOLLONGONG													
	81.438	75	90	90	..	..	..	..	..	..	75	90	90
	82.490	60	90	90	..	..	..	..	..	..	60	90	90
	82.782	..	..	..	..	..	..	95	95	95	..	..	..
	82.784	..	..	..	95	95	95	..	..	..	..	..	..
WOLLONGONG CITY	82.919												
	83.446	..	..	..	70	90	90	70	90	90	..	..	..
	83.801	..	..	..	60	90	90	60	90	90	60	65	70
CONISTON	84.097												
	84.190	X25	206 Points								X25	205 Points	
	84.190												
	84.200	60	65	65				..	..	..	..	..	..
	84.298	X25	204 Points										
	84.368	..	..	..	..	..	..	50	65	65	..	..	..
	84.382	..	..	..	..	..	..	X25	204 Points			..	..
	84.382	..	..	..	..	..	..	..	..	..	X25	203 Points	
	84.431	..	..	..	..	..	..	X25	203 Points				
	84.488	50	65	65	..	..	..	..	..	..			
	85.199	..	..	..	..	..	..	65	65	65			
	85.199	X50	1101 Points						..	..			
	85.333	..	..	..	..	..	..	..	..	..	X50	1103 Points	
	85.335	..	..	..	..	..	..	X50	1101 Points			..	..
	85.435	..	..	..	X50	1103 Points			..	..	..	..	..
	85.478	100	100	100	..	..	..	..	..	..	100	100	100
Unanderra North Jct	86.541												

DOWN MAIN						UP MAIN					
87.727	..	..	..	100	100	100	100	100	100	..	..
87.727				..	..	..	..	..	..	X50	1105 Points
87.850	X50		1106 Points	..	..	..	..	..	..	..	..
87.850	..	..	..	X50	1105 Points	..	..	..	..	..	..
UNANDERRA	88.273	..	..	..	..	..	..	..	..	..	..
88.390	..	..	..	80	85	90	..	..	..	..	..
88.403	..	..	..	..	..	..	80	..	90	..	..
88.845	..	..	..	..	..	..	..	..	..	60	..
88.853	60	..	60	..	..	..	..	..	..	..	..
90.920	..	..	..	..	..	..	..	..	..	40	..
90.928	40	..	40	..	..	..	..	..	..	..	..
90.997	..	..	..	50	..	60	50	..	60	..	..
TfNSW BOUNDARY	91.080										

## Unanderra to Bomaderry

KILO	DOWN			UP			KILO	DOWN			UP		
METRAGE	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH	METRAGE	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH
87.924	..	..	..	X50	1106 Points		114.758	75	75	80	..	..	..
87.924	50	50	50				114.806	..	..	..	75	90	95
88.273	UNANDERRA						116.166	50	50	60	..	..	..
88.661	100	100	100	..	..	..	116.209	..	..	..	75	75	80
88.743	X50	1115 Points	..	..	..		116.816	60	80	85	50	50	60
88.870	..	..	..	X50	1115 Points		117.160	40	80	85	60	80	80
89.174	..	..	..	80	85	90	117.292	60	80	85	40	80	80
91.586	KEMBLA GRANGE						117.551	BOMBO					
93.151	85	100	100	..	..	..	117.940	..	..	..	60	80	80
93.618	100	100	100	..	..	..	117.985	60	60	60	..	..	..
94.500	..	..	..	100	100	100	118.946	25	25	25	..	..	..
95.047	DAPTO						118.955	..	..	..	60	60	60
							119.160	KIAMA					
95.300	..	..	..	90	100	100							
95.862	80	80	80	..	..	..	119.430	..	..	..	25	..	25
96.813	..	..	..	100	100	100	119.473	100	..	100	..	..	..
96.873	100	115	140	..	..	..	123.210	45	..	45	75	..	95
97.847	..	..	..	80	80	80	123.800	..	..	..	45	..	45
101.804	80	100	100	..	..	..	123.814	60	..	60	..	..	..
102.203	90	100	100	..	..	..	124.360	100	..	100	60	..	60
102.857	90	90	100	..	..	..	125.696	90	..	90	..	..	..
102.932	..	..	..	100	115	140	126.434	..	..	..	100	..	100
103.341	ALBION PARK						126.457	100	..	125			
							127.221	..	..	..	90	..	90
103.746	100	100	100	..	..	..	128.560	GERRINGONG					
103.755	..	..	..	40	40	40	129.171	100	..	100	100	..	125
105.194	100	100	110	..	..	..	131.620	100	..	140	..	..	..
105.522	OAK FLATS						131.997	..	..	..	100	..	100
							134.877	100	..	100	100	..	140
106.085	..	..	..	100	100	100	139.063	80	..	80	100	..	100
107.930	..	..	..	100	100	110	139.473	..	..	..	80	..	80
107.940	80	80	85	..	..	..	140.629	..	..	..	90	..	90
108.750	X60	51A Points	..	..	..		140.760	@40					
108.790	..	..	..	80	80	85	140.844	BERRY					
108.832	100	100	100	..	..	..	141.200				@50		
108.887	SHELLHARBOUR JUNCTION						141.250	90	..	95	..	..	..
108.890	60	60	60	On Loop			141.720	..	..	..	@50	..	80
108.890	On Loop			X60	51B Points		142.272	100	..	100	90	..	95
110.657	DUNMORE (NOT IN SERVICE)						145.886	90	..	90	100	..	100
110.860	On Loop			60	60	60	146.436	100	..	100	90	..	90
110.950	52B Points			X35	..	..	150.540	100	..	140	..	..	..
111.668	80	80	80	..	..	..	151.000	..	..	..	100	..	100
112.078	..	..	..	100	100	100	152.290	80	..	80	..	..	..
112.270	75	75	80	..	..	..	153.169	50	..	50	100	..	140
112.776	75	90	95	..	..	..	153.348	BOMADERRY					
113.040	..	..	..	75	75	75							
113.372	MINNAMURRA												

@ Level crossing sign NGE216

## Coniston to Port Kembla

KILO	DOWN			UP			KILO	DOWN			UP			
METRAGE	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH	METRAGE	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH	
84.097	CONISTON						86.422	X45	195A Points			Down Sign Up Main		
84.190	X25	206 Points			..	..	86.543	Up Sign Down Main			X45	195B Points		
84.190	X25	205 Points			Down Sign Up Main			87.238	..	..	..	55	75	75
84.200	60	65	65	On Main Line			87.650	CRINGILA						
84.298	X25	204 Points			..	..	88.280	55	60	60	..	..	..	..
84.382	..	..	..	X25	204 Points			88.583	..	..	..	45	65	65
84.382	X25	203 Points			Down Sign Up Main			88.667	..	..	..	X30	186 Points	
85.045	45	75	75	55	65	65	88.771	PORT KEMBLA NORTH						
86.267	LYSAGHTS						89.697	..	..	..	45	60	60	
86.385	55	80	80	..	..	..	89.950	25	25	25	..	..	..	
86.386	..	..	..	X45	197 Points			90.015	..	..	..	25	25	25
							90.239	PORT KEMBLA						

## Unanderra North Junction to Inner Harbour (via Flyover)

KILO-	DOWN SOUTH FORK						UP SOUTH FORK					
	▼ DOWN SIGNS▼			▲ UP SIGNS▲			▲ UP SIGNS▲			▼ DOWN SIGNS▼		
METRAGE	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH
85.133	100	..	..	40	..	..	40	..	..	100	..	..
85.318		X25		1102 Points								

## Unanderra North Junction to Lysaghts

KILO	DOWN			UP			
METRAGE	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH	
#85.318	# Illawarra Line Km			X25	1102 Points		
+84.843	X25	1102 Points			+ Triangle Loop Line		
+84.840	50	..	..		+ Triangle Loop Line		
+84.860		+ Triangle Loop Line			30	..	..
+86.282		+ Triangle Loop Line			50	..	
+86.321	X45	197 Points			+ Triangle Loop Line		
86.386	Port Kembla Line			X45	197 Points		

+ Kilometrage measured back from Port Kembla Line

## Coniston to Inner Harbour

KILO	DOWN			UP			
METRAGE	GENERAL	MEDIUM	HIGH	GENERAL	MEDIUM	HIGH	
84.097	CONISTON						
84.190	#X25	206 Points			# On Main Line		
84.190	X25	205 Points			Down Sign Up Main		
84.296		Up Sign Up Fork			X25	206 Points	
84.296		Up Sign Down Fork			X25	205 Points	

## Station data

Station	Kilo – metrage	Signal Box Status	Hours of Signal Box	Facilities
Waterfall	38.627	A	Always	P,WC
Helensburgh	46.384	C	Controlled from Wollongong Signal Box	P,LP
Metropolitan Coll Jct	48.947	C	Controlled from Wollongong Signal Box	L
Metropolitan Colliery	*50.221	C	* On Branch	PS
Otford	52.639	C	Controlled from Wollongong Signal Box	P,LP
Stanwell Park	55.950			P
Coalcliff	59.273	C	Controlled from Wollongong Signal Box	P,LP
Scarborough	62.529	C	Controlled from Wollongong Signal Box	P,LP
Wombarra	64.335			P
Coledale	66.233			P
Austinmer	68.585	C	Controlled from Wollongong Signal Box	P
Thirroul	70.237	C	Controlled from Wollongong Signal Box	P,LP
Bulli	72.151	C	Controlled from Wollongong Signal Box	P
Woonona	73.993			P
Bellambi	75.547			P
Corrimal	76.989	C	Controlled from Wollongong Signal Box	P
Towradgi	78.021			P
Fairy Meadow	79.358			P
North Wollongong	81.320			P
Wollongong	82.919	C	Controlled from Wollongong Signal Box	P
Wollongong Sig Box	83.250	A	Always	
Coniston	84.097	C	Controlled from Wollongong Signal Box	P,LP
Unanderra Nth Jct	86.541	C	Controlled from Wollongong Signal Box	L
Unanderra	88.273	C	Controlled from Wollongong Signal Box	P,LP
Kembla Grange	91.586			P
Tubemakers Siding				PS
Dapto	95.047	C	Controlled from Wollongong Signal Box	P,LP
Albion Park	103.341	C	Controlled from Wollongong Signal Box	P
Oak Flats	105.522			P
Shellharbour Jct	108.887			P
Dunmore (not in service)	110.657	C	Controlled from Wollongong Signal Box	P
Quarry Siding	*112.060		* On Branch	PS
Minnamurra	113.372			P
Bombo Quarry Siding	*117.212		* On Branch	PS
Bombo	117.551	C	Controlled from Wollongong Signal Box	P
Kiama	119.160	P	Controlled from Wollongong Signal Box	P,TT
Gerringong	128.560			P
Berry	140.844	P	Monday to Friday: 0430 – 2000 Saturday, Sunday, and Public Holidays: 0510 – 2105	P
Bomaderry	153.348	A	Always	P,TT
Mill Siding	*155.913		* On Branch	PS
<b>Port Kembla Branch</b>				
Allans Creek	86.267	C	Controlled from Wollongong Signal Box	L
Cringila	87.650	C	Controlled from Wollongong Signal Box	P
Port Kembla North	88.771	C	Controlled from Wollongong Signal Box	P
Port Kembla	90.239	C	Controlled from Wollongong Signal Box	P
<b>Inner Harbour Branch</b>				
Inner Harbour	84.488	C	Controlled from Wollongong Signal Box	G, L

## Emergency working or diversion of container trains Tempe – Unanderra (en route to and from Moss Vale)

**The operation of container trains, on the UP and DOWN tracks between Unanderra and Tempe, (en route to and from Moss Vale), shall comply with the following special working conditions.**

These conditions shall apply to all container trains because of the potential for any vehicle in the consist to be loaded to the maximum allowable height above rail of 4050 mm, as published in the *TOC manual General Instructions, Section 5 Loading Restrictions* covering vehicles subject to Note R10.

As the UP and DOWN tracks between Tempe and Unanderra are presently only authorised for container traffic operating to a maximum height of 3916 mm above rail, all trains conveying container traffic shall operate as an out of gauge train. Note that this gauge infringement is in height only and does not affect passing traffic.

Therefore, the following operating conditions shall apply:

- A maximum speed limit of **15 km/h** is imposed on all tunnels between Unanderra and Tempe.
- The speed limit shall apply for the full length of the train (excluding locomotives).
- Train to run to the fastest schedule applicable to the class of rolling stock ( for example Schedule A1 for A class rolling stock) shown in *DOWN – sectional running times and full sectional loads* (page 52) *UP – sectional running times and full sectional loads* (page 54).

Train Control is to ensure that crews operating the relevant container trains on this route are aware of the above conditions of operation.

## Loads and conditions between Unanderra and 91.080 km (Unanderra – Moss Vale line)

*Version December 2020*

### DOWN loads

SECTIONS	LOCOMOTIVE CLASS = L	LOAD - TONNES				TRAIN DATA		
		SINGLE	DOUBLE	TRIPLE	QUAD	VEHICLE CLASS	SECT RUN TIMES	NOTES
1 UNANDERRA - (#91.080 km)	AC6	1130	2260	3390	4520	ABCDEF	%	
2 UNANDERRA - (#91.080 km)	AC6 + L2	--	1750	--	--	ABCDEF	%	b
3 UNANDERRA - (#91.080 km)	AC6 + 2 x L2	--	--	2529	--	ABCDEF	%	b
4 UNANDERRA - (#91.080 km)	2 x AC6 + L2	--	--	2727	--	ABCDEF	%	b
5 UNANDERRA - (#91.080 km)	L3/L4	500	1000	1500	--	ABCDEF	%	1
6 UNANDERRA - (#91.080 km)	L2	900	1800	2700	3600	ABCDEF	%	
7 UNANDERRA - (#91.080 km)	L3/L4	750	1500	2250	3000	ABCDEF	%	
8 UNANDERRA - (#91.080 km)	L5	690	1380	2070	2760	ABCDEF	%	
9 UNANDERRA - (#91.080 km)	L6	551	1102	1653	2204	ABCDEF	%	
10 UNANDERRA - (#91.080 km)	L7	543	1086	1629	2172	ABCDEF	%	
11 UNANDERRA - (#91.080 km)	L8	517	1034	1551	2068	ABCDEF	%	
12 UNANDERRA - (#91.080 km)	L9	485	970	1455	1940	ABCDEF	%	
13 UNANDERRA - (#91.080 km)	L10	430	860	1290	1720	ABCDEF	%	
14 UNANDERRA - (#91.080 km)	L11	388	776	1164	1552	ABCDEF	%	
15 UNANDERRA - (#91.080 km)	L12	362	724	1086	1448	ABCDEF	%	

1. Empty wheat / coal vehicles. ARTC Unanderra to Dombarton running times (19 minutes) to apply.

- # 91.080 km TfNSW/ARTC boundary.  
 % ARTC Unanderra to Dombarton running times (26 minutes) to apply.  
 b The AC6 locomotive shall be a C44ACi or GT46C-ACe type AC locomotive and the L2 locomotive can be NR or AN class. A full listing of approved AC6 locomotives (United Group Ltd – C44ACi, Downer EDI Rail – GT46C-ACe and CRRC Ziyang – SDA1) is summarised under Table 8 Approved locomotives grouped into load categories – locomotive type AC in TS TOC 1.

## DOWN - sectional running times and full sectional loads

	FULL SECTIONAL LOADS														GRADE							
	#SECTIONAL RUNNING TIMES						LOCOMOTIVE CATEGORIES = L															
	1	2	3	4	5	6	Loco	AC6	2	3	4	5	6	7	8	9	10	11	12	13	14	
UNANDERRA	26	26	26	26	26	26	26	26	26	26	26	26	26	26	26	26	26	26	26	26	26	26
ARTC boundary (91.080 km)	%	%	%	%	%	%	%	1133	903	791	745	696	551	543	517	442	430	388	362	253	1:30	

% ARTC Unanderra to Dombarton running times (26 minutes for trains and 17 minutes for locomotive movements) to apply.

## UP loads

SECTIONS	LOCOMOTIVE CLASS = L	LOAD - TONNES				TRAIN DATA		
		SINGLE	DOUBLE	TRIPLE	QUAD	VEHICLE CLASS	SECT RUN TIMES	NOTES
1 (#91.080 km) - UNANDERRA	AC6	--	--	--	--	ABCDEF	%	1, 4
2 (#91.080 km) - UNANDERRA	AC6	--	3600	--	--	ABCDEF	%	2, 4
3 (#91.080 km) - UNANDERRA	AC6	--	--	4600	--	ABCDEF	%	3
4 (#91.080 km) - UNANDERRA	AC6 + L2	--	--	--	--	ABCDEF	%	1, 2, 4, b
5 (#91.080 km) - UNANDERRA	AC6 + 2 x L2	--	--	--	--	ABCDEF	%	1, 2, 4, b
6 (#91.080 km) - UNANDERRA	2 x AC6 + L2	--	--	--	--	ABCDEF	%	1, 2, 4, b
7 (#91.080 km) - UNANDERRA	L2	--	3600	--	--	ABCDEF	%	2, 4
8 (#91.080 km) - UNANDERRA	L2/L3/L4	--	3300	--	--	ABCDEF	%	2, 4
9 (#91.080 km) - UNANDERRA	L4 + L9	--	3300	--	--	ABCDEF	%	2, 4
10 (#91.080 km) - UNANDERRA	L2	2080	2400	--	--	ABCDEF	%	1, 4
11 (#91.080 km) - UNANDERRA	L3/L4	1840	2400	--	--	ABCDEF	%	1, 4
12 (#91.080 km) - UNANDERRA	L5	1872	2400	--	--	ABCDEF	%	1, 4
13 (#91.080 km) - UNANDERRA	L6	1651	2400	--	--	ABCDEF	%	1, 4
14 (#91.080 km) - UNANDERRA	L7	1610	2400	--	--	ABCDEF	%	1, 4
15 (#91.080 km) - UNANDERRA	L8	1563	2400	--	--	ABCDEF	%	1, 4
16 (#91.080 km) - UNANDERRA	L9/L10	1200	2400	--	--	ABCDEF	%	1, 4
17 (#91.080 km) - UNANDERRA	L11	1191	2382	2400	--	ABCDEF	%	1, 4
18 (#91.080 km) - UNANDERRA	L12	1112	2224	2400	--	ABCDEF	%	1, 4
19 (#91.080 km) - UNANDERRA	L13	500	1000	1500	2000	ABCDEF	%	4

Note – published loads may be further restricted with the notes 1 to 4 associated with braking, see UP – 91.080 km to Unanderra – Explanatory notes (page 63)

% ARTC Unanderra to Dombarton running times (22 minutes) to apply

# 91.080 km TfNSW/ARTC boundary.

- b The AC6 locomotive shall be a C44ACi or GT46C-ACe type AC locomotive and the L2 locomotive can be NR or AN class. A full listing of approved AC6 locomotives (United Group Ltd – C44ACi, Downer EDI Rail – GT46C-ACe and CRRC Ziyang – SDA1) is summarised under Table 8 Approved locomotives grouped into load categories – locomotive type AC in TS TOC 1.

## UP - sectional running times and full sectional loads

Although the section between ARTC boundary (91.080km) and Unanderra is downgrade, the ARTC approved full sectional load between Moss Vale and Unanderra shall be applied. In addition the ARTC sectional running times between Dombarton and Unanderra is to be used.

*Note: The running time between Dombarton and Unanderra (ARTC) is 22 minutes*

*Note: The ruling grade between Moss Vale and Unanderra is 1:75*

Further loading restrictions applicable to single pipe trains, two pipe trains and ECP braking trains are explained in Note 1, Note 2 and Note 3 respectively under **UP – 91.080 km to**

**Unanderra – Explanatory notes.** This may result in loads smaller than the ARTC approved full sectional loads for the ruling grade.

## UP – 91.080 km to Unanderra – Explanatory notes

### Note 1 – Single pipe trains:

On steeply falling grades between 91.080 km and Unanderra, loads for single pipe trains are limited due to air brake capacity to a **maximum load of 2400 tonnes**. The combination of loaded and empty vehicles in a train shall not exceed that listed in the table below. For multipack/articulated vehicles, the number of platforms shall be counted instead of vehicles; i.e. an RRAY 5 pack shall count as 5 vehicles.

For trains over 2400 tonnes see section **Operation of Single Pipe Trains in Excess of 2400 tonnes and up to 1500 metres long from Summit Tank to Unanderra** on page 64.

Loaded Vehicles	Maximum empties	Loaded Vehicles	Maximum empties	Loaded Vehicles	Maximum empties
0	45	12	29	24	14
1	43	13	28	25	12
2	42	14	27	26	11
3	41	15	25	27	10
4	39	16	24	28	9
5	38	17	23	29	7
6	37	18	21	30	6
7	36	19	20	31	5
8	34	20	19	32	3
9	33	21	18	33	3
10	32	22	16	34	1
11	30	23	15	35	0

### Note 2 – Two pipe trains:

Two pipe vehicles have a main reservoir that recharges the air brake system. These vehicles listed in the General Instruction Pages, **Section 10 Locomotive and Rolling Stock Data** and are identified by **••** in the Brake Type column.

**The maximum train length of two pipe vehicles on a train is 46 vehicles.** Up to 6 empty or loaded single pipe vehicles may be attached to the **REAR** of a loaded or empty two pipe train. The two pipe portion shall not exceed 40 wagons.

### Note 3 – ECP braked trains:

**The maximum train length of trains operating under ECP brakes is 46 vehicles.** This is the approved load for ECP trains operating from the western coal fields.

### Note 4 – Pressure maintaining brake valves:

Lead locomotives on freight trains operating from 91.080 km to Unanderra should have pressure maintaining brake valves (26L brake equipment or equivalent).

Where the lead locomotive is not fitted with a pressure maintaining brake valve, and the train is to be held stationary on the grade for periods in excess of ten (10) minutes, handbrakes shall be applied in accordance with the requirements in the **General Instructions Pages, Section 3 train Operations, Holding a train stationary on a grade.**

## Conditions of operation of freight trains - Unanderra and 91.080 km (en route to and from Moss Vale)

### Braking requirements – DOWN direction:

- Freight trains with grade control valves are required to have a HP grade inspection carried out on the train.
- Grade control valves are to be set in the **EX position**.

### Braking requirements – UP direction:

- Unless at least 80% of the train mass is fitted with fixed exhaust chokes, freight trains are required to have a HP grade inspection carried out on the train.
- Grade control valves (where fitted) are to be set in the **IP position** at the inspection location or other approved location.
- Dynamic brake shall be used if available.

## Operation of single pipe trains in excess of 2400 tonnes and up to 1500 metres long from Summit Tank to Unanderra

Single pipe trains between **2400 and 4000 tonnes and up to 1500 metres long** may operate from the **ARTC/TfNSW boundary** to Unanderra under mandatory dynamic brake conditions as follows:

- These trains shall have a HP grade Inspection and grade control valves set in 'IP'.
- The minimum allowable vehicle mass for vehicles in the front third of a train shall not be less than 25 tonnes. In the case of multipack vehicles the minimum allowable vehicle mass shall be the gross mass divided by the number of platforms (decks).
- There shall not be any empty platforms (decks).
- Maximum train length 1500 metres plus locomotives.
- Maximum train mass 4000 tonnes plus locomotives.
- Train shall have three (3) locomotives at the front of the train and up to two (2) locomotives at the rear of the train from the **ARTC/TfNSW boundary** to Unanderra.
- One locomotive shall be provided for each 800 tonnes or part thereof of train load.
- All locomotives shall have operable extended range dynamic brake and a minimum mass of 129 tonnes.
- The speed of the train shall be controlled by dynamic brake supplemented by use of air brake as required.

- The speed of the train shall not exceed 25 km/h.
- Crews shall have clear understanding of procedures for operating these trains in the event of loss of radio communication.

**If the dynamic brake fails on one locomotive only after departing the ARTC/TfNSW boundary** the train may continue under the control of the remaining dynamic brake and supplemented by the air brake.

- If the driver has any trouble in adequately recharging the brake pipe, the train shall be brought to a stand and held on the locomotive independent brake and sufficient handbrakes and the brake pipe fully recharged.
- The grade control valves shall be placed in the "**HP**" position.
- The train may then continue under the control of the remaining dynamic brake and supplemented by the air brake.
- If the driver again has trouble in adequately recharging the brake pipe, the train shall be brought to a stand and secured by handbrakes.
- The train may be subsequently moved only by dividing the train or attaching additional locomotive/s with operable dynamic brake.

**If the dynamic brake fails on more than one locomotive only after departing the ARTC/TfNSW boundary** the train shall be brought to a stand and secured by hand brakes. The train may be subsequently moved only by dividing the train or attaching additional locomotive/s with operable dynamic brake.

- If the train is required to be divided as above, each portion of the train shall comply with the single pipe train load and length limits as specified in Note 1 above.

# Conditions for the operation of self-propelled diesel trains - Unanderra and 91.080 km (en route to and from Moss Vale)

Version April 2018

XPT	Xplorer, Endeavour	Conditions of Operation – Down Direction
✓	--	All power cars operating
--	✓	All engines operating
✓	--	Maximum 7 trailer cars with 2 power cars or 3 trailer cars with 1 power car powering and 1 power car disabled
✓	✓	All compressors operating
✓	✓	Emergency coupler available
✓	✓	No brake cut outs permitted
✓	✓	Electro-pneumatic (EP) brake, automatic brake, hand and all spring parking brakes fully operational

XPT	Xplorer, Endeavour	Conditions of Operation – UP Direction
✓	--	One or two power cars operating
✓	--	Single power car not permitted (train must consist of at least two vehicles, either two power cars or one power car and one trailer)
--	✓	All engines operating
✓	--	At least half of traction motors working. Single car not permitted.
✓	--	Maximum 7 trailer cars with 2 power cars or 3 trailer cars with 1 power car powering and 1 power car disabled
✓	✓	All compressors operating (compressor on any dead power car to be switched to hotel supply)
✓	✓	Emergency coupler available
✓	✓	No brake cut outs permitted
✓	✓	Electro-pneumatic (EP) brake, automatic brake, hand and all spring parking brakes fully operational

## **Section 16**

### **Sydney Metropolitan Area pages**

## 16. Sydney Metropolitan Area pages

### Maximum speed of locomotives and rolling stock - Sydney Metropolitan Area

Version December 2020

SECTION	Notes	Class of Line	LOCOMOTIVES													FREIGHT VEHICLES						PASSENGER VEHICLES							
			^1	^2	^3	^4	^5	^6	^7	^8	^9	^10	^11	^12	^13	A	B	C	D	E	F	XPT	Xplorer	Loco Hauled	Diesel Railcars				
<b>City Circle</b>		L, LQ, LZ, 31	Note O lists applicable locomotives	82, CLP, GL, NR	14, 81, ALF, AN, BL, CLF, G, VL	42, 80, 80s, B, DL	18	442, 442s, 700, GM12, S, X	Note Q lists applicable locomotives	43, 44s, 930	423	D, K, T, 32	47, 48, 48200, 48s, 49, 830, 900, GPU, MM, PL	73, (K)	46, 86	59, 32(P) Steam Multi Loco Wkg (Hp limited to 16000hp)	A	B	C	D	E	F							
Central-Quay-Central (Inner)	1	A,B,C,H	40	40	40	40	40	40	40	40	40	40	40	40	N/A	U	40	40	40	N/A	N/A	40	40	40	40				
Central-Quay-Central (Outer)	1	A,B,H	40	40	40	40	40	40	40	40	40	40	40	40	N/A	U	40	40	40	N/A	N/A	40	40	40	40				
<b>Main Suburban/West</b>																													
Sydney Terminal-Granville (Main)	1	100	100	100	100	100	100	90	100	100	100	80	100	100	70	100	80	U	100	100	80	65	80	65	100	100	100		
Granville-St Marys (West Sub/Sub)	1	100	115	115	115	115	115	90	115	115	115	80	100	100	70	100	80	U	115	100	80	65	80	65	160	145	115	115	
St Marys-Penrith (Main)	1	100	115	115	115	115	115	90	115	115	115	80	100	100	70	100	80	U	115	100	80	65	80	65	160	145	115	115	
Central-Homebush (Suburban)	1	D	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	U	50	50	50	50	50	50	100	100	50	100
Homebush-Granville (Suburban)	1	D	80	80	80	80	80	80	80	100	100	80	100	100	70	80	N/A	U	100	100	80	65	80	65	100	100	100	100	
Granville-St Marys (West Main/Main)	1	100	115	115	115	115	115	90	115	115	115	80	100	100	70	100	80	U	115	100	80	65	80	65	160	145	115	115	
Central-Homebush (Local)	1	D,H	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	N/A	U	50	50	50	50	N/A	N/A	100	100	50	100
<b>Clyde</b>																													
Clyde-Parramatta Rd	2	H	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	N/A	U	50	50	50	50	N/A	N/A	60	60	50	60
<b>Richmond</b>																													
Blacktown-Richmond	1	H	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	U	50	50	50	50	N/A	N/A	115	115	50	115
Seven Hills-Blacktown (Down Bch)	1	H	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	70	U	70	70	70	70	N/A	N/A	70	70	70	70
<b>Main North</b>																													
Strathfield-Hornsby (Main)	1	100	115	115	115	115	115	90	115	115	115	80	100	100	70	100	80	U	115	100	80	65	80	65	115	115	115	115	115
Strathfield-North Strath Jct (Flyovers)	1	H	40	40	40	40	40	40	40	40	40	40	40	40	40	40	40	40	U	40	40	40	40	N/A	N/A	40	40	40	40
Nth Strath Jct-Rhodes (Down Relief)	1	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	U	80	80	80	80	65	80	80	80	80	80
West Ryde-Epping (Down Suburban)	1	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	U	90	90	80	65	80	65	90	90	90	90
Epping-West Ryde (Up Suburban)	1	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	U	90	90	80	65	80	65	90	90	90	90
Epping-Thornleigh (Down Relief)	1	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	U	75	75	75	65	75	65	90	90	75	75
Thornleigh-Pennant Hills (Up Relief)	1	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	50	U	50	50	50	50	50	50	50	50	50	50
Normanhurst-Hornsby (Down Relief)	1	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	U	75	75	75	65	75	65	80	80	75	75
Rhodes-Nth Strath Jct (Up Relief / NSRU)	1	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	75	U	75	75	75	65	75	75	75	75	75	75
<b>North Shore</b>																													
Central-North Sydney	1	A,C,H	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	N/A	U	30	30	30	N/A	N/A	80	80	30	80
North Sydney-Hornsby	1	H, V	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	30	U	30	30	30	N/A	N/A	80	80	50	80




## Notes for *Maximum speed of locomotives and rolling stock - Sydney Metropolitan Area*

- N/A Not allowed to run on this section under normal working conditions.
- ^ Numbered columns represent axle loadings. Column 1 heaviest to column 13 lightest.
- A The maximum speed for all non-stopping trains, for all underground platforms, is 10 km/h in the tunnel before the platform and 15 km/h through the platform.
- B The max speed for all locomotives in the Circular Quay area, outside of the platform, between the Harrington St and the Macquarie St portals is 25 km/h.
- C Heavy axle loads and unscrubbed diesel locomotives (i.e. diesel locomotives not fitted with approved exhaust conditioners) are only approved for restricted operation in the city underground as follows :-  
 (a) Locomotives designated in columns numbered 1 to 6 (Includes 86 class) above and freight vehicles heavier than 76 tonnes gross are not permitted to run through platforms at: (1) Wynyard station, Up and Down Shore, and (2) Town Hall station, Up and Down Shore and City Inner except in an emergency and only when issued with a current TOC waiver covering each movement.  
 (b) Unscrubbed diesel locomotives are also permitted to operate in the city underground but only when issued with a current TOC waiver covering each movement.
- D The following rolling stock is not allowed to run over the Flying Junctions between Redfern and Central in the Up direction:  
**Locomotives designated in columns numbered 1 to 6 above and freight vehicles heavier than 76 tonnes gross.**
- F Electric locomotives are allowed on the UP NORTH FORK between Meeks Road West Junction and Meeks Road Sydenham Junction ONLY.
- G 81/82/NR class locomotives and E/F class freight vehicles allowed between Sefton Park North Junction and Sefton Park East Junction at a max speed of 25 km/h.
- H Freight vehicles loaded greater than 20 tonnes axle load NOT PERMITTED, unless authorised by a TOC Waiver.
- I Freight vehicles loaded greater than 23 tonnes axle load NOT PERMITTED, unless authorised by a TOC Waiver.
- J Electrified between Rosehill & Electric train Stop sign located at location CC22+736 (Overhead Wire Structure).
- K Only locomotives fitted with vigilance control system are approved to operate outside shunting yards.
- L **Maximum load**  
 Freight trains shall not contain any freight vehicles with a **gross mass exceeding 73 tonnes**.
- Operational requirements**  
 Between Martin Place and Bondi Jct to conform to structure loading limits on the viaducts the following conditions shall be obeyed:  
 The only time that simultaneous movements are permitted on adjacent tracks over this section is when the freight trains are in the **empty** condition.  
**All trains** when passing each other on the above section shall not exceed a **maximum speed of 15 km/h**.
- N 81 Class and 48 Class locomotives only.
- O 1100, 92, 93, 6000, 6020, ACC, C, CF, CM, CEY, CSR, FIE, GWA, GWU, LDP, LDP10, MRL, PHC, QBX, RL, SCT, TT(134t), TT100 (134t), WH, XRN, SSR. Note CSR/QBX locomotives not permitted on all lines, refer to TS TOC 1 section 10 for allowable routes/lines.
- P Refer to ARTC for operating conditions.
- Q 1200, 22, 421, 422, 44, 45, 45s, 600, DC, EL, FL, GM1, HL
- R Operation of freight vehicles over 18 tonne axle loads NOT PERMITTED, unless authorised by a TOC Waiver or operating under conditions detailed in this section, *East Hills Line – operation of freight vehicles with axle loads greater than 18 tonnes*, page 74.
- S Operation of freight vehicles over 20 tonne axle loads NOT PERMITTED, unless authorised by a TOC Waiver or operating under conditions detailed in this section, *Cronulla Line – operation of 81, 82, BL, C, G, GL, RL, and VL locomotives*, page 76.
- U Unlimited number of locomotives for multiple working of locomotives (subject to a maximum horsepower limit of 16000HP per locomotive group).
- V Limited to between Hornsby and Gordon only.
- X 59, 32(P) class not permitted to traverse the East Hills Viaduct (between signal EH12 at 24.160 km and EH15.05 at 24.720 km). Traversing from Wolli Creek to Glenfield not permitted via the East Hills Line, only Wolli Creek to East Hills (up to signal EH12) or Glenfield to East Hills (up to signal EH15.05).


# Sydney Metropolitan Area - sectional freight loads

Version August 2020



# Sydney Metropolitan Area - freight and locomotive running times

Version August 2020



## Hours of signal boxes

Version December 2014

	<b>Signal Box / Complex</b>	<b>Hours of duty</b>
<b>Illawarra</b>	Sydney	Always
	Strathfield / Homebush	Always
<b>Southern</b>	Sydenham	Always
	Waterfall	Always
<b>Western</b>	# Fairfield	Always
	Campbelltown	Always
<b>Freight Lines</b>	Auburn	Always
	Clyde	Always
	Parramatta Road	Always
	Granville	Always
	Blacktown	Always
	St Marys	Always
<b>Freight Lines</b>	Penrith	Always
	Enfield Control Centre	Refer ARTC network control centre south (Junee)

# This location is manned by a qualified employee for station duties, which includes switching in for timetabled movements through the interlocking or to meet operational requirements as per requests from the Train Controller.

## Dangerous goods in the Sydney Underground

Version December 2018

The following goods are totally banned from being carried by freight trains through the Sydney Underground lines (Central to North Sydney; City Inner and City Outer; Redfern to Bondi Junction; Central to Wolli Creek Junction):

<b>CLASS 1</b>	Explosives in any quantity that requires marking of freight containers
<b>CLASS 2.1</b>	Flammable gas in bulk tankers
<b>CLASS 2.3</b>	Poison gas in any quantity which requires marking of freight containers
<b>CLASS 3</b>	Flammable liquids in bulk tanks where the hazchem code includes the letter E (this includes petrol tankers returning unpurged)

## Tonnage signals

Version 15.0 December 2012

Certain signals listed herein are treated as **Tonnage Signals**, that is to say, in order to avoid the risk of trains over a certain tonnage being brought to a stand at signals where it would be difficult for them to restart, these tonnage signals shall not be passed by trains conveying loads in excess of 75% of the prescribed load (i.e. 75% of Full Sectional Load) unless the Tonnage signal is in the clear position (or by telephone instructions in the case of failure).

The following signals are to be treated as a Tonnage signal, in accordance with Sydney Trains Network Rule *NSG 608 Passing signal at STOP*.

	Kilometrage	Signal number	Section located
<b>North</b>	17.880	WR1	Meadowbank – West Ryde
	22.308	EG21 – Down Suburban	Eastwood – Epping
	22.308	EG23 – Down Main	Eastwood – Epping
	23.745	EG45 – Down Main	Epping – Cheltenham
	23.759	EG43 – Down Suburban	Epping – Cheltenham
	32.051	HY13	Normanhurst – Hornsby
<b>Illawarra</b>	26.025	SD71 DI Down Home & Starting	Sutherland
	26.055	SD69 DR Down starting Refuge to Down Main	Sutherland
<b>West</b>	17.506	ST420M Up Home	Up Main Lidcombe
	17.506	ST422S Up Home	Up Suburban Lidcombe

## Bondi Junction – trains / vehicles less than 4 cars using diamond crossover

Version 15.0 December 2012

Whenever a train or vehicle less than 4 cars in length has to traverse the diamond crossing at Bondi Junction, through points 907 in the reverse position it shall be block worked in accordance with Sydney trains Network Rule *NSY 512 Manual block working* between SY767 and SY783 or SY770 and ES6.48 signals.

Trains or vehicles shorter than 4 cars in length may not reliably operate the track circuits.

## East Hills Line – operation of freight vehicles with axle loads greater than 18 tonnes

Version April 2020

Operation of freight vehicles over 18 tonne axle loads on the East Hills line is normally not permitted, and the note R restriction applies (as detailed in Notes for *Maximum speed of locomotives and rolling stock - Sydney Metropolitan Area* on page 70). However for the purposes of East Hills line maintenance (work trains) or when the Main South line is blocked or closed to traffic or when directed by RMC, freight vehicles over 18 tonne axle loads are permitted under special operating conditions. The following conditions shall apply:

1. Operation of freight vehicles is only permitted when the Main South lines are blocked or closed or when East Hills line maintenance is required (work trains) or when directed by RMC. Note H restriction shall not apply in this case.
2. Axle loads greater than 25 tonnes are not permitted.
3. The maximum speeds, as per *Location of speed signs* in this section, page 82, sub-section 13 and 13a, shall be strictly observed.
4. The maximum speeds associated with this operation shall be adhered to for the whole train length if any single hauled vehicle within the train consist is loaded above 72 tonnes gross mass or above 18 tonnes axle load for multipacks. This includes any dead attached or powering locomotives.
5. Operation onto the Airport line is not permitted, no operation of freight vehicles in the up direction past the 500A and 500B points on the up and down local lines.
6. Passing of freight trains between Revesby and Kingsgrove is not permitted (in effect single line working). The section for no passing is bound by Revesby Station and Kingsgrove Station with the following signals:
  - Up Main  
From Signal RY22 (20.866 km) up to Signal M12.6 (12.735 km)
  - Up Local  
From Signal RY20 (20.866 km) up to Signal L12.6 (12.735 km)
  - Down Main  
From Signal SM441DM (13.408 km) up to Signal RY23D (21.067 km)
  - Down Local  
From Signal SM437DL (12.735 km) up to Signal RY25 (21.067 km)
7. Passing of freight trains (with other freight or passenger trains) over East Hills viaduct is not permitted (in effect absolute single line working). The section for no passing is bound by signal EH12 (24.720km) up to signal EH15.05 (24.160km).
8. When travelling over the Glenfield flyover, all trains shall not move beyond signal GD20 (Up East Hills) or GD18 (Up Main South) until a full clear signal (GD20) or medium turnout signal (GD18) is shown.
9. The Network Maintainers Civil Maintenance Engineer (in charge of the East Hills Line) shall be notified of any freight vehicle operation on the East Hills line by the next working day.

# Cronulla Line – operation of 81, 82, BL, C, G, GL, RL, and VL locomotives

Version April 2016

Operation of freight vehicles and locomotives on the Cronulla line is normally not permitted, and the note S restriction applies (as detailed in Notes for *Maximum speed of locomotives and rolling stock - Sydney Metropolitan Area* on page 70). However the use of 81, 82, BL, C, G, GL, RL, VL Class locomotives is permitted on the Cronulla line for the purpose of line maintenance. The maximum speed of these locomotives shall be as detailed in Table 3 - Locomotive bridge speed restrictions on the Cronulla line:

**Table 3 - Locomotive bridge speed restrictions on the Cronulla line**

Location (km)	Structure Designation	Structure	Maximum speed (81, 82, BL, G Class) (km/h)	Maximum speed (RL, C Class) (km/h)	Maximum speed (RL, C Class) (km/h)
24.967	Princess Hwy	Steel underbridge	40	30	20
25.408	Merton St	Steel underbridge	40	30	20
25.795	Glencoe St	Steel underbridge	40	30	20
28.526	Sylvania Rd	Steel underbridge	40	30	20
29.473	Kiora Rd (Miranda station access)	Steel underbridge	40	30	20
29.516	Miranda station	Concrete subway	40	30	20
30.477	Kareena Rd	Steel underbridge	40	30	20
32.537	Gannons Rd	Steel underbridge	40	30	20
34.431	Searl Rd (Burraeneer Bay Rd)	Concrete underbridge	40	30	20
34.665	Cronulla station	Concrete subway	40	30	20

The maximum speed on all other sections of the Cronulla line (not detailed in Table 3) shall not exceed 50 km/h.

The Network Maintainers Civil Maintenance Engineer (in charge of the Cronulla Line) shall be notified of any freight vehicle operation on the Cronulla line by the next working day.

## General - Sectional running times and full sectional loads

Version April 2020

The locomotive-load-run times configurations (DOWN loads and UP loads) published in this section are for existing approved paths in the Standard Working Timetable (SWTT). For configurations that are not listed, the train shall run at the discretion of the train controller, based on the following:

- The trailing load does not exceed the sum of individual locomotive full sectional loads, accounting for load reductions specified in (TS TOC.1 Section 2.11 and 2.12)
- There is capacity on the network (based on the live status and the SWTT/DWTT) for the train controller to allocate additional times for the train if longer journey or sectional running times, or both are foreseen.
- The operator operates to the assigned schedule or under the direction of the train controller to ensure the train's arrival at critical junctions or destinations does not cause train control conflicts to the network.

The sectional running times published are based on RailNet Running Time Profiles (simulations). Train consists (locomotive and trailing loads) used in the simulations are based on the length limits in the train operating length diagram in TS TOC 1 (Section 1.11) with no speed restrictions applied.

Any planned and timetabled sectional running times used in ad hoc paths, Daily Working Timetable, and Standard Working Timetable have additional time added to the published running times (for example recovery time), which should be accounted for by the train controller / planner / programmer as appropriate.

## Main South – DOWN loads

Version December 2020

DOWN LOADS SECTIONS	LOCO-MOTIVE CLASS = L	SINGLE	DOUBLE	TRIPLE	QUAD	VEHICLE CLASS	SECT RUN TIMES	NOTES
			LOAD - TONNES					
1 SYDNEY METROP – MACARTHUR	L4	675	1350	2025	2700	A	A	
2 SYDNEY METROP – MACARTHUR	L4	800	1600	2400	3200	A	A1	
3 SYDNEY METROP – MACARTHUR	L8	650	1300	--	--	A	A1	
4 SYDNEY METROP – MACARTHUR	L9	500	1000	1500	2000	A	A1	
5 SYDNEY METROP – MACARTHUR	L2	1300	2600	3900	5200	A	A2	
6 SYDNEY METROP – MACARTHUR	L4	970	1940	2910	3880	A	A2	
7 SYDNEY METROP – MACARTHUR	L8	875	1750	2625	3490	A	A2	
8 SYDNEY METROP – MACARTHUR	L9/L10	610	1220	1830	2440	A	A2	
9 SYDNEY METROP – MACARTHUR	AC6	1500	3000	4600*	--	A	A2	*
10 SYDNEY METROP – MACARTHUR	AC6 + L2	--	2750	--	--	A	A2	b
11 SYDNEY METROP – MACARTHUR	AC6 + 2 x L2	--	--	4050	--	A	A2	b
12 SYDNEY METROP – MACARTHUR	2 x AC6 + L2	--	--	4200	--	A	A2	b
13 SYDNEY METROP – MACARTHUR	AC6 + L2	--	2750	--	--	ABCE	C1	b
14 SYDNEY METROP – MACARTHUR	L2	1300	2600	3900	5200	ABCE	C1	
15 SYDNEY METROP – MACARTHUR	L4	970	1940	2910	3880	ABCE	C1	
16 SYDNEY METROP – MACARTHUR	L8	875	1750	2625	3490	ABCE	C1	
17 SYDNEY METROP – MACARTHUR	L9/L10	610	1220	1830	2440	ABCE	C1	
18 SYDNEY METROP – MACARTHUR	L11	550	1100	1650	2200	ABCE	C1	
19 SYDNEY METROP – MACARTHUR	AC6	1500	3000	4600*	--	ABCE	C2	*
20 SYDNEY METROP – MACARTHUR	L3	1200	2400	3600	4800	ABCE	C2	
21 SYDNEY METROP – MACARTHUR	L4	1130	2260	3390	4520	ABCE	C2	
22 SYDNEY METROP – MACARTHUR	L5	1047	2094	3141	4188	ABCE	C2	
23 SYDNEY METROP – MACARTHUR	L6	926	1852	2778	3704	ABCE	C2	
24 SYDNEY METROP – MACARTHUR	L7	909	1818	2727	3636	ABCE	C2	
25 SYDNEY METROP – MACARTHUR	L8	875	1750	2625	3490	ABCE	C2	
26 SYDNEY METROP – MACARTHUR	L9	750	1500	2250	3000	ABCE	C2	
27 SYDNEY METROP – MACARTHUR	L10	725	1450	2175	2900	ABCE	C2	
28 SYDNEY METROP – MACARTHUR	L11	640	1280	1920	2560	ABCE	C2	
29 SYDNEY METROP – MACARTHUR	L12	615	1230	1845	2460	ABCE	C2	
30 SYDNEY METROP – MACARTHUR	L13	310	615	925	1230	ABCE	C2	

Note - All the above published loads in the Down direction can depart Metropolitan sites via the Main or East Hills.

Note - For trains via the East Hills line refer to Note R, Notes for Maximum speed of locomotives and rolling stock - Sydney Metropolitan Area (page 70) of this section.

Note - Refer to table of Sydney Metropolitan Area – freight and locomotive running times.

b The AC6 locomotive shall be a C44ACi or GT46CACe type AC locomotive and the L2 locomotive can be NR or AN class. A full listing of approved AC6 locomotives (United Group Ltd – C44ACi, Downer EDI Rail – GT46C-ACe and CRRC Ziyang – SDA1) is summarised under Table 8 Approved locomotives grouped into load categories – locomotive type AC in TS TOC 1.

\* Total trialling load limited to 4500 t only if consist contains any SDA1 type AC locomotives.

# Main South – DOWN sectional running times and full sectional loads

Version April 2021 (5.14)

DOWN	SECTIONAL RUNNING TIMES (INDICATIVE)					Loco	FULL SECTIONAL LOADS LOCOMOTIVE CATEGORIES = L													GRADE
	A	A1	A2	C1	C2		1	2	3	4	5	6	7	8	9	10	11	12	13	
ENFIELD WEST to:	↗	↗	↗	↗	↗	↗	Refer to Sydney Metropolitan Area – sectional freight loads (page 71) for Full Sectional Freight loads and grades													
SEFTON PRK JCT	02:48	02:48	02:48	02:48	02:48	03:00														
LEIGHTONFIELD	04:30	04:30	04:30	04:30	04:30	03:06														
CLYDE YARDS	..	..	..	..	..	..														
GRANVILLE	..	..	..	..	..	..														
FAIRFIELD	..	..	..	..	..	..														
CABRAMATTA JCT	03:24	03:24	03:24	03:24	03:24	03:54														
LIVERPOOL	03:48	03:48	03:48	03:48	03:48	04:00														
GLENFIELD	05:42	05:42	05:42	05:42	05:42	06:12														
INGLEBURN	03:42	03:48	03:48	03:48	03:54	03:36														
CAMPBELLTOWN	07:06	07:30	07:48	07:48	07:36	05:48														
MACARTHUR	01:36	01:36	01:36	01:36	01:24															
<b>Sefton Park Junction – Cabramatta Junction</b>																				
SEFTON PRK JCT to:	↗	↗	↗	↗	↗	↗	Refer to Sydney Metropolitan Area – sectional freight loads (page 71) for Full Sectional Freight loads and grades													
LIDCOMBE LOOP	11:36	11:36	11:36	06:30	06:30	06:00														
AUBURN	06:36	03:48	06:36	03:48	03:48	02:24														
CLYDE	02:18	02:12	02:12	02:12	02:12	03:00														
GRANVILLE	00:36	00:42	00:42	00:42	00:42	00:42														
MERRYLANDS	02:42	02:42	02:42	02:42	02:42	02:00														
YENNORA JCT	02:48	02:48	02:48	02:48	02:48	03:00														
CABRAMATTA JCT	06:12	06:12	06:12	06:12	06:12	04:36														
<b>Parramatta – Merrylands (Y-link)</b>																				
PARRAMATTA to:	↗	↗	↗	↗	↗	↗	Refer to Sydney Metropolitan Area – sectional freight loads (page 71) for Full Sectional Freight loads and grades													
MERRYLANDS	03:24	03:24	03:24	03:24	03:24	03:00														

## Main South – UP loads

Version December 2020

UP LOADS SECTIONS	LOCO- MOTIVE CLASS = L	SINGLE	DOUBLE	TRIPLE	QUAD	TRAIN DATA		
			LOAD - TONNES			VEHICLE CLASS	SECT RUN TIMES	NOTES
1 MACARTHUR - SYDNEY METROP	L4	675	1350	2025	2700	A	A	
2 MACARTHUR - SYDNEY METROP	L4	800	1600	2400	3200	A	A1	
3 MACARTHUR - SYDNEY METROP	L8	650	1300	--	--	A	A1	
4 MACARTHUR - SYDNEY METROP	L9/L10	500	1000	1500	2000	A	A1	
5 MACARTHUR - SYDNEY METROP	L2	1300	2600	3900	5200	A	A2	
6 MACARTHUR - SYDNEY METROP	L4	970	1940	2910	3880	A	A2	
7 MACARTHUR - SYDNEY METROP	L8	822	1644	--	--	A	A2	
8 MACARTHUR - SYDNEY METROP	L8+L10	--	1360	--	--	A	A2	
9 MACARTHUR - SYDNEY METROP	L9/L10	610	1220	1830	2440	A	A2	
10 MACARTHUR - SYDNEY METROP	AC6	1500	3000	4500	--	A	A2	
11 MACARTHUR - SYDNEY METROP	AC6 + L2	--	2750	--	--	A	A2	b
12 MACARTHUR - SYDNEY METROP	AC6 + 2 x L2	--	--	4050	--	A	A2	b
13 MACARTHUR - SYDNEY METROP	2 x AC6 + L2	--	--	4200	--	A	A2	b
14 MACARTHUR - SYDNEY METROP	L2	1500	3000	4500	6000	AB	B1	
15 MACARTHUR - SYDNEY METROP	AC6	1500	3000	4500	--	AB	B1	
16 MACARTHUR - SYDNEY METROP	AC6 + L2	--	3000	--	--	AB	B1	b
17 MACARTHUR - SYDNEY METROP	AC6 + 2 x L2	--	--	4050	--	AB	B1	b
18 MACARTHUR - SYDNEY METROP	L2	1100	2200	3300	4400	ABCE	C1	
19 MACARTHUR - SYDNEY METROP	L4	970	1940	2910	3880	ABCE	C1	
20 MACARTHUR - SYDNEY METROP	L8	875	1750	2625	3490	ABCE	C1	
21 MACARTHUR - SYDNEY METROP	L9/L10	610	1220	1830	2440	ABCE	C1	
22 MACARTHUR - SYDNEY METROP	AC6	1100	2200	3300	--	ABCE	C1	
23 MACARTHUR - SYDNEY METROP	L2	1600	3200	4800	6400	ABCE	C2	
24 MACARTHUR - SYDNEY METROP	L3/L4	1200	2400	3600	4800	ABCE	C2	
25 MACARTHUR - SYDNEY METROP	L5	1047	2094	3141	4188	ABCE	C2	
26 MACARTHUR - SYDNEY METROP	L6	926	1852	2778	3704	ABCE	C2	
27 MACARTHUR - SYDNEY METROP	L7	909	1818	2727	3636	ABCE	C2	
28 MACARTHUR - SYDNEY METROP	L8	875	1750	2625	3490	ABCE	C2	
29 MACARTHUR - SYDNEY METROP	L9	750	1500	2250	3000	ABCE	C2	
30 MACARTHUR - SYDNEY METROP	L10	725	1450	2175	2900	ABCE	C2	
31 MACARTHUR - SYDNEY METROP	L11	640	1280	1920	2560	ABCE	C2	
32 MACARTHUR - SYDNEY METROP	L12	615	1230	1845	2460	ABCE	C2	
33 MACARTHUR - SYDNEY METROP	L13	310	615	925	1230	ABCE	C2	
34 MACARTHUR - SYDNEY METROP	L3/L4	1650	3250	--	--	ABCE	C3	
35 MACARTHUR - SYDNEY METROP	L10	1290	2580	--	--	ABCE	C3	
36 MACARTHUR - SYDNEY METROP	L11	1020	2040	3200	--	ABCE	C4	
47 MACARTHUR - SYDNEY METROP	L13	510	1020	1530	2040	ABCE	C4	

Note - All the above published loads in the Up direction may enter Metropolitan sites via the Main or East Hills line with the following conditions:

Clear run shall be given Revesby to Narwee.

Note - For trains via the East Hills line refer to Note R, Notes for Maximum speed of locomotives and rolling stock - Sydney Metropolitan Area (page 70) of this section.

Note - Refer to table of Sydney Metropolitan Area – freight and locomotive running times.

b The AC6 locomotive shall be a C44ACi or GT46CACe type AC locomotive and the L2 locomotive can be NR or AN class. A full listing of approved AC6 locomotives (United Group Ltd – C44ACi, Downer EDI Rail – GT46C-ACe and CRRC Ziyang – SDA1) is summarised under Table 8 Approved locomotives grouped into load categories – locomotive type AC in TS TOC 1.

# Main South – UP sectional running times and full sectional loads

Version April 2021 (5.14)

UP	SECTIONAL RUNNING TIMES (INDICATIVE)									FULL SECTIONAL LOADS LOCOMOTIVE CATEGORIES = L													
	A	A1	A2	B1	C1	C2	C3	C4	Loco	1	2	3	4	5	6	7	8	9	10	11	12	13	GRADE
MACARTHUR to:	∅	∅	∅	∅	∅	∅	∅	∅	∅														
CAMPBELLTOWN	02:24	02:30	02:36	02:42	02:30	02:42	02:54	03:00	01:54														
INGLEBURN	07:42	07:42	07:48	07:54	08:00	08:00	08:12	08:48	07:06														
GLENFIELD	03:30	03:30	03:36	03:36	03:30	03:36	03:36	03:42	03:24														
LIVERPOOL	06:00	06:00	06:00	06:00	06:00	06:00	06:00	06:00	06:30														
CABRAMATTA JCT	03:54	03:54	03:54	03:54	03:54	03:54	03:54	03:54	03:48														
LEIGHTONFIELD	04:00	04:00	04:00	04:00	04:00	04:00	04:00	04:00	03:36														
SEFTON PRK JCT	03:18	03:18	03:18	03:18	03:18	03:18	03:18	03:18	03:24														
ENFIELD WEST	03:36	03:36	03:36	03:36	03:24	03:24	03:36	03:36	02:00														
<b>Cabramatta Junction – Sefton Park Junction</b>																							
CABRAMATTA JCT to:	∅	∅	∅	∅	∅	∅	∅	∅	∅														
YENNORA JCT	05:36	05:36	05:36	05:36	05:36	05:36	05:36	05:36	04:18														
MERRYLANDS	03:48	03:48	03:48	03:48	03:48	03:48	03:48	03:48	04:06														
GRANVILLE	03:00	03:00	03:00	03:00	03:00	03:00	03:00	03:00	02:42														
CLYDE	00:30	00:30	00:30	00:30	00:30	00:30	00:30	00:30	00:36														
AUBURN	02:24	02:24	02:24	02:24	02:24	02:24	02:24	02:24	02:12														
LIDCOMBE LOOP	03:00	03:00	03:00	03:00	03:00	03:00	03:00	03:00	02:54														
SEFTON PRK JCT	10:00	05:48	10:00	10:00	05:48	05:42	10:00	10:00	04:30														
<b>Merrylands – Parramatta (Y-link)</b>																							
MERRYLANDS to:	∅	∅	∅	∅	∅	∅	∅	∅	∅														
PARRAMATTA	03:54	03:54	03:54	03:54	03:54	03:54	03:54	03:54	03:36														

Refer to Sydney Metropolitan Area –  
 sectional freight loads (page 64) for Full  
 Sectional Freight loads and grades

Refer to Sydney Metropolitan Area –  
 sectional freight loads (page 64) for Full  
 Sectional Freight loads and grades

## Location of speed signs

Version April 2021: Section 2e, 6a, 8c

Version December 2020: Section 2d, 2e, 2f, 2g, 6a, 8b, 11

### Speed signs for the area bounded by Hornsby, Penrith, Macarthur and Waterfall

For speed signs beyond Hornsby refer to **Northern Division Pages** Location of speed signs (page 27).

For speed signs beyond Penrith refer to **Western Division Pages** Location of speed signs (page 42).

For speed signs beyond Waterfall refer to **Illawarra Division Pages** Location of speed signs (page 56).

	<b>Sub Section Area</b>	<b>Tracks</b>
<b>City</b>	1	City Circle
<b>West Suburban</b>	2a	Central – Homebush
	2b	Central – Homebush
	2c	Central – Homebush
	2d	Homebush – St Marys
	2e	Homebush – St Marys
<b>West Suburban</b>	2f	St Marys – Penrith
	2g	Eveleigh – Redfern
	2h	Illawarra Dive
	2i	Strathfield Flyover
	2j	Lidcombe Loop
	2k	Y Link Granville
<b>Carlingford</b>	3a	Clyde – Carlingford
<b>Richmond</b>	4	Blacktown – Richmond
<b>South</b>	5a	Lidcombe – Macarthur
	5b	Granville – Cabramatta
	5d	Glenfield
<b>North Shore</b>	6a	Central – Hornsby
	6c	Waverton – North Sydney Car Sidings
<b>North</b>	7a	Strathfield – Hornsby
	7b	Nth Strathfield – Rhodes
	7c	West Ryde – Epping
	7d	Epping – Thornleigh
<b>Illawarra</b>	8a	Central – Hurstville
	8b	Central – Hurstville
	8c	Hurstville – Waterfall
	8d	Hurstville – Sutherland Bi Directional
	8e	Eveleigh Yard
	9	Sutherland – Cronulla
<b>Eastern Suburbs</b>	10	Erskineville Junction – Bondi Junction
<b>Bankstown</b>	11	Sydenham – Regents Park
<b>Airport Line</b>	12	Central – Wolli Creek
<b>East Hills</b>	13	Wolli Creek Junction – Glenfield
	13a	Turrella – Revesby
<b>Metropolitan Freight</b>	14a	ARTC Boundary – Flemington West Jct
	14b	Marrickville – Botany
	14d	ARTC Boundary – Sefton Park Jct
	14e	Flemington East Jun – Flemington Sth Jn
	14f	Nth Strathfield Jun – Flemington Mkts Jn
	14g	Flemington Goods Jun – Olympic Park
<b>Leppington</b>	15	Glenfield – Leppington
	15a	Glenfield – Leppington

## Sydney Metropolitan Area – Division page references

Section 1 City Circle.....	84
Section 2a Central – Homebush Sydney Yard.....	84
Section 2a Central – Homebush Main lines .....	84
Section 2b Central – Homebush Suburban Lines .....	84
Section 2c Central – Homebush Local Lines.....	85
Section 2d Homebush – St Marys .....	85
Section 2e Homebush – St Marys Suburban / Main.....	85
Section 2f St Marys – Penrith .....	86
Section 2g Up Engine Dive Eveleigh – Redfern .....	86
Section 2h Illawarra Dive Down – Up .....	86
Section 2i Strathfield Flyovers Down / Up North Suburban.....	86
Section 2j Lidcombe Loop .....	86
Section 2k Y Link Granville.....	86
Section 3a Clyde – Carlingford .....	86
Section 4 Blacktown – Richmond .....	86
Section 5a Lidcombe – Macarthur .....	87
Section 5b Granville – Cabramatta.....	87
Section 6a Central – Hornsby (Shore).....	87
Section 6c Waverton – North Sydney Car Sidings .....	88
Section 7a Strathfield – Hornsby .....	88
Section 7b North Strathfield – Rhodes Relief Lines .....	88
Section 7c West Ryde – Epping Suburban Lines .....	89
Section 7d Epping – Thornleigh Down Relief .....	89
Section 8a Central – Hurstville Illawarra Line.....	89
Section 8b Central – Hurstville Illawarra Local Line .....	89
Section 8c Hurstville – Waterfall .....	89
Section 8d Hurstville – Sutherland Bi-directional – Illawarra Line .....	90
Section 8e Eveleigh Yard .....	90
Section 9 Sutherland - Cronulla.....	90
Section 10 Erskineville Junction – Bondi Junction .....	90
Section 11 Sydenham – Regents Park.....	91
Section 12 Central – Wollie Creek (Airport Line).....	91
Section 13 Wollie Creek Junction – Glenfield.....	91
Section 13a Turrella – Revesby Local Line .....	92
Section 14a Metropolitan Freight Lines .....	92
Section 14d Metropolitan Freight Lines .....	92
Section 14e Metropolitan Freight Lines .....	92
Section 14f Metropolitan Freight Lines .....	92
Section 14g Metropolitan Freight Lines (including Olympic Park) .....	92
Section 15 Glenfield - Leppington.....	93
Section 15a Glenfield – Leppington (Loop Lines).....	93









	DOWN	UP	
0.590	.. ..	30 ..	
0.785	40	.. ..	
1.176	Town Hall	.. ..	
2.047	Wynyard	.. ..	
2.173	60	.. ..	
2.982	.. ..	40 ..	
3.340	55	.. ..	
4.435	Milsons Point	.. ..	
4.880	30	.. 50	..
5.134	North Sydney	.. ..	
5.200	.. ..	30 ..	
5.215	10	.. No. 3 Platform	
5.220	.. ..	30 ..	
5.226	10	.. No. 2 Platform	
5.300	50	.. ..	
5.676	.. ..	10 ..	
	No 2 & 3 Road Tunnel		
5.895	50	.. ..	
6.110	Waverton	.. ..	
6.225	.. ..	50 ..	
6.480	50	.. ..	
7.175	Wollstonecraft	.. ..	
7.505	.. ..	50 ..	
7.645	50	.. ..	
8.100	80	.. ..	
8.410	St Leonards	.. ..	
8.629	.. ..	50 ..	
10.160	50	.. ..	
10.280	.. ..	75 ..	
10.295	Artarmon	.. ..	
10.560	80	.. ..	
10.860	.. ..	80 ..	
11.020	70	.. ..	
11.220	.. ..	75 ..	
11.570	.. ..	80 ..	
11.682	Chatswood	.. ..	
11.790	80	.. ..	
12.180	.. ..	60 ..	
12.860	.. ..	80 ..	
13.273	Roseville	.. ..	
13.320	.. ..	70 ..	
14.290	50	.. 80	..
14.540	.. ..	45 ..	
14.604	Lindfield	.. ..	
14.725	70	.. ..	
15.889	Killara	.. ..	
16.880	X40	.. 50 Pts	
16.900	50	.. ..	
17.035	51 Pts	X40 ..	
	On Platform Road		
17.118	Gordon	.. ..	
17.250	X25	.. 52 Pts	
17.298	70	.. ..	
17.300	.. ..	75 ..	
17.345	.. ..	X40 ..	
18.896	Pymble	.. ..	
19.070	80	.. ..	
19.230	.. ..	70 ..	
20.750	.. ..	65 ..	
20.760	50	.. ..	
20.818	Turramurra	.. ..	
20.920	80	.. ..	
21.810	70	.. ..	
21.886	Warrawee	.. ..	
22.315	.. ..	70 ..	
22.774	Wahroonga	.. ..	
23.000	.. ..	65 ..	
24.100	50	.. ..	

	DOWN	UP	
24.208	Waitara	.. ..	
24.740	.. ..	70 ..	
24.840	40	.. ..	
25.090	.. ..	40 ..	
25.115	X15	.. 515A Pts	
25.150	X15	516B X15 516B	
25.255	Hornsby	.. ..	

Down sign on Up Shore

Up sign on Down Shore

## Section 6c Waverton – North Sydney Car Sidings

KILO-MET-RAGE	DOWN	UP	
MET-RAGE	Nor- mal	XPT	Nor- mal
6.110	Waverton	.. ..	
6.410	40	.. ..	.. ..
7.670	.. ..	40 ..	
7.845	North Sydney CS	.. ..	

## Section 7a Strathfield – Hornsby

KILO-MET-RAGE	DOWN	UP	
General	Medium	High	General Medium High
11.806	Strathfield	.. ..	
12.145	538A Pts	X25 ..	
12.162	60 60 60	.. .. ..	
12.333	80 80 80	.. .. ..	
12.333	.. .. ..	60 60 60	
12.837	.. .. ..	70 70 70	
13.382	North Strathfield	.. ..	
13.559	80 115 115	.. .. ..	
14.544	Concord West	.. ..	
15.110	584B Pts	X80 ..	
15.890	50B Pts	X75 ..	
16.576	Rhodes	.. ..	
16.718	.. .. ..	80 115 115	
16.817	80 115 115	.. .. ..	
18.183	Meadowbank	.. ..	
18.761	60 100 100	.. .. ..	
18.761	.. .. ..	60 115 115	
18.910	.. .. ..	X25 ..	
19.196	West Ryde	.. ..	
19.295	60 90 90	.. .. ..	
19.295	X50 ..	.. .. ..	
20.069	60 100 100	.. .. ..	
20.155	Denistone	.. ..	
20.678	.. .. ..	60 90 90	
21.392	Eastwood	.. ..	
22.642	60 90 90	.. .. ..	
23.004	.. .. ..	60 80 80	
23.030	X25 ..	.. 104A Pts	
23.115	103B Pts	X35 ..	
23.135	50 60 60	.. .. ..	
23.230	X15 ..	.. 105B Pts	
	Up sign on Down Main		
23.233	25 25 25	.. .. ..	
	Up sign on Down Main		
23.391	Epping	.. ..	
23.475	X25 ..	.. 107A Pts	
23.570	107B Pts	X25 ..	

TS TOC.2 : 2021 issue 1  
Train Operating Conditions (TOC) Manual – Division Pages Version 21.0  
Issue date: 11 May 2021

	DOWN	UP	
23.570	108 Pts	X15 ..	
	Down sign on Up Main		
23.595	.. ..	60 60 60	
	Down sign on Up Main		
23.880	.. ..	60 60 60	
23.880	X60 ..	.. 109 Pts	
24.089	60 60 60	.. .. ..	
	Down sign on Up Main		
24.460	70 90 90	.. .. ..	
24.563	113A Pts	X60 ..	
	Down sign on Up Main		
24.565	25 25 25	.. .. ..	
	Up sign on Down Main		
24.601	.. ..	60 80 80	
24.695	X25 ..	.. 113B Pts	
	Up sign on Down Main		
25.376	Cheltenham	.. ..	
26.255	70 70 75	.. .. ..	
26.257	.. ..	60 90 90	
26.904	Beecroft	.. ..	
27.938	.. ..	60 70 75	
27.948	80 80 85	.. .. ..	
28.266	80 115 115	.. .. ..	
28.579	Pennant Hills	.. ..	
29.431	Thornleigh	.. ..	
29.947	.. ..	60 95 95	
30.489	80 85 90	.. .. ..	
30.764	80 90 90	.. .. ..	
31.562	.. ..	80 95 95	
31.720	Normanhurst	.. ..	
31.811	80 80 80	.. .. ..	
32.818	X75 ..	.. .. 500A Pts	
32.967	75 80 80	.. .. ..	
32.967	60 80 80	.. .. ..	
33.375	60 80 80	Down Relief	
33.495	.. ..	80 80 80	
33.539	X75 ..	.. .. 501B Pts	
	Up sign on Down Main		
33.539	X25 ..	.. .. 502A Pts	
33.864	Hornsby	.. ..	

## Section 7b North Strathfield – Rhodes Relief Lines

KILO-MET-RAGE	DOWN	UP	
General	Medium	High	General Medium High
12.528	55 55 60	.. .. ..	
12.750	557B Pts	.. X50 ..	
13.382	North Strathfield	.. ..	
13.619	80 85 90	.. .. ..	
13.619	.. 80 80 80	55 55 55	
13.873	.. ..	55 55 55	
14.544	Concord West	.. ..	
14.726	.. 80 80 80	80 80 80	
14.785	X80 ..	.. .. 581A Pts	
15.753	.. ..	75 75 75	
16.503	70 70 75	.. .. ..	
16.576	Rhodes	.. ..	
16.680	X70 ..	.. .. 53B Pts	

Up sign on Down Relief





## Section 13 Wolli Creek Junction – Glenfield

KILO- MET- RAGE	DOWN		UP			
	General	Medium	High	General	Medium	High
7.279	Wolli Creek Jct					
7.361		75A Pts		X50	..	..
7.450	..	..	..	50	50	55
7.528	50	50	55	..	..	..
7.829	80	80	85	..	..	..
8.213	X70	..	..		501A Pts	
8.220	..	..	..	80	80	85
8.343	80	80	85	..	..	..
8.618		504B Pts		X70	..	..
8.633	# Turrella					
9.276	60	80	85	80	80	90
9.867	80	80	85	..	..	..
9.902	..	..	..	60	80	90
10.095	# Bardwell Park					
11.368	# Bexley North					
11.679	..	..	..	80	80	90
11.745	80	100	115	..	..	..
12.624	# Kingsgrove					
13.160	60	100	115	..	..	..
13.902	..	..	..	80	100	115
13.964	X60	..	..		511A Pts	
14.589	..	..	..	60	100	115
14.646	# Beverly Hills					
14.733	60	100	110	..	..	..
15.302	..	..	..	60	95	105
15.533	60	100	100	..	..	..
15.785	# Narwee					
16.153	..	..	..	60	100	105
16.339	60	115	115	..	..	..
17.497	# Riverwood					
17.752	60	105	110	..	..	..
18.131	..	..	..	60	100	110
18.138	60	115	125	..	..	..
18.805	..	..	..	60	115	125
19.340	# Padstow					
20.230	80	115	125	..	..	..
20.306	..	..	..	80	115	125
20.430		51B Pts		X60	..	..
20.964	Revesby					
21.392	80	105	115	60	115	115
21.663		55B Pts		X60	..	..
21.700	80	105	115	..	..	..
21.992	..	..	..	70	115	115
22.554	Panania					
23.560	..	..	..	80	115	115
23.647	X25	..	..		31A Pts	
23.880	80	115	115	..	..	..
23.882				X25	..	..
					On Up Terminal Road	
24.028	East Hills					
26.755	Hawthorn					
31.303	80	105	115	..	..	..
31.360	..	..	..	80	115	115
32.200	Glenfield North Jct					
%41.081	Glenfield North Jct					
%41.082	60	100	100	..	..	..
%41.095	X60	..	..		50A Pts	
%41.359	..	..	..	80	80	80
%41.359	52B Pts			X60	..	..
%41.560	60	100	100	..	..	..

## Section 12 Central – Wolli Creek (Airport Line)

KILO- MET- RAGE	DOWN		UP		
	General	Medium	High	General	Medium
0.100	Central				
0.183	45	..	..		
	Airport Turnback				
0.270	X55	..	636 Points		
0.271	..	..	25	..	
	Up Sign on Airport Turnback				
0.271	X45	..	..		
	Airport Turnback				
0.353		635B Pts	X40	..	
0.390	..	..	X45	..	
	Up Sign on Dwn Airport				
0.420	..	..	45	..	
0.432	80	..	..	..	
0.896	..	..	80	..	
	Up Sign on Down Airport				
1.052		850B Pts	X75	..	
2.070	..	..	80	..	
2.240	60	..	..	..	
2.714	Green Square				
2.998	..	..	60	..	
3.172	80	..	..	..	
4.935	..	..	80	..	
5.105	60	..	..	..	
5.191	Mascot				
5.275	..	..	60	..	
5.445	80	..	..	..	
6.480	..	..	80	..	
6.655	60	..	..	..	
6.743	Domestic				
6.825	..	..	60	..	
7.000	80	..	..	..	
7.935	..	..	80	..	
8.110	60	..	..	..	
8.271	International				
8.280	..	..	60	..	
8.460	80	..	..	..	
9.024	..	..	80	..	
9.200	60	..	..	..	
9.489	Wolli Creek				
9.680	..	..	60	..	
9.855	80	..	..	..	

**Superseded by TSTOC 2 v22.0, 24/09/2021**



KILO-METRE	DOWN		UP	
RAGE	Normal	XPT	Normal	XPT
(5)15.070%	35	..	..	..
(5)15.145%	..	..	X40	..
(7)15.285%	X35	..	35	..
(5)15.330%	..	..	40	..
(6)15.350%	X35	..	X35	..
(8)15.390	..	..	X35	..
(8)15.490	50	..	..	..
(8)15.815	X45	..	50	..
(9)15.905	..	..	50	..
(9)15.925	X20	..	X40	..
(8)15.960	X35	X40MU		
16.030	<b>Flem West Jun</b>			
(9)16.050	..	..	X35	X40MU
(8)16.090	X35	X40MU	..	..
	<b>Lidcombe Shuttle Road</b>			
15.995	..	..	X35	..
16.020	20	..	..	..
16.330	..	..	20	..

# Down Main South.  
 % Down East Hills.

## Section 15a **Glenfield – Leppington (Loop Lines)**

KILO-METRE	DOWN		UP	
	Normal	Up signs	Normal	Down signs
50.293	X60	200A Pts	..	..
50.740	203 Pts	X60	X60	202 Pts
51.057	<b>Leppington</b>			
51.390	X60	204 Pts	205 Pts	X60
51.511	..	..	X60	205 Pts

#Km via H'bush Bay East Fork.

%Km via H'bush Bay Line.

- (1) Homebush Bay East Fork.
- (2) Homebush Bay Loop.
- (3) Inner Platform Road.
- (4) Outer Platform Road.
- (5) Up Homebush Bay West Fork.
- (6) Down Homebush Bay West Fork.
- (7) Homebush Bay connection.
- (8) Down Homebush Bay Line.
- (9) Up Homebush Bay Line.

## Section 15 **Glenfield - Leppington**

KILO-METRE	DOWN		UP	
	Normal	Up signs	Normal	Down signs
41.925	<b>Glenfield</b>			
42.017	X45	..	60A Pts	..
			#	
42.017	X60	..	62A Pts	..
			%	
42.200	75	63B Pts	X60	..
42.910	115	..	75	..
45.040	95	..	115	..
45.390	<b>Edmondson Park</b>			
45.620	115	..	..	..
50.293	60	..	..	..
50.293	X60	200A Pts	..	..
50.430	..	..	115	60
50.740	201B Pts	X60	..	..
51.057	<b>Leppington</b>			
51.390	60	60	..	..
51.511	204 Pts	X60	X60	205 Pts
52.290	X40	210A Pts	209A Pts	X40
52.539	209B Pts	X40	X40	210B Pts
52.705	13	..	..	13
52.705	X13	211A Pts	212A Pts	X13
52.710	..	60	60	..
53.000	All Sidings	25	25	All Sidings

Superseded by TS TOC 2 v22.0, 24/09/2021

## Section 17

### Passenger train operating conditions

## 17. Passenger train operating conditions

Version April 2021

### Introduction

This section of the Train Operating Conditions Manual contains specific operating conditions for passenger trains which include Sydney Trains, NSW TrainLink, privately owned diesel railcars, heritage trains and locomotive hauled trains.

### Sydney Trains and NSW TrainLink

As Sydney Trains and NSW TrainLink operate similar types of rolling stock, the following sections refer to both Sydney Trains and NSW TrainLink.

### Designation of rolling stock

All rolling stock have been classified as **Narrow, Medium, Extended Medium or Wide gauge** rolling stock as outlined TOC Manual, General Instructions, Section 10 Locomotive and Rolling Stock Data.

In Table 5 and Table 6 - Maximum speed of Sydney Trains and NSW TrainLink rolling stock (pp 98-99) the various sections of track have designated **Narrow, Medium, Extended Medium or Wide gauge**. Table 4 shows details the profile track gauge groups.

**Table 4 – Profile Track Gauge Groups and Speeds**

PROFILE	# GROUP	MAX SPEED	DESIGN SPEED	AREA OF OPERATION
Narrow gauge rolling stock	1 & 6	115	115	may run on Narrow, Medium, Extended medium or Wide gauge track areas
Medium width gauge rolling stock	2	115	115	may run on Medium, Extended medium or Wide gauge track areas
Medium width gauge rolling stock	3	130	130	may run on Medium, Extended medium or Wide gauge track areas
Medium width gauge rolling stock	3a	* 115	* 130	may run on Medium, Extended medium or Wide gauge track areas
Extended Medium gauge rolling stock	4	115	115	may only run on Extended medium or Wide gauge track areas or where authorised herein or other authority i.e. TOC Waiver
Wide gauge rolling stock	5	80	80	may only run on Wide gauge track areas with a further restriction of 20km/h through <b>ALL PLATFORMS</b> (unless otherwise specified in TOC Waiver authority)

# For group categories, refer to General Instructions, Section 10 Locomotive and Rolling Stock Data.

\* Maximum speed limited to 115 km/h compared to the design speed of 130 km/h, refer to *Speed signs - maximum kilometres per hour* in this section for further details.

For trains requiring to run in areas outside their rolling stock boundaries (e.g. rolling stock transfers, special working etc.), permission shall be obtained from Director Fleet Engineering, Asset Management Branch and all special requirements necessary for the movement are to be included on a Special Train Notice or ‘Tables’ telegram. The following table includes certain authorised working for special movements (e.g. movement of nominated Extended Medium gauge rolling stock Sydney - Broadmeadow).

## Speed signs - maximum kilometres per hour

Speed signs indicate the maximum speed permitted between a speed sign and the next in advance. Drivers shall make sure that the front of the train passes a sign at or below the speed given by the sign.

If speed signs allow an increase in speed, Drivers shall not increase speed until the rear of the train has passed the speed sign. (Sydney Trains Network Rule *NSG 604 Indicators and signs*).

The maximum speed through the curved portion of the turnout is **25 km/h** unless otherwise shown. An ‘X’ speed sign applies to crossovers and turnouts, e.g. X30.

A white background speed sign with the letters “MU” alongside the numerals, by itself or under a yellow background speed sign, applies to XPT, Xplorer, Endeavour, Hunter trains and Multiple Unit trains (Sydney Trains Network Rule *NSG 604 Indicators and signs*).

### Speed signs - Endeavour / Hunter / Xplorer Trains

Endeavour / Hunter / Xplorer trains are to run to normal or general speed signs (black numbers on a yellow background). Where Multiple Unit or Medium speed signs are provided (black MU numbers on a white background or white numbers on blue background) Endeavour / Hunter / Xplorer trains will run to these speed signs up to a maximum speed of 115 km/h. Where XPT or High speed signs are provided (black numbers on a white background), Endeavour / Hunter / Xplorer trains will run to these speed signs up to a maximum speed of 145 km/h.

### Speed signs – OSC (Outer Suburban Cars)

OSC trains are to run to normal or general speed signs (black numbers on a yellow background). Where Multiple Unit or Medium speed signs are provided (black MU numbers on a white background or white numbers on blue background) OSC trains will run to these speed signs up to a maximum speed of 115 km/h. Where XPT or High speed signs are provided (black numbers on a white background) OSC trains will run to these speed signs up to a maximum speed of 130 km/h.

### Speed signs – Millennium / Waratah / Waratah Series 2 (SGT)

Millennium / Waratah / Waratah 2 trains are to run to normal or general speed signs (black numbers on a yellow background). Where Multiple Unit or Medium speed signs are provided (black MU numbers on a white background or white numbers on blue background) Millennium / Waratah / Waratah 2 trains will run to these speed signs up to a maximum speed of 115 km/h.

## Maximum speed of Sydney Trains and NSW TrainLink rolling stock

Table 5 and Table 6 - Maximum speed of Sydney Trains and NSW TrainLink rolling stock (pp 98-99) show the maximum speed of Sydney Trains and NSW TrainLink rolling stock over the various sections of lines. These speeds are subject to permanent speed signs and temporary speeds that may be in force.

The approval applies to Down and Up directions unless specified.

Where speeds are shown in the following table, these are to be taken as authority for these trains to operate on the designated section of line.

Where the letters N/A are shown, trains are not permitted to travel over that section of line under normal conditions. When the letters N/A are shown and a train is required to travel over that section of line, permission shall be obtained from Director Fleet Engineering, Asset Management Branch before the movement commences.

**Table 5 - Maximum speed of Sydney Trains and NSW TrainLink rolling stock**

AREA / SECTION	TRACK WIDTH	ELEC-TRIFIED	SPEED-SIGNS	INTER-CITY Y/N	SUBURBAN						DIESEL RAILCARS		NOTES Locality working	
	CLASS				Double Deck	Double Deck	Double Deck	Double Deck	Single Deck	Endeavour / Xplorer	Hunter	XPT		
Train Type ⇒														
Train Width ⇒					Narrow	Medium	Medium	Medium	Extended	+ Wide Medium	Narrow	Narrow	Narrow	
++Group					1	2	3	3a	4	5	6	6		
<b>City Circle</b>														
CENTRAL – CIRCULAR QUAY – CENTRAL – City Inner and Outer	Wide*	Yes	Yes	40	40	40	40	40	40*	40*	40	N/A	N/A	1a
<b>Sydney to Lithgow</b>														
SYDNEY <> GRANVILLE – Main	Wide	Yes	Yes	100	100	100	100	100	80	100	100	100	100	
GRANVILLE <> ST MARYS –West Sub/Sub	Wide	Yes	Yes	115	115	115	115	115	80	115	115	115	115	
CENTRAL <> GRANVILLE – Suburban	Wide	Yes	Yes	80	80	80	80	80	80	80	80	80	80	
GR'VILLE <> ST MARYS – West Main/Main	Wide	Yes	Yes	115	115	115	115	115	80	115	115	115	115	
CENTRAL <> HOMEBUSH – Local	Wide	Yes	Yes	75	75	75	75	75	75	75	75	75	75	
ST MARYS <> EMU PLAINS	Wide	Yes	Yes	115	115	115	115	115	80	115	115	115	115	
EMU PLAINS <> SPRINGWOOD	Medium	Yes	Yes	85	85	85	85	85	N/A	N/A	85	85	85	
SPRINGWOOD <> LITHGOW	Narrow	Yes	Yes	100	N/A	N/A	N/A	N/A	N/A	N/A	115	115	115	
Power House Museum Siding	Narrow	No	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	10	10	N/A	
Regent Street- Mortuary Platform	Wide	No	No	10	10	10	10	10	10	10	10	10	N/A	
Eveleigh > Redfern – Up Engine Dive	Wide	Yes	Yes	15	15	15	15	15	15	15	15	15	15	
Redfern – Illawarra Dives	Wide	Yes	Yes	30	30	30	30	30	30	30	30	30	30	
<b>Clyde</b>														
CLYDE <> PARRAMATTA RD	Wide	No	Yes	N/A	N/A	N/A	N/A	N/A	N/A	N/A	10	10	10	
<b>Blacktown to Richmond</b>														
BLACKTOWN <> RICHMOND	Wide	Yes	Yes	115	115	115	115	115	80	115	N/A	N/A	115	
SEVEN HILLS > BLACKTOWN >- Down Branch	Wide	Yes	Yes	70	70	70	70	70	70	70	N/A	N/A	70	
<b>Lidcombe/Granville to Macarthur</b>														
GRANVILLE <> CABRAMATTA	Wide	Yes	Yes	100	100	100	100	100	80	100	100	100	100	
LIDCOMBE <> MACARTHUR (Via Regents Prk)	Wide	Yes	Yes	115	115	115	115	115	80	115	115	115	115	
Lidcombe <> Loop Line	Wide	Yes	Yes	15	15	15	15	15	15	15	15	15	15	
Granville <> Y Link	Wide	Yes	Yes	70	70	70	70	70	70	70	70	70	70	
<b>Central to Hornsby (Via North Shore)</b>														
CENTRAL <> NORTH SYDNEY	Wide	Yes	Yes	60	60	60	60	60	60	60	N/A	60	1a	
NORTH SYDNEY <> HORNSBY	Wide	Yes	Yes	80	80	80	80	80	80	80	80	80	80	
Waverton <> North Sydney Car Sidings	Wide	Yes	Yes	40	40	40	40	40	40	40	40	40	N/A	
<b>Strathfield to Newcastle Interchange</b>														
STRATHFIELD <> COWAN (Main)	Wide	Yes	Yes	115	115	115	115	115	80	115	115	115	115	
COWAN <> Newcastle Interchange	Medium	Yes	Yes	115	115(7a)	130(7a)	115(7a)	115(7b)	N/A	145	145	160	7a, 7b	
Strathfield <> Nth Strathfield – Flyover	Wide	Yes	No	40	40	40	40	40	40	40	40	40	40	
Rhodes>Nth Strathfield – Up Relief / NSRU	Ext Med	Yes	Yes	80	80	80	80	80	N/A	80	80	80	80	
North Strathfield <> Rhodes – Down Relief	Wide	Yes	Yes	85	85	90	85	85	80	90	90	90	90	
West Ryde > Epping – Down Suburban	Wide	Yes	Yes	90	90	95	90	90	80	95	95	95	95	
Epping > West Ryde – Up Suburban	Wide	Yes	Yes	90	90	90	90	90	80	90	90	90	90	
Epping>Thornleigh – Down Relief	Ext Med	Yes	Yes	75	75	90	75	75	N/A	90	90	90	90	
Thornleigh > Pennant Hills – Up Relief	Wide	Yes	No	50	50	50	50	50	50	50	50	50	50	
Berowra > Down Relief	Wide	Yes	Yes	50	50	50	50	50	50	50	50	50	50	

+ See *Sydney Metropolitan area - operation of wide gauge rolling stock* (page 100) re operation of Wide Gauge rolling stock in the Metropolitan area.

++ Refer to Section General Instructions, Section 10 Locomotive and Rolling Stock Data for group categories.

\* Circular Quay station restricted to Medium and Narrow rolling stock widths only, Wide and Extended Medium Rolling Stock not permitted through Circular Quay.

**For all operational requirements outside the TfNSW Metropolitan Heavy Rail network,  
refer to the CRN and ARTC Train Operating Conditions Manuals.**

**Table 6 - Maximum speed of Sydney Trains and NSW TrainLink rolling stock**

AREA / SECTION	TRACK WIDTH CLASS	ELEC-TRIFIED	SPEED SIGNS Y/N	INTER-CITY	SUBURBAN					DIESEL RAILCARS		NOTES Locality working
Train Type ⇒				Double Deck	Single Deck	Endeavour / Xplorer	Hunter	XPT				
Train Width ⇒				Narrow	Medium	Medium	Medium	Extended Medium	+ Wide	Narrow	Narrow	Narrow
++Group		1	2	3	3a	4	5	6	6			
<b>Sydney to Port Kembla/Bomaderry</b>												
CENTRAL <> HURSTVILLE - Illawarra Line	Wide	Yes	Yes	100	100	100	100	100	80	100	100	100
CENTRAL <> HURSTVILLE - Illawarra Local	Wide	Yes	Yes	80	80	85	80	80	80	85	85	85
HURSTVILLE <> HELENSBURGH	Wide	Yes	Yes	115	115	115	115	115	80	115	115	115
HELENSBURGH <> PORT KEMBLA	Medium	Yes	Yes	115	115	115	115	N/A	N/A	115	115	115
CONISTON <> KIAMA	Medium	Yes	Yes	115	115	130	115	N/A	N/A	140	140%	140
KIAMA <> BOMADERRY	Narrow	No	Yes	N/A	N/A	N/A	N/A	N/A	N/A	140	N/A	140
Redfern <> Down and Up Illawarra Dive	Wide	Yes	Yes	30	30	30	30	30	30	30	30	30
Meeks Road - XPT Depot	Narrow	No	No	N/A	N/A	N/A	N/A	N/A	N/A	15	15	15
Allans Creek - Unanderra North Junction	Narrow	No	Yes	N/A	N/A	N/A	N/A	N/A	N/A	60	60	60
<b>Sutherland to Cronulla</b>												
SUTHERLAND <> CRONULLA	Wide	Yes	Yes	100	100	100	100	100	80	100	N/A	100
<b>Erskineville Jct to Bondi Jct</b>												
ERSKINEVILLE JUNCTION <> BONDI JUNCTION	Wide	Yes	Yes	60	60	60	60@	60	60	N/A	N/A	15
<b>Sydenham to Regents Park</b>												
SYDENHAM <> REGENTS PARK	Wide	Yes	Yes	80	80	80	80	80	80	80	80	80
<b>Central to Wolli Creek (Airport Line)</b>												
CENTRAL <> WOLLI CREEK	Wide	Yes	Yes	80	80	80	80	80	80	80	80	12a
<b>Wolli Creek to Glenfield</b>												
WOLLI CREEK JCT <> TURRELLA	Wide	Yes	Yes	80	80	85	80	80	80	85	85	85
TURRELLA <> REVESBY - Main Line	Wide	Yes	Yes	115	115	125	115	115	80	125	125	125
TURRELLA <> REVESBY - Local Line	Wide	Yes	Yes	110	110	115	110	110	80	115	115	115
REVESBY <> GLENFIELD	Wide	Yes	Yes	115	115	115	115	115	80	115	115	115
<b>Glenfield to Leppington</b>												
GLENFIELD <> LEPPINGTON - Main Line	Wide	Yes	Yes	115	115	115	115	115	N/A	115	115	115
GLENFIELD <> LEPPINGTON - Loop Line	Wide	Yes	Yes	60	60	60	60	60	N/A	60	60	60
<b>Metropolitan Freight Lines</b>												
NORTH STRATH JCT <> FLEM MARKETS JCT	Wide	Yes	Yes	50	50	50	50	50	50	50	50	50
FLEMINGTON GOODS JCT <> FLEM STH JCT	Wide	Yes	Yes	40	40	40	40	40	40	40	40	40
FLEMINGTON STH JCT <> LIDCOMBE GDS JCT	Wide	Yes	Yes	40	40	40	40	40	40	40	40	40
FLEMINGTON MIDDLE JCT <> FLEM WEST JCT	Wide	Yes	Yes	50	50	50	50	50	50	50	50	50
FLEM EAST JCT/ FLEM MIDDLE JCT <> HOMEBUG BAY LOOP Olympic Park	Ext Med	Yes	Yes	50	50	50	50	50	N/A	50	50	50
FLEMINGTON STH JCT <> ARTC BOUNDARY	Wide	* Yes	Yes	70	70	70	70	70	70	70	70	70
ARTC BOUNDARY <> SEFTON PK EAST JCT	Wide	* Yes	Yes	80	80	80	80	80	80	80	80	80
SEFTON PARK EST JCT <> SEFTON PK STH JCT	Wide	* Yes	Yes	35	35	35	35	35	35	35	35	35
CHULLORA NTH JCT <> CHULLORA WEST JCT	Refer to ARTC for operating conditions											
CHULLORA WEST JCT <> PAC. NAT. DEPOT	Refer to ARTC for operating conditions											
CHULLORA TRACKFAST JCT <> INDUST SDGS	Refer to ARTC for operating conditions											
CHULLORA SOUTH JCT <> ENFIELD STH MAIN	Refer to ARTC for operating conditions											
ENFIELD SOUTH <> CAMPSIE	Refer to ARTC for operating conditions											
CAMPSIE <> WARDELL ROAD WEST JCT	Refer to ARTC for operating conditions											
ARTC BOUNDARY <> MEEKS RD WEST JCT	Narrow	No	Yes	40	N/A	N/A	N/A	N/A	N/A	40	40	40
MEEKS RD WEST JCT > MEEKS RD/ SYDENHAM UP LINE North Fork	Narrow	* Yes	Yes	25	N/A	N/A	N/A	N/A	N/A	25	25	25
SYDENHAM/MEEKS RD DOWN LINE Dwn North Fork <> MEEKS RD WEST JCT	Narrow	No	Yes	N/A	N/A	N/A	N/A	N/A	N/A	25	25	25
MEEKS RD STH JN <> MEEKS RD NORTH JCT	Narrow	No	No	N/A	N/A	N/A	N/A	N/A	N/A	25	25	25
MEEKS ROAD WEST JCT <> TEMPE JCT	Narrow	* Yes	Yes	25	N/A	N/A	N/A	N/A	N/A	25	25	14a
MARRICKVILLE JCT <> COOKS RIVER	Refer to ARTC for operating conditions											
COOKS RIVER <> BOTANY (10.410km)	Refer to ARTC for operating conditions											

+ See *Sydney Metropolitan area - operation of wide gauge rolling stock* (page 100) re operation of Wide Gauge rolling stock in the Metropolitan area.

++ Refer to General Instructions, Section General Instructions, Section 10 Locomotive and Rolling Stock Data for group categories.

% Hunter cars not permitted beyond Dunmore.

\* This section of track may be 'Unavailable for electric traction'. Refer to the 1500-volt sectioning diagrams for the current status.

@ Waratah (A) and Waratah 2 (B) sets not permitted on ESR line between Erskineville Jct and Bondi Jct (Electrical and Signalling restrictions). Refer to note 10a.

**For all operational requirements outside the TfNSW Metropolitan Heavy Rail network refer to the CRN and ARTC Train Operating Conditions Manuals.**

## Local area working - special instructions

When a number appears in the *Notes* column of Table 5, or Table 6 (pp 98-99), the pages referring to the specific locality should be examined for any special instructions or conditions that may be in force for the relevant section of line.

## Sydney Metropolitan area - operation of wide gauge rolling stock

Due to a reduction of platform clearances, all trains containing **WIDE WIDTH (Group 5)** rolling stock as designated in *General Instructions, Section 10 Locomotive and Rolling Stock Data* shall reduce speed to **20 km/h through all platforms** and not accelerate until the last car has left the platform.

## Specific localities

### 1 - City Circle

#### 1a - Non stopping trains at City Circle stations

Non stopping trains are to reduce to a speed not exceeding 10 km/h in the tunnel before the platform and then proceed through the platform at a speed not exceeding 15 km/hr. Station staff are to announce that passengers are to stand clear, as the next train will not stop at that station.

### 7 - Strathfield to Newcastle Interchange

#### 7a - Operation of Medium Width rolling stock between Sydney and the Newcastle area.

**(The following conditions apply to Up and Down directions)**

Medium width rolling stock may operate under normal conditions between Sydney and Newcastle Interchange (both directions) except as shown below:

1. The instructions contained in the Sydney Trains Network Local Appendices *NLA 312 Gosford* regarding the operation of Medium Width rolling stock in Gosford interlocking will apply.
2. The cars may pass upgrading operations and associated ballast trains at speeds not exceeding 10km/h provided that the train is safely piloted past ballast trains and machines in the non-operable position and stationary, and all staff are standing well clear.
3. In the event the cars will have to be locomotive hauled, the locomotive can be directly coupled to the leading car (T, H, M, A, B sets use special transition / emergency couplers).

Prior to coupling locomotive, the brake pipe pressure on the locomotive shall be reduced to 425KPa/60psi (or as required by the vehicle and vehicle hauling procedure) and automatic brake applied and released on the locomotive a number of times.

4. If the cars are being locomotive hauled, the crew shall be made aware of the above mentioned conditions.
5. The Train Controller shall inform the signaller at Gosford when additional trains consisting of medium width electric suburban rolling stock are required to operate or out-of-course running occurs in order to enable the signaller at Gosford to take the necessary precautions to prevent trains consisting of medium

width electric suburban rolling stock passing or being passed on an adjacent line between 81.027km and 82.174 km by a similar train.

## 7b - Transfer of Extended Medium Width rolling stock between Sydney and the Newcastle area destinations.

**(The following conditions apply to Up and Down directions)**

Approval for the restricted movement of limited *extended medium width* suburban rolling stock outside the Wide Electric area from Cowan to Broadmeadow is given subject to the following conditions:

1. Approval applies to rolling stock with a maximum width of *3077mm ONLY* as listed in Table 5, or Table 6 (pp 98-99).
2. Approval applies to the area Cowan to Broadmeadow and United Group Limited Workshops only.
3. Approval applies for the purpose of transferring double deck suburban cars for the purpose of refurbishment or major repair only.
4. Normal track speed is permitted on all track, platforms, and tunnels with the exception that a reduced speed of **30 km/h** is required through the following platforms in both the Down and Up directions:

**Gosford, Wyong, Fassifern, Cardiff, and Broadmeadow.**

5. All restrictions applying to the movement of Medium Width rolling stock in the area of Gosford Yard (as outlined in the Sydney Trains Network Local Appendices *NLA 312 Gosford* shall apply to these movements.
6. The Extended Medium width Electric rolling stock as detailed in *TS TOC 1* may pass or be passed by other passenger trains, freight trains, locomotives or other rolling stock to a maximum width of 3077mm wide travelling in the same or opposite directions, except as nominated in clause 5.

*For the complete list of 3077mm wide Suburban electric rolling stock approved to operate between Cowan and Goninans Broadmeadow under the conditions outlined above, refer to TS TOC 1, General Instructions, Section 10 Locomotive and Rolling Stock Data **Group 4 Extended Medium Width Cars**.*

*NOTE: The above approval **does not apply** to Tulloch type trailers.*

7. If the movement consists of extended medium and medium width cars, the above instructions will apply.
8. The extended medium width double deck suburban cars may pass upgrading operations and associated ballast trains at speeds not exceeding 10km/h provided that the train is safely piloted past ballast trains and machines in the non-operable position and stationary, and all staff are standing well clear.
9. Authority is given for the nominated rolling stock to pass the notice board 'WIDE GAUGE ROLLING STOCK MUST NOT PASS THIS POINT' located at Signal C19DM or C21UM at Cowan (Kilometrage 48.969km).
10. A portable headlight shall be fitted to the leading car in accordance with *NTR 406 Using lights*.

## 10 - Erskineville to Bondi Junction

### 10a – Bondi Junction – Block working of trains less than 4 cars in length.

Whenever a train or vehicle has to traverse the diamond crossing at Bondi Junction through 908/912 or 911/907 points in the reverse position and if the train or vehicle is less than 4 cars in length, it shall be block worked in accordance with Sydney Trains Network Rule *NSY 512 Manual block working between SY767 and SY783 signals or SY770 and ES6.48 signals respectively*.

Trains or vehicles shorter than 4 cars in length may not reliably operate the track circuits.

@ Due to electrical and signalling restrictions, Waratah (A sets) and Waratah Series 2 (B sets) are not permitted on the Eastern Suburbs Rail Line between Erskineville Junction and Bondi Junction.

## 12 - Central to Wolli Creek (Airport Line)

### 12a – Restriction of locomotive hauled services and non electric powered vehicles.

Under normal working conditions, diesel passenger services and non – electric powered vehicles are not permitted to operate on the Airport line.

Notice boards inscribed: *Drivers of locomotive hauled services and non-electric powered vehicles proceeding to the Airport line must not pass this point until authorised by the signaller.*

Refer to Sydney Trains Network Local Appendix NLA 108 Central - Sydenham (via Green Square) for further information.

## 14 - Metropolitan freight lines

### 14a - Restrictions for Medium, Extended Medium and Wide gauge trains at Meeks Road junction.

At Meeks Road junction trains of Medium, Extended Medium or Wide rolling stock outline may occupy either the Up Goods between 747 points and 774 points (West junction) or Down Goods between 746 catch points and 773 points (West junction). Only trains of Narrow rolling stock outline are allowed on the adjacent track.

Signaller at Sydenham Signal Control Centre is to ensure the above instructions are carried out.

## Passenger train loads and running times

Version December 2021 (5.14)

The sectional running times published are based on RailNet Running Time Profiles (simulations). Any planned and timetabled sectional running times used in ad hoc paths, Daily Working Timetable, and Standard Working Timetable have additional time added to the published running times (for example recovery time), which should be accounted for by the train controller / planner / programmer as appropriate.

## Western locomotive hauled loads – Up and Down Loads

SECTION	LOCO TYPE	SINGLE	DOUBLE	TRIPLE	QUAD	VEHICLE CLASS	SECT RUN TIMES	NOTES
1 SYDNEY - LITHGOW	L2	850	1426	--	--	--	1	NR only
2 LITHGOW - SYDNEY	L2	850	1426	--	--	--	2	NR only

## Western locomotive hauled running times

SECTIONAL RUNNING TIMES (INDICATIVE)			
Down		Up	
	1		2
SYDNEY TERMINAL	↗	CRN BOUNDARY (158.800km)	↗
REDFERN	04:12	LITHGOW	00:36
ASHFIELD	06:48	LITHGOW C.S. BOX	02:00
BURWOOD	01:42	ZIG ZAG	04:18
STRATHFIELD	01:00	EDGECOMBE	06:18
HOMEBUSH	01:00	NEWNES JUNCTION	03:06
FLEMINGTON	01:42	MT VICTORIA	09:30
LIDCOMBE	02:00	KATOOMBA	16:48
AUBURN	02:06	WENTWORTH FALLS	10:42
CLYDE	02:18	LAWSON	10:18
GRANVILLE	00:36	SPRINGWOOD	24:54
PARRAMATTA	02:00	VALLEY HEIGHTS	03:18
WESTMEAD	01:42	GLENBROOK	10:48
SEVEN HILLS	05:24	EMU PLAINS	11:24
BLACKTOWN	02:18	PENRITH	02:24
ST MARYS	09:36	ST MARYS	06:24
PENRITH	06:42	BLACKTOWN	09:54
EMU PLAINS	02:00	SEVEN HILLS	02:18
GLENBROOK	09:42	WESTMEAD	06:00
VALLEY HEIGHTS	10:48	PARRAMATTA	02:30
SPRINGWOOD	03:00	GRANVILLE	02:18
LAWSON	23:12	CLYDE	00:36
WENTWORTH FALLS	09:12	AUBURN	02:12
KATOOMBA	09:54	LIDCOMBE	02:12
MT VICTORIA	11:12	FLEMINGTON	02:18
NEWNES JUNCTION	13:24	HOMEBUSH	01:18
EDGECOMBE	03:00	STRATHFIELD	01:00
ZIG ZAG	05:42	BURWOOD	02:00
LITHGOW C.S. BOX	04:00	ASHFIELD	01:54
LITHGOW	01:42	REDFERN	06:18
CRN BOUNDARY (158.800km)	00:24	SYDNEY TERMINAL	03:18

## **Section 18**

### **Coal train working**

## 18. Coal train working

*Version April 2021 (5.14)*

### General - Sectional running times and full sectional loads

The locomotive-load-run times configurations (DOWN loads and UP loads) published in this section are for existing approved paths in the Standard Working Timetable (SWTT). For configurations that are not listed, the train shall run at the discretion of the train controller, based on the following:

- The trailing load does not exceed the sum of individual locomotive full sectional loads, accounting for load reductions specified in (TS TOC.1 Section 2.11 and 2.12)
- There is capacity on the network (based on the live status and the SWTT/DWTT) for the train controller to allocate additional times for the train if longer journey or sectional running times, or both are foreseen.
- The operator operates to the assigned schedule or under the direction of the train controller to ensure the train's arrival at critical junctions or destinations does not cause train control conflicts to the network.

The sectional running times published in this section are based on RailNet Running Time Profiles (simulations).

Any planned and timetabled sectional running times used in ad hoc paths, Daily Working Timetable, and Standard Working Timetable have additional time added to the published running times (for example recovery time), which should be accounted for by the train controller / planner / programmer as appropriate.

### North coal train loads and running times

Sect Run Times (INDICATIVE)	DOWN					UP					LOADING					EMPTY					
	2	2A	4	6	8	8G	1	3	5	Sect Run Times (INDICATIVE)	2	4	6	8	1	3	5				
MFN Flemington to:	☒	☒	☒				☒			Islington Jct to:	☒	☒	☒	☒	☒	☒	☒	☒			
Flemington Gds Sth Jct	01:00	01:00	01:00				01:00			Woodville Jct	02:06	02:06	02:00	02:06	02:00	01:54	02:06				
Flemington Gds Mid Jct	01:42	01:42	01:42				01:42			Broadmeadow	00:54	00:54	01:00	01:06	00:48	00:48	01:18				
Flemington Markets	01:12	01:12	01:12				01:12			Broadmeadow Yd	01:36	01:36	02:00	02:06	01:18	01:24	01:24				
Nth Strathfield Jct	03:42	03:42	03:42				03:42			Adamstown	00:36	00:36	00:54	00:54	00:24	00:30	00:30				
Concord West	02:30	02:30	02:30				02:24			Sulphide Jct	08:18	08:30	13:30	13:48	06:18	06:24	06:12				
Rhodes	01:36	01:48	01:54				01:36			(1) Teralba Coll Jct	02:24	02:54	02:30	03:00	02:24	02:24	02:24				
West Ryde	02:18	02:18	02:36				02:18			(2) (3) Newstan Coll Jct	07:06	08:06	09:54	11:48	06:30		06:36				
Eastwood	04:42	05:00	04:42				02:36			Fassifern	00:30	00:30	00:24	00:30	00:30						
Epping	03:48	04:06	03:42				02:18			Awaba	04:18	05:12	04:48	06:18	04:00						
Thornleigh	12:18	12:54	12:30				07:18			(4) Eraring Jct	05:30	06:00	10:12	11:24	04:06						
Hornsby	04:24	04:42	05:00				03:42			Morisset	09:00	10:30	12:06	14:42	07:42						
Berowra	11:06	11:54	12:18				09:36			(5) Vales Point Jct	03:24	04:00	03:48	04:36	03:06						
Cowan	04:24	04:36	04:36				04:24			Wyee	04:00	04:54				03:36					
Boronia x/over	03:48	03:54	03:48				03:54			Wyong	11:54	14:24				10:36					
Hawkesbury River	05:48	05:48	05:48				05:48			Gosford	16:30	19:24				16:06					
Woy Woy	15:42	16:30	16:54				13:42			Woy Woy	07:24	08:12				07:06					
Gosford	07:18	07:24	08:12				07:00			Hawkesbury River	14:24	15:42				13:30					
Wyong	16:48	17:42	19:54				15:54			Boronia x/over	14:30	14:30				08:00					
Wyee	11:24	11:42	13:48				10:30			Cowan	10:48	10:54				05:48					

DOWN	LOADED	EMPTY	UP	LOADED	EMPTY
(1) Vales Point Jct 04:06 04:30 04:54		03:30 ↗ ↘		Berowra 06:24 06:24	04:06
Morisset 03:18 03:42 03:54		03:06 03:06 03:06		Hornsby 10:12 11:00	10:00
(2) Eraring Jct ↗ 11:12 12:00 13:06		08:30 08:30 08:12		Thornleigh 04:00 04:30	03:54
Awaba 04:36 05:00 04:54		04:00 04:00 04:12		Epping 06:24 06:30	06:24
Fassifern 04:18 04:42 05:00		04:06 04:06 04:06		Eastwood 02:18 02:18	02:06
(3) (4) Newstan Coll Jct 00:18 00:18 00:24 ↗		00:18 00:18 00:18		West Ryde 02:12 02:12	02:12
(5) Teralba Coll Jct 07:00 08:06 08:06 08:54 ↗ ↘		06:36 06:36 06:30		Rhodes 02:42 02:42	02:42
Sulphide Junction 02:42 03:00 03:12 03:18 03:48 03:36 02:36 02:36 02:42				Concord West 02:12 02:06	02:06
Adamstown 09:24 10:00 09:36 09:54 14:06 12:54 07:24 07:24 07:24				Nth Strathfield Jct 02:06 02:06	02:06
Broadmeadow Yd 01:18 01:24 01:18 01:18 01:18 01:18 01:18 01:18 01:18				Flemington Markets 03:18 03:18	03:18
Broadmeadow 00:42 00:48 00:42 00:36 00:42 00:42 00:42 00:42 00:42				Flemington Gds Mid Jct 01:12 01:12	01:12
Woodville Jct 00:36 00:48 00:36 00:42 00:36 00:36 00:36 00:36 00:36				Flemington Gds Sth Jct 01:24 01:24	01:24
Islington Jct 01:12 01:18 01:12 01:12 01:18 01:18 01:12 01:12 01:12				MFN Flemington 01:36 01:36	01:36

Notes:

- (1) 5 minutes from Vales Point.
- (2) 5 minutes from Eraring.
- (3) 6 minutes to/from Newstan Colliery (Empty Arriving).
- (4) 10 minutes to/from Newstan Colliery (Loaded Departing).
- (5) 10 minutes from Teralba Colliery.

Notes:

- (1) 12 minutes to Teralba Colliery (To clear Down Main).
- (2) 6 minutes to Newstan Colliery (Empty Arriving).
- (3) 10 minutes to Newstan Colliery (Loaded Departing).
- (4) 4 minutes to Eraring.
- (5) 5 minutes to Vales Point.

## Loaded - DOWN

Section	Loco type	Single	Double	Triple	Quad	Vehicle Class	Sect Run Times
1 Sydney Metrop – Woodville Jct	L3/L4	--	--	--	4500	C	2
2 Sydney Metrop – Woodville Jct	L3/L4	--	--	--	4500	F	4
3 Sydney Metrop – Woodville Jct	AC6 (5)	--	--	4600	--	C	2
4 Sydney Metrop – Woodville Jct	AC6 (5)	--	--	4600	--	F	4
5 Sydney Metrop – Woodville Jct	AC6 (5)	--	--	5000(4)	--	C	2A
6 Newstan - Woodville Jct	L1	1650	3300	--	--	C/G	6
7 Newstan - Woodville Jct	L1+L3	--	2700	--	--	F	6
8 Newstan - Woodville Jct	L1+L3+L3	--	--	3700	--	F	6
9 Newstan - Woodville Jct	2 x L1 + 2 x L3	--	--	--	5520	G	6
10 Newstan - Woodville Jct	L3/L4	--	2100	--	4200	F/G	6
11 Newstan - Woodville Jct	AC6 (5)	--	--	5000(4)	--	C	2A
12 Teralba – Woodville Jct	L1	3150	5925 (1)	--	--	C	8
13 Teralba – Woodville Jct	L3/4	2100	4200	5925 (1)	--	F/G	8
14 Teralba – Woodville Jct	AC6 (5)	2623	5246	7369 (2)	--	C	8
15 Teralba – Woodville Jct	AC6 (5)	2623	5246	7369 (2)	--	G	8G
16 Teralba – Woodville Jct	L1			7369 (2)	--	G	8G
17 Teralba – Woodville Jct	L1+L1+L3/4			7369 (2)	--	G	8G
18 Teralba – Woodville Jct	L1		6521 (3)		--	G	8G
19 Teralba – Woodville Jct	L3/4			6521 (3)	--	G	8G

(1) To allow for greater flexibility, train of 72 vehicles can run into Teralba, however due to length restraints under the loader, only the first 55 vehicles are to be loaded. In this instance the total load will be 5925 tonnes.

(2) To allow for greater flexibility, train of up to 80 vehicles can run into Teralba, however due to length restraints under the loader, only the first 57 vehicles are to be loaded. In this instance the total load will be 7369 tonnes.

(3) To allow for greater flexibility, train of up to 60 vehicles can run into Teralba, however due to length restraints under the loader, only the first 53 vehicles are to be loaded. In this instance the total load will be 6521 tonnes.

(4) Applicable to PHTH/PHGH wagons (in ECP mode) only.

(5) Excludes SDA1 type AC locomotives (CSR, QBX).

## Empty - DOWN

Section	Loco type	Single	Double	Triple	Quad	Vehicle Class	Sect Run Times
1 Sydney Metrop - Woodville Jct	L3/L4	--	1300	--	--	C	1
2 Sydney Metrop - Woodville Jct	AC6	--	1300	--	--	C	1
3 Vales Point - Newstan	L6 + L12	--	900	--	--	C	3
4 Vales Point - Woodville Jct	L3/L4	--	1300	--	--	C	3
5 Vales Point - Woodville Jct	L1	--	1400	--	--	G	5
6 Vales Point - Woodville Jct	AC6	--	1300	--	--	C	3
7 Vales Point - Woodville Jct	AC6	--	1400	--	--	G	5
8 Eraring - Woodville Jct	L3/L4	--	1300	--	--	C	5

## Loaded - UP

Section	Loco type	Single	Double	Triple	Quad	Vehicle Class	Sect Run Times
1 Woodville Jct – Sydney Metrop	L3/L4	--	--	--	4500	C	2
2 Woodville Jct – Sydney Metrop	L3/L4	--	--	--	4500	F	4
3 Woodville Jct – Sydney Metrop	AC6 (1)	--	--	4600	--	C	2
4 Woodville Jct – Sydney Metrop	AC6 (1)	--	--	4600	--	F	4
5 Woodville Jct – Vales Pt	L3/L4	--	4200	--	--	C	6
6 Woodville Jct – Vales Pt	L3/L4	--	4200	--	--	F	8
7 Woodville Jct – Eraring/Vales Pt	AC6 (1)	2640	5280	7920	--	C	6
8 Woodville Jct – Eraring/Vales Pt	AC6 (1)	2640	5280	7920	--	F/G	8
9 Woodville Jct – Eraring	L1	3150	6300	--	--	C	6
10 Woodville Jct – Eraring/Vales Point	L1	3150	6300	--	--	F/G	8
11 Woodville Jct – Eraring	L1+L3	--	4800	--	--	C	6
12 Woodville Jct – Eraring	L1+L3	--	4800	--	--	F	8
13 Woodville Jct – Eraring	L3/L4	2100	4200	--	--	C	6
14 Woodville Jct – Eraring/Vales Point	L3/L4	2100	4200	--	--	F/G	8
15 Woodville Jct – Eraring	L1+L3+L3	--	--	6600	--	C	6
16 Woodville Jct – Eraring	L1+L3+L3	--	--	6600	--	F	8
17 Newstan – Vales Point	L6 + L12	--	2888	--	--	C	8

(1) Excludes SDA1 type AC locomotives (CSR, QBX).

## Empty - UP

Section	Loco type	Single	Double	Triple	Quad	Vehicle Class	Sect Run Times
1 Woodville Jct - Sydney Metrop	L3/L4	--	1300	--	--	C	1
2 Woodville Jct - Sydney Metrop	AC6	--	--	1500	--	C	1
3 Woodville Jct - Teralba	L3/L4	--	1800	--	--	C	3
4 Woodville Jct - Teralba	L1	--	1800	--	--	C	3
5 Woodville Jct - Teralba	AC6	--	1800	--	--	C	3
6 Woodville Jct - Newstan	L1	--	1300	--	--	C	5
7 Woodville Jct - Newstan	L3/L4	--	1300	--	--	C	5

## Western coal train loads and running times

### SECTIONAL RUNNING TIMES (INDICATIVE)

DOWN	EMPTY	UP	LOADED			
COLUMN	1		COLUMN	%2	#4	#4A
MFN Flemington to:	→	CRN West Boundary to:	→	→	→	→
Flemington Gds South	01:00	Lithgow	00:42	00:48	00:48	
Lidcombe	02:48	Lithgow C.S Box	02:00	02:00	02:00	
Auburn	02:06	Zig Zag	07:18	07:06	07:18	
Clyde	02:18	Edgecombe	11:00	11:06	12:00	
Granville	00:36	Newnes Junction	03:42	03:48	04:00	
Parramatta	02:00	Mt Victoria	19:18	18:00	19:48	
Westmead	01:42	Katoomba	23:06	19:54	21:48	
Seven Hills	05:30	Wentworth Falls	11:54	10:42	11:36	
Blacktown	02:18	Lawson	11:12	10:24	10:54	
St Marys	09:54	Springwood	26:36	25:06	25:36	
Penrith	07:00	Valley Heights	04:06	03:42	03:54	
Emu Plains	02:06	Glenbrook	12:00	11:00	11:24	
Glenbrook	08:18	Emu Plains	12:54	11:36	11:54	
Valley Heights	09:24	Penrith	02:36	02:30	02:18	
Springwood	02:36	St Marys	07:36	07:24	07:42	
Lawson	17:42	Blacktown	10:54	10:48	11:30	
Wentworth Falls	06:48	Seven Hills	02:24	02:18	02:30	
Katoomba	08:00	Westmead	06:18	06:18	06:24	
Mt Victoria	18:06	Parramatta	02:36	02:30	02:48	
Newnes Junction	13:06	Granville	02:18	02:18	02:30	
Edgecombe	03:00	Clyde	00:36	00:36	00:36	
Zig Zag	05:48	Auburn	02:24	02:24	02:36	
Lithgow C.S. Box	04:00	Lidcombe	02:12	02:12	02:30	
Lithgow	01:42	Flemington Gds Sth Jct	01:42	01:42	01:48	
CRN West Boundary	00:24	MFN Flemington	01:36	01:36	01:36	

% / # Air brake (%) or Dynamic brake (#) for planning purposes only between Katoomba and Valley Heights.

### Empty - DOWN

Section	Loco type	Single	Double	Triple	Quad	Vehicle Class	Column
1 Sydney Metrop – Newnes Jct/Lithgow	L3/L4 (3)	--	--	--	1125	C	1
2 Sydney Metrop – Newnes Jct/Lithgow	(1)	--	--	--	1125	C	1
3 Sydney Metrop – Newnes Jct/Lithgow	L3/L4 (4)	--	--	784	--	C	1
4 Sydney Metrop – Newnes Jct/Lithgow	L3/L4	--	--	--	908	C	1
5 Sydney Metrop – Newnes Jct/Lithgow	(2)	--	--	--	908	C	1
6 Sydney Metrop – Newnes Jct/Lithgow	AC6	--	1300	--	--	C	1

(1) 2xL3/L4+2xDL or 3xL3/L4 + 1xDL.

(2) 1xL3/L4+3xDL.

(3) 1x L3/L4 locomotive may be placed off line.

(4) 2xL3/L4 + 1xDL.

### Loaded - UP

Section	Loco type	Single	Double	Triple	Quad	Vehicle Class	Column
1 Lithgow/Newnes Jct – Sydney Metrop	L3/L4	--	--	--	4500	C/F	%2/#4
2 Lithgow/Newnes Jct – Sydney Metrop	(1)	--	--	--	4500	C/F	%2/#4
3 Lithgow/Newnes Jct – Sydney Metrop	L3/L4 (3)	--	--	3344	--	C/F	%2/#4
4 Lithgow/Newnes Jct – Sydney Metrop	L3/L4	--	--	--	3876	C/F	%2/#4
5 Lithgow/Newnes Jct – Sydney Metrop	(2)	--	--	--	3876	C/F	%2/#4
6 Lithgow/Newnes Jct – Sydney Metrop	AC6 (5)	--	--	4600	--	C/F	%2/#4
7 Lithgow/Newnes Jct – Sydney Metrop	AC6 (5)	--	--	5000(4)	--	C/F	#4A

(1) 2x L3/L4+2xDL or 3x L3/L4 + 1xDL.

(2) 1x L3/L4+3xDL.

(3) 2x L3/L4 + 1xDL.

(4) Applicable to PHTH/PHGH wagons (in ECP mode) only.

(5) Excludes SDA1 type AC locomotives (CSR, QBX).

% Air brake or # Dynamic brake for planning purposes only between Katoomba and Valley Heights.

## Illawarra coal train loads and running times

### SECTIONAL RUNNING TIMES (INDICATIVE)

DOWN	LOADED	EMPTY	UP	LOADED	EMPTY			
Sect Run Times	2	4	1	2	Sect Run Times	2	4	1
Marrickville Jct	2	4	1	2	Inner Harbour			2
Meeks Road Junction	02:06				Coniston			03:18
Wollli Creek Junction	04:54				Wollongong			01:30
Hurstville	10:00				Corrimal			04:42
Mordale	02:42				Thirroul			05:48
Sutherland	12:54				Scarborough			07:00
Waterfall	20:54				Coal Cliff			03:54
Helensburgh	08:30				Otford			07:30
(1) Metrop Coll Jct	02:36	2			(1) Metrop Coll Jct			05:06
Otford	04:18	04:24			Helensburgh			01:48
Coal Cliff	08:18	10:00			Waterfall			08:24
Scarborough	04:30	06:54			Sutherland			12:36
Thirroul	07:30	07:12			Mordale			07:06
Corrimal	06:30	05:54			Hurstville			02:00
Wollongong	05:48	04:54			Wollli Creek Junction			07:36
Coniston	01:30	01:36			Meeks Road Junction			02:06
Inner Harbour	07:42	07:42			% Marrickville Jct			03:36
Inner Harbour		2			Wongawilli Junction		2	
Unanderra North Jct		7			Unanderra	2	10	
Unanderra		3	2		Unanderra North Jct	3		
Wongawilli Junction		10			Inner Harbour		8a	

Notes:

(1) 5 minutes to/from Metrop Colliery.

Notes:

(1) 5 minutes from/to Metrop Colliery.

### SECTIONAL RUNNING TIMES (INDICATIVE)

DOWN	LOADED
Sect Run Times	All
Coniston	2
Unanderra North Jct	03:48
Unanderra	04:24
++89.200 km	--
++91.080 km	06:18

++ On Unanderra – Moss Vale refer to Illawarra Division Pages for full sectional loads

## Loaded - DOWN

Section	Loco type	Single	Double	Triple	Quad	Vehicle Class	Sect Run Times
1 Sydney Metrop – Inner Harbour	L3/L4	--	--	--	4500	C/F	2
2 Sydney Metrop – Inner Harbour	(1)	--	--	--	4500	C/F	2
3 Sydney Metrop – Inner Harbour	L3/L4 (3)	--	--	3344	--	C/F	2
4 Sydney Metrop – Inner Harbour	L3/L4	--	--	--	3876	C/F	2
5 Sydney Metrop – Inner Harbour	(2)	--	--	--	3876	C/F	2
6 Sydney Metrop – Inner Harbour	AC6 (4)	--	--	4600	--	C/F	2
7 Metrop Colliery - Inner Harbour	L3/L4	--	4500	--	--	C/F	4
8 Metrop Colliery - Inner Harbour	AC6 (4)	--	5200	--	--	C/F	4

(1) 2xL3/L4+2xDL or 3xL3/L4 + 1xDL.

(2) 1 x L3/L4+3 x DL.

(3) 2 x L3/L4 + 1xDL.

(4) Excludes SDA1 type AC locomotives (CSR, QBX).

## Empty - DOWN

Section	Loco type	Single	Double	Triple	Quad	Vehicle Class	Sect Run Times
1 Inner Harbour- Unanderra	AC6	--	1125	--	--	C/F	1
2 Inner Harbour- Unanderra	L3/L4	--	1125	--	--	C/F	1
3 Unanderra – Wongawilli Junction	L4	1600	--	--	--	C/F	2

## Loaded – UP

Section	Loco type	Single	Double	Triple	Quad	Vehicle Class	Sect Run Times
1 Unanderra – Inner Harbour	AC6	--	4500	--	--	C/F	2
2 Unanderra – Inner Harbour	L4	--	4200	--	--	C/F	2
3 Unanderra – Inner Harbour	L3	--	4500	--	--	C/F	2
4 Wongawilli Junction – Unanderra	L4	1600	--	--	--	C/F	4

## Empty - UP

Section	Loco type	Single	Double	Triple	Quad	Vehicle Class	Sect Run Times
1 Inner Harbour – Sydney Metrop	L3/L4	--	--	--	1125 (3)	C	1
2 Inner Harbour – Sydney Metrop	(1)	--	--	--	1125	C	1
3 Inner Harbour – Sydney Metrop	L3/L4 (4)	--	--	784	--	C	1
4 Inner Harbour – Sydney Metrop	L3/L4	--	--	--	908	C	1
5 Inner Harbour – Sydney Metrop	(2)	--	--	--	908	C	1
6 Inner Harbour – Sydney Metrop	AC6	--	--	1300 (5)	--	C	1
7 Inner Harbour – Metrop Colliery	L3/L4	--	1125 (4)	--	--	C	1
8 Inner Harbour – Metrop Colliery	AC6	--	1300	--	--	C	1

(1) 2xL3/L4+2xDL or 3xL3/L4 + 1xDL.

(2) 1 x L3/L4+3 x DL.

(3) 1 x L3/L4 locomotive may be placed off line.

(4) 2 x L3/L4 + 1xDL.

(5) 1 x AC6 off line.